

## 10218 Pet Shop

Welcome to text-based instructions from LEGO for the Blind. Before you start building, here are some terms we'll be using:

**Front:** towards you.

**Back:** away from you.

**Up:** towards the ceiling.

**Down:** towards the floor.

**Stud:** the bump on a Lego brick. Example: A 2x1 brick has two studs on it.

**Vertically:** going from front to back.

**Horizontally:** going from left to right.

**Upright:** pointing up towards the ceiling, and down towards the floor.

**Symmetrically:** a mirror image. Example: If you place a 2x1 brick with technic connector on the front wall at the right, connector to the front, and then place another such piece symmetrically on the back wall, at the right, the technic connector of the second piece should point to the back, since it will be placed symmetrically.

There are also abbreviations defined at the end of this file.

This highly detailed, 3-story Pet Shop building and townhouse with full internal and external detailing is the perfect addition to your LEGO town. Greet customers with a menagerie of pets and let them treat them with a selection of toys and supplies. The pet shop building features a hinged staircase for easy access, upper apartment with kitchenette and upper loft overlooking the open plan interior below. To the side, the tastefully appointed townhouse features a detailed ground floor with accessories and spiral staircase leading to the upper floor. The attic space features storage boxes and French doors leading out to an elegant front balcony, while the rooftop garden, complete with fresh vegetables, brightens up the rear of the building.

Book 1.

Bag 1 number 1

1. Put a flat 32x16 ver on the table. Put a flat smooth 6x1 hor on its front edge, starting from the left side.
2. Put a flat smooth 4x1 hor to the right.
3. Put a flat smooth 6x1 hor to the right.

Number 2

1. Put a flat smooth 2x1 hor to the back of the PP, starting from the right.
2. Put a flat smooth 2x1 hor to the left.
3. Repeat.
4. Repeat.
5. Put a 2x1 grate hor to the left.
6. Put a flat smooth 2x1 hor to the left.
7. Repeat.
8. Repeat.
9. Put a flat smooth 2x1 hor to the back of the PP.
10. Put a flat smooth 1x1 to the back, on the left.
11. Put a flat smooth 2x1 ver to the back.
12. Put a flat smooth 2x2 to the back and to the right, starting from the left edge.
13. Put a flat 3x1 ver to the front.
14. Put a flat smooth 2x2 to the right and to the front, touching the 2x1 pieces on the left and on the front.
15. Put a flat smooth 2x2 to the right.
16. Put a flat smooth 2x1 hor to the right, touching the grate piece.
17. Put a flat 3x1 ver to the back, on the left.
18. Put a flat smooth 1x1 to the right, touching the 2x1 on the front.
19. Put a flat smooth 2x2 to the right and to the front.

20. Put a flat smooth 2x2 to the right.
21. Repeat.
22. Repeat.

Bag 2 number 3

1. Put a flat 4x1 hor to the back of the PPs, skipping two rows to the back and three columns from the right edge to the left.
2. Put a flat 6x1 hor to the back and to the left and to the right of the PP.
3. Put a flat 6x1 hor to the back.
4. Put a flat 8x1 hor to the back and to the left and to the right.
5. Put a flat 1x1 to the back of the leftmost button of the PP.
6. Put a flat smooth 4x1 ver to the back.
7. Put a 4x2 ver to the back and to the right.

Number 4.

1. Make a part. Put a flat 8x1 hor on the table. Put a flat 3x1 hor on its left end. Put a flat smooth 2x1 hor to the right. Put a flat 3x1 hor to the right. Put this part hor on top of the flat 8x1 piece.
2. Put a flat smooth 2x1 hor to the front of the flat smooth piece in the middle of the PP, on top of the flat 6x1 piece.
3. Put a curved 2x1 hor to the right of this flat 6x1 piece.
4. Put a curved 2x1 hor to the left of the same 6x1 piece.
5. Skipping four buttons to the left, put a curved 4x1 hor to the left (ending on the left edge).
6. Put a flat 6x2 hor on top of the two vertical parallel flat 3x1 pieces (from bag 1), skipping their front buttons.

Number 5

1. Put a 4x2 hor to the back, in the middle.
2. Put a flat 2x1 ver left and to the front of the PP, its front button on the leftmost back button of the flat 6x2 piece, and its back button on top of the 2x2 flat smooth piece.
3. Put a flat 2x1 ver symm to the right of the 4x2 piece.
4. Put a flat 4x1 hor on top of the back row of the 4x2 piece.
5. Put the 1x1 buttons on top the 1x1 leaflets, make three such parts and put them on top of the flat pieces on the right of the base, on its outer corners.

Bag 4 number 6

1. Put a 2x1 with the hole ver on the left edge, to the back of the 2x1 curved piece.
2. Put a 10x1 ver to the back.
3. Put a 2x1 with the hole ver to the back.
4. Put a 10x1 hor to the back and to the right.
5. Put a 3x1 hor to the back of the three rightmost buttons of the PP.
6. Put a 4x2 hor to the back and to the left of the PP, aligned on the right.
7. Put a cylinder to the right of the hor 10x1 piece.
8. Put a 1x1 slide to the back, slide to the back.
9. Insert a connector into a 2x1 piece with the hole and put it ver on the right edge, back to the curved 2x1 piece, connector to the right.
10. Put a 10x1 ver to the back.
11. Insert a connector into a 2x1 holed piece and put it ver to the back, connector to the right.
12. Put a cylinder to the back.
13. Put a slide piece to the back, slide to the back.

Number 7.

1. Put a 1x1 wedge piece into the garbage can, cover and put to the left of the 4x2 piece.
2. Put a 1x1 slipper piece ver on top of the cylinder and the slide on the right edge, toe to the back.
3. Put another slipper piece on top of the other cylinder the same way.
4. Put three 2x1 curved pieces on the front wall, on top of the other three curved pieces,
5. Put a 4x2 ver on top of the other ver 4x2 in the middle.
6. Put a 2x1 lip piece hor, lip to the back, to the back of the right button of the middle 2x1 curved piece.

Number 8

1. Insert a long end of a short connector into a 1x1 piece. repeat. Put them on top of the slipper pieces, connectors facing each other.

2. Put a 3x1 hor to the left of the left PP.
3. Put a 6x1 hor to the left.
4. Put a 6x1 ver to the left and to the front.
5. Put a 6x1 ver to the front.
6. Put a 3x1 ver to the front.
7. Make a part. Put a F 6x2 hor on the table.
8. Put a F 6x1 hor on top of the front row.
9. Put a three-button corner piece on the leftmost two buttons of the back row, letter J.
10. Put a lip 2x1 piece to the right, lip to the back.
11. Put a corner piece to the right, letter H.
12. Put this part, the way it is, on the front, on the top stair of the stairs, on the back row
13. Put a 3x1 hpr on the right end of the front wall, to the back of the curved piece.
14. Put a 2x1 curved piece ver to the back, on the right wall.
15. Put a 3x1 ver to the back.
16. Put a 2x1 curved ver to the back.
17. Put a 6x1 ver to the back.
18. Put a 4x2 hor on top of the other hor 4x2, in the back.

Number 9

1. Put a 4x2 ver on top of the other ver 4x2 pieces, in the middle of the base.
2. Stack two F 1x1 and put them on top of the left connector piece.
3. Put a 4x2 from a sep bag hor to the left.
4. Put a 6x1 hor to the left.
5. Make a part. Put a F 3x1 hor on the table. Put a F 4x1 hor on top, overhanging on the left.
6. Put a F 2x1 hor on top of its left two buttons.
7. Put this part ver, 2x1 to the back, on the back end of the right wall.
8. Put a 6x1 ver to the front.
9. Put a 3x1 ver to the front.

Number 10

1. Put a three-button corner piece to the front and to the left of the PP, letter J.
2. Put a small smooth corner piece to the left, upright sides to the right and to the front.
3. Put a button on top of a 1x1 piece with the handle. Repeat. Put one such part to the left of the PP, handle to the left. Skip two buttons to the left and put the second part in, handle to the right.
4. Put a small smooth corner piece to the left, upright sides to the front and to the left.
5. Put a three-button corner piece to the left and back and right, letter F.
6. Put a 2x1 curved piece hor to the left.
7. Put a F 4x1 hor to the left.
8. Put a 2x1 curved piece hor to the left.
9. Put a 6x1 ver to the back.
10. Put a 2x1 curved piece from a sep bag ver to the back.
11. Put a 6x1 ver to the back.

Number 11

1. Put three FS 4x1 pieces hor in the middle of the three bottom stairs on the front wall.
2. Put six F 1x1 pieces at the sides of each FS PP.
3. Install the doors into the 4x1 frame and put it hor, doors to the back, on the back wall, hanging diagonally to the back from the two connectors.
4. Put a 2x1 upright grate piece ver on the right wall, grate hanging to the left, on the 3<sup>rd</sup> and 4<sup>th</sup> buttons from the back.
5. Make a part. Flip a 1x1 cornice piece upside down, cornice to the right, and put its side button into the base of another 1x1 cornice piece lying on its back, its side button to the ceiling. Repeat.
6. Put one such part, the way it is, on the front wall, on top of the right 1x1 handle piece.
7. Put the other part to the left, symm.

Number 12.

1. Put a frame hor on the right back corner, handle to the left.
2. Put a F 8x8 to the left, on the left back corner.
3. Put a F 8x8 to the front.

4. Put a F 8x8 to the front of the frame.
5. Put a F 2x1 ver to the front, on the right front corner.
6. Put a F 2x1 ver to the left.
7. Put a F 2x1 hor to the left of its back corner.
8. Skip two buttons to the left and put a F 2x1 hor to the left.

Number 13.

1. Make a part. Put a FS 2x1 upside down hor on the table.
2. Put two F 1x1 with the clasp on top, upside down, one on left and one on right, clasps to the back.
3. Put two one-button sector pieces, upside down, on top, curved sides to the front and facing away from each other.
4. Install the way it is in the front wall, in the recession on the right side.
5. Put a 6x1 hor on the left end of the back edge.
6. Make a 4x3 hor checker pattern with the 1x1 FS and 1x1 F pieces to the front of the PP, skipping the leftmost column. Start with the F 1x1 on the left back corner of the pattern base.

Number 14.

1. Make a toilet part. Put a pot on the table, handle to the back. put a clasp upright on the handle from above. Put a ring on top of the pot and the clasp. Put a 1x1 cornice piece on top of the clasp, cornice to the left. Put a F 1x1 upright on the left-side button of the PP, and another the right side of the cornice piece. put a FS 2x1 hor on top of the three PPs. Put a button upright to the left, on the left 1x1 upright button. Install this part in the middle of the checker pattern, upright button to the front.
2. Stack two F half-round pieces and install them, upside down, rounded side to the front, on top of the sectors in the front, in the middle, overhanging to the back.
3. Put a bench piece, hor, upright side to the back, in the middle of the upper stair on the front wall.
4. Put a colonnade piece ver on the front end of the right edge, in front of the right wall.
5. Put another colonnade piece hor to the left, on the front.
6. Repeat.

Number 15

1. Put a 1x1 on the back button of the vertical colonnade on the right wall.
2. Put a 1x1 button on top.
3. Put a 1x1 on the rightside of the top stair, to the right of the bench piece.
4. Put a 1x1 to the left of the bench piece.
5. Stack two F 2x1 and put them hor to the back and to the left of the PP, on the left front corner of the platform.
6. Put an 8x1 ver on the left edge, starting from the back, to the front of the horizontal 6x1 on the back edge.
7. Put a 3x2 hor to the right of the first two buttons of the PP.
8. Skip one row to the back and put a 4x1 shelf piece hor, smooth side to the front.

Number 16

1. Make a curved railing part. Put a movable F 2x1/2x1 piece hor on the table, open like a 4x1 piece, hinge to the front. Put a F 1x1 clasp on the rightmost button. Put a F 1x1 to the left.
2. Take another movable piece, turn it hor, open, hinge to the back, and put its right two buttons on top of the left two buttons of your part.
3. Repeat.
4. Take another movable piece, turn it hor, open, hinge to the front, and put its right two buttons on top of the left two buttons of your part.
5. Install this part, the way it is, on the right side of the front, two rightmost buttons on the right end of the front edge, then curving along the sectors, then the leftmost two buttons on the front edge to the left of the sectors.
6. Put a 6x1 ver on the front end of the right edge.
7. Put an 8x1 ver to the back.
8. Put a 6x1 hor to the back and to the left.
9. Put a 6x1 ver on the front end of the left edge, to the front of the 8x1.

Number 17

1. Put a F 2x1 hor to the front and to the right of the PP.

2. Skip four buttons to the right and put a F 2x1 hor on top of the left end of the movable part.
3. Put a F 2x1 hor on top of the right end of the movable part.
4. Put four candlestick pieces, wide end down, on the washer board piece to the back of the sectors.
5. Put six upright clasp pieces at the ends of the bottom three stairs of the staircase.
6. Put two 1x1 wedge pieces at the end of the top stair, tall sides to the back.
7. Put a F 2x1 with one button to the front and to the right of the shelf piece, so that its left side is to the front of the rightmost button of the shelf piece.
8. Put a cylinder on top of the PP.

Number 18

1. Go to the back wall. Put a 1x1 on the leftmost button of the right side of it.
2. Put a 4x1 hor to the right.
3. Put an 8x1 ver to the right and to the front.
4. Put an 8x1 ver to the front.
5. Put a 1x1 to the left.
6. Go to the back wall. Put a 1x1 on the rightmost end of the left side of it.
7. Put a 4x1 hor to the left.
8. Put a 4x1 ver to the left and to the front/
9. Put a three-button corner piece to the front and to the right, letter H.
10. Put a 2x1 ver to the front, on the left wall.
11. Put a 3x1 hor to the right, in the corner made by two PPs.
12. Put a FS 3x1 hor to the front (one step down).
13. Put an 8x1 ver to the front of the 2x1, on the left wall.

Number 19

1. Make an old-fashioned phone part. Put a F 2x1 hor on top of a F 2x2 with one button. Put a 1x1 wedge on its right button, tall side to the left.
2. Put a 1x1 clasp to the left, hor.
3. Insert a candlestick in the clasp, facing front and back. install this part? The way it is. On the cylinder in front of the shelf piece.
4. Put the trapdoor hor into the gap.
5. Put a curved 2x1 ver on the right edge of the door, on the first two buttons.
6. Put a F 2x1 ver on top.
7. Put a cup on top.

Number 20.

1. Make a couch. Put a F 3x2 ver on the table. Put a F 6x1 hor on top, its two leftmost buttons on top of the two back-row buttons of the 3x2. Put a F 3x2 ver on the table, underneath the two rightmost buttons of the 6x1, symm to the left.
2. Put a F 6x1 hor to the front of the first 6x1. Put a F 4x1 hor to the front, in the middle.
3. Put a F 2x1 ver on the back end of the left side.
4. Repeat symm on the right.
5. Put two FS 2x2 pieces side by side on the first two rows, between the two PPs.
6. Put a F 6x1 hor to the back.
7. Put two hammer pieces on the front ends, buttons to the back.
8. Put two F 2x1 ver on top and to the back of the hammer pieces.
9. Flip over and put two disk pieces underneath.
10. Flip over and put a ... what'dycallit? Smooth curved piece at the back row.
11. Put two wedge pieces to the left and to the right, tall sides facing each other.
12. Install ver, seat to the left, to the front of the cup stand at the back of the right wall.

Number 21.

1. Make a part. Put a 1x1 on top of a 1x1 with a side button, button to the front.
2. Put a 1x1 with a cornice from a sep bag on top, cornice to the front.
3. insert a clasp stick into the PP from the back.
4. install, the way it is, on the front wall, in the middle, to the back of the right wedge on the top stair.
5. Make a part. Put two 1x1 with the cornice side by side on the table, cornices to the front. connect by putting a FS 2x1 upright on top of the side buttons. install the way it is on the right end of the front wall.
6. Put an 8x1 ver to the back, on the right wall.

7. Put a 6x1 ver to the back.
8. Put a 6x1 ver to the back and to the left.
9. Skip four buttons to the left and put a 6x1 hor on top of the left side of the back wall.
10. Put an 8x1 ver to the front.
11. Put a 4x1 ver to the front.
12. Put a 1x1 to the front.
13. Put a FS 3x1 on the front row of the back stair.
14. Put a 3x2 hor to the back, one step up.

Number 22.

1. Make a part. Stack two F 3x2. Put two FS 3x2 hor on top, side to long side. Install to make the last stair of the back staircase.
2. Put a FS 3x1 hor to the front, on step down.
3. Put a 1x1 somewhere to the right of the top stair of the back staircase.
4. Put a F 2x2 with one button from a sep bag on top of another such piece, diamond-like. Install on top of the four candlesticks.

Number 23.

1. Stack four 1x1 pieces, install them in the middle of the front wall, to the right of the column with the side buttons.
2. Insert the short end of a stick into the small end of a cone and install to the back of the column with side buttons.
3. Go to the left side of the back wall. Put a 2x1 hor on its right end.
4. Skip two buttons to the left and put a 1x1 on.
5. Put an 8x1 ver to the left and to the front.
6. Put a 6x1 ver to the front.

Number 24.

1. Make a mailbox, put a FS 2x1 letter inside, put a 1x1 wedge on the right back corner, tall side to the front, and install on the left front corner, to the front of the left wall, overhanging to the front.
2. Put a 1x1 button on the rightmost button of a F rounded 5x1 piece.
3. Put a FS 3x1 hor to the left. Install this part, the way it is, on the top back stair, its leftmost button on the left wall.
4. Go to the right side of the back wall. Put a 2x1 hor on its left end.
5. Skip two buttons to the right and put a 1x1 on.
6. Put an 8x1 ver to the right and to the front.
7. Put an 8x1 to the front.
8. Put a 1x1 to the left, on the front wall.

Number 25

1. Put two corniced 1x1 pieces side by side, connect by a FS 2x1 and put hor on the right end of the front wall, at the same position as the other such part.
2. Put an 8x1 ver to the back.
3. Repeat.
4. Put a 2x1 hor to the back and to the left.
5. Slip two buttons to the left and put a 1x1 on.
6. Insert the flower heads on the stalk, put on the cone and install on the diamond piece over the candlesticks.

Number 26.

1. Put an 8x1 ver on the front end of the left wall, starting on the mailbox.
2. Put a 4x1 ver to the back.
3. Stack two F 2x1, put a 1x1 button underneath its back button and install ver to the back of the PP.
4. Put a 2x1 ver to the back.
5. Put a 2x1 hor to the back and to the right.
6. Skip two buttons to the right and put a 1x1 on.
7. Put a stick with the knobs on top of the long stick behind the corniced column, parallel to the ground, larger knob on. hang a hat on the smaller knob.

Number 27

1. Install the window panes into two frames and put into the gaps at the sides of the back wall.
2. Put a three-button arch bit ver on the leftmost end of the right side of the back wall, upper side to

the back.

3. Repeat on the left.
4. Put another such piece on the left side of the front wall, on the right button of the mailbox, upper side to the front.
5. Put another such part the same way on top of the corniced column to the right.

Number 28

1. Make a part. Put a F 4x1 hor on the table. Put a FS 3x1 hor on it, starting from the left. Put a 1x1 button to the right. Put a 1x1 button underneath it, on the left end.
2. Repeat to make another such part.
3. Stack them and put on top of the back stair to make a rounded stair.
4. Put a 1x1 on the right end of the front wall, on the left button.
5. Put an 8x1 ver to the right and to the back.
6. Put an 8x1 ver to the back.
7. Put a 1x1 to the left.
8. Skip two buttons to the left and put a 2x1 hor on.
9. Skip four buttons to the left and put a 2x1 hor on (on the right end of the left side of the back wall.)

Number 29

1. Stack two frames, install the panes, repeat to make three such part and intall in the front wall to make a bay window, on top of the movable part, at an angle to each other.
2. Put a 2x1 hor to the left, its left button on the arch bit.
3. Skip four buttons to the left and put a 1x1 on topf of the left arch bit.
4. Put an 8x1 ver to the left and to the back.
5. Put an 8x1 ver to the back.
6. Put a 1x1 to the right.

Number 30

1. Make three doors. Put one hor in the back, opening to the back and to the right. Put one hor in the front, opening to the front and to the left. Put another vet to the front of the back wall, to the left of the back door, opening to the right and to the front.

Number 31.

1. Make a part. Put a F 4x2 hor on the table. Put a F 2x1 hor to the left of its back row. Repeat symm on the right. Connect by putting a F 8x1 hor on top of the back row. Install the eay it is on the left end of the front wall, overhanging to the front over the door.
2. Stack two F 2x1 and put them hor on top of the right end of the front wall.
3. Put an 8x1 ver to the back, on the right wall.
4. Put a 6x1 ver to the back.
5. Put an 8x1 to the back and to the left.
6. Put a 1x1 to the left.
7. Put a three-button corner piece to the left and to the front, letter F.
8. Put a 2x1 ver to the front, over the door.

Lego pet shop book 1 second floor

Number 1 - 3

1. Put a F 12x2 hor on the table.
2. Put a F 2x1 hor to the left, next to the back row.
3. Put a F three-button corner piee to the left and to the front, letter F.
4. Connect by putting a F 8x1 hor on top, starting from the left.
5. Put a F 8x1 hor to the right.
6. Put a F 12x6 hor to the front of the PP.
7. Put a F 6x1 ver to the front of the leftmost button of the back edge.

Number 4.

1. Flip over so that the gap is on the right back. put a F 18x8 hor to the front of the other large piece.
2. Connect by putting a F 12x1 ver on the left edge.
3. Put a F 12x2 ver on the left edge of the two large pieces.
4. Put a F 12x1 ver on the right edge.

Number 5

1. Put a F 8x1 hor on the left end of the front edge.
2. Put a F 8x2 hor to the right.

Number 6.

1. Flip over so that the gap is at the left back.
2. Make a movable part as on the first floor. Install on the front, starting from the right.
3. Put a F 4x2 hor to the left, overhanging to the front.
4. Put a F 2x1 hor to the left.

Number 7.

1. Skip two buttons to the right and put a FS 1x1 on the front edge, on the third button from the left.
2. Put a F 2x1 with one button ver to the back.
3. Put a F 2x1 with one button ver to the left and to the front, on the first and second rows.
4. Put a F 2x1 with one button ver to the right.
5. Put a FS 1x1 to the right, on the first row.
6. Put a F 2x1 with one button ver to the back.
7. Skip two buttons to the right and put a F 2x1 hor on the second row.
8. Put a F 4x2 ver to the right and to the front.
9. Put a F 2x1 hor to the right, on the first row.
10. Put two F 2x1 diagonally on the movable diagonals.

Number 8 - 9.

1. Put an 8x1 ver on the left wall starting at the front.
2. Put an 8x1 ver to the back.
  3. Put a 6x1 hor to the right.
  4. Put an 8x1 hor to the right.
  5. Put an 8x1 ver to the right and to the front.
  6. Put an 8x1 ver to the front.
  7. Put a 1x1 to the left.
  8. Put a FS 6x1 hor to the left and to the back, on the second row.
  9. Put a F 2x1 trapeze to the front, in the middle, wide side to the back.
10. Put a 1x1 to the left, on the first row. It might be a slide. If it is, the slide is to the back.
11. Repeat.
12. Skip four buttons to the left and put a 1x1 on.
13. Stack some flowers and put them to the right and to the front, on the protruding piece in front of the first row.
14. Put a F 4x1 ver to the right of the gap, skipping three buttons from the back wall.
15. Put a FS 3x1 ver on top, starting at the front.
16. Put a 1x1 button to the back.

Number 10.

1. Put two 1x1 corniced pieces side by side and connect by putting a FS 2x1 upright (as on the first floor.)
2. Repeat.
3. Put one such part on the left end of the front wall.
4. Put the other on the right end.
5. Put an 8x1 ver to the back.
6. Put a 6x1 ver to the back.
7. Put a 6x1 hor to the back and to the left.
8. Stack three F 4x1 and put hor to the left.
9. Put a 6x1 hor to the left.
10. Put a 6x1 ver to the front.
11. Put an 8x1 ver to the front.

Number 11.

1. Put a 1x1 on the left end of the front wall, skipping the leftmost button.
2. Put an 8x1 ver to the left and to the back.
3. Put a 3x1 ver to the back.
4. Put a 1x1 with the handle to the back, handle to the right.
5. Put a 4x1 ver to the back.
6. Put a 1x1 to the right.



7. Put a 1x1 on the right end of the back wall, skipping the rightmost button.
8. Put an 8x1 ver to the right and to the front.
9. Put an 8x1 ver to the front.
10. Put a 1x1 to the left.

Number 12

1. Make four stairs as on the first floor, using a F 4x1, a FS 3x1 and two buttons.
2. Install fan-like over the gap, starting on top of the vertical first step.
3. Put a F 4x1 from a sep bag ver on the left wall starting from the back.
4. Put a 1x1 button on its third button from the back.

Number 13.

1. Make the top step, as on the first floor. Put a DS 2x1 in the middle of a F rounded 4x1. Put a 1x1 button to the right.
2. Install on the top of the stairs, its left end to the front of the button on the left wall.
3. Make a couch (?). Put a F 2x1 hor on the table. Put a 1x1 cornice piece on its back, so that the cornice is upward and to the back, and put on its left button. Repeat on the right. Put a grate piece hor on top. Turn it so that the cornices are on the table facing back, and put on top of a shelf piece so that the smooth side is to the front. Lay the shelf on its back and install ver, grate side to the front (facing upward) on the 4<sup>th</sup> - 7<sup>th</sup> rows, 4<sup>th</sup> - 7<sup>th</sup> columns from the right.
4. Make a coffee table. Put a F 2x2 disk on top of a 2x2 cylinder and put a FS disk on top. Install to the left and to the front of the couch.

Number 14.

1. Put a 2x1 hor on the left end of the front wall.
2. Put an 8x1 ver to the back.
3. Put a 2x1 ver to the back.
4. Put a F 2x1 ver to the back.
5. Put a 2x1 ver to the back.
6. Put a 2x1 hor to the back and to the right.
7. Put a 2x1 hor on the right end of the back wall.
8. Put a 6x1 ver to the front.
9. Put an 8x1 ver to the front.
10. Put a 2x1 hor to the front and to the left.

Number 15.

1. Insert the panes into the window frames.
2. Put a narrow window in the left end of the back wall, to the right of the 2x1.
3. Repeat symm on the right.
4. Put a 1x1 to the right.
5. Put an 8x1 ver to the right and to the front.
6. Put a 1x1 to the front.
7. Put a 1x1 with the side button to the front, side button to the left,
8. Put a 6x1 ver to the front.
9. Put a 1x1 to the left.
10. Put a wide window in the middle of the back wall.

Number 16.

1. Stack three 2x1.
2. Repeat.
3. Put them hor to the left and to the right of the wide window.
4. Put a 1x1 to the left of the left window.
5. Put an 8x1 ver to the left and to the front.
6. Put an 8x1 ver to the front.
7. Put a 1x1 to the right.
8. Hang a FS 4x2 upright, diagonally, on the right wall, on the side button.

Number 17.

1. Make a painting roll. Insert a longer end of a small connector into a smooth tube. Put a 11x corner piece on the connector, so that the other side is next to the tube. Insert a wide end of a stick into this side. Give the roll to a person and stand him so that it would look like the FS upright piece on the wall is the first smudge of the new paint he is laying with his roll.

2. Make a part of the front wall. Put two 1x1 corniced pieces on a 2x1, side by side, cornices to the front.
3. Put a FS 2x1 upright on the side buttons.
4. Repeat steps 2-3 and put on top of your part.
5. Install the way it is skipping four button to the right from the end of the left side of the front wall (on top of a horizontal movable piece).

Number 18

1. Put an 8x1 ver on the front end of the right wall, skipping the first button.
2. Put a 6x1 ver to the back.
3. Put an 8x1 hor to the back and to the left.
4. Put a 3x1 hor to the left.
5. Make a part.
6. Stack two F 2x1, put a 1x1 button on the left, put a 1x1 with the handle on the right (handle to the front) and install hor to the left.
7. Put a 3x1 hor to the left.
8. Put a 6x1 ver to the front.
9. Put an 8x1 ver to the front.

Number 19.

1. Make a part. Stack a shorter shelf piece on a taller one, shelves to the right. put a 1x1 wedge on the back button, slide to the back. install the way it is on the front two rows, to the right of the left end of the front wall.
2. Make a symm left-oriented part and install it to the right, skipping two buttons (to the left of the 2x1 tall part of the wall).

Number 20

1. Make a part. Stack a rounded frame on a regular frame (with the pane in it). Install between the two parts from number 19.
2. Stack two frames with panes. Repeat to make three. Install to the right, two diagonally and one in between.

Number 21.

1. Make four more steps as before and install them.
2. Make two other two-cornices-upright-S-piece parts and put one on the right end of the front wall, and the other on the left end.
3. Put a 4x1 arch hor to the right.
4. Put a 2x1 hor to the right.

Number 22.

1. Put a F 2x1 hor on top of the PP.
2. Skip four buttons to the left and put a F 2x1 hor on.
3. put a F 2x1 hor on the right end of the front wall.
4. Put a 1x1 to the back, on the right wall.
5. Put a 6x1 ver to the back.
6. Put an 8x1 ver to the back.
7. Put a 6x1 hor to the left.
8. Put a 4x1 hor to the left.
9. Put a F rounded 5x1 ver to the left and to the front, on top pf the stairs.

Number 23.

1. Put a 3x1 hor to the left, on the back wall.
2. Put an 8x1 ver to the front.
3. Put a 6x1 ver to the front.
4. Put a 1x1 to the front.
5. Put a F 2x1 hor to the front and to the right.
6. Put four F 2x1 with one button ver, side by long side, to the right.
7. Put two movable parts to the right, on top of the bay window.
8. Put a F 1x1 to the right.
9. Put a F 1x1 with the clasp to the right, clasp to the front.

Number 24.

1. Put a movable part on top of the PP and to the left.

2. Put a movable part to the left.
  3. Put a F 8x1 hor to the left.
- Number 25 (all flat smooth).
1. Put a 3x1 ver on the front end of the left wall.
  2. Put a 6x1 ver to the back.
  3. Repeat.
  4. Put a 6x1 hor to the back and to the right.
  5. Put a two-button 4x1 hor to the right.
  6. Put a 6x1 hor to the right.
  7. Put a 6x1 ver to the front.
  8. Repeat.
  9. Put a 3x1 ver to the front.
  10. Put a 1x1 to the left.
  11. Put a 2x1 diagonally to the left.
  12. Put a 2x1 hor to the left.
  13. Put a 2x1 diagonally to the left.
  14. Put a two-button 4x1 hor to the left.
  15. Put a 4x1 hor to the left.

Lego Pet Shop Book 1. Third Floor  
Number 1.

1. Put a F 6x1 ver on the table.
2. Put a F 3x1 hor to the right of its back button.
3. Connect by putting an 8x1 hor on top, starting from the left, overhanging to the right.

Number 2

1. Put F 12x6 hor to the right and to the front, so that the four leftmost buttons on its last row are under the 8x1.
2. Put a F 16x6 hor to the front and to the left, aligned at the sides.

Number 3.

1. Put an 8x1 ver on the back end of the left edge.
2. Put a 6x1 ver to the front of the horizontal 8x1 on the back edge.
3. Put a 2x1 hor to the front and to the right of the PP.
4. Skip four columns to the right and put a 2x1 hor on.
5. Put a 2x1 ver to the right and to the front.
6. Put a F 16x6 hor to the front of the other 16x6.

Number 4

1. Connect by putting an 8x1 ver to the front of the vertical 2x1 on the right edge.
2. Put an 8x1 ver to the front of the vertical 8x1 on the left edge.
3. Put a F 2x1 ver on the 2<sup>nd</sup> and 3<sup>rd</sup> rows, skipping one column to the left from the right wall.
4. Put a FS 2x1 hor to the left and to the back, touching corners.
5. Put a FS 2x1 hor to the left.
6. Put a F 2x1 ver to the left and to the front, touching corners.

Number 5

1. Make a colonnade part. Put a F 3x1 hor on the table. Put an upright clasp in the middle, clasp vertically, something on the base to the back.
2. Put a 1x1 button to the left, and another to the right.
3. Put two faucet pieces on the buttons, sticks in the clasp.
4. Put a FS 3x1 on top.
5. Install the way it is to the right of the left wall, on the front edge of the gap.
6. Put a 2x1 curved piece ver to the left of the front end of the right wall.
7. Skip one column to the left and put 1x1 corner piece on the 3<sup>rd</sup> row, upright sides to the front and to the left.
8. Skip two columns to the left and put another corner on, upright sides to the right and to the front.
9. Skip one column to the left and put a 2x1 curved piece ver on the 2<sup>nd</sup> and 3<sup>rd</sup> rows.

Number 6

1. Put a FS 2x2 on top of a 2x2 and put it, skipping one column to the right from the left wall and two rows to the front from the colonnade.
2. Put four 4x1 with side buttons hor on the front edge.

Number 7

1. Stack two 2x2 and put a FS 2x2 on top of the first 2x2 (I have no idea how!)
2. Put a 1x1 button upright on the leftmost front side button.
3. Put a FS 2x1 upright to the right.
4. Put a 1x1 button to the right. continue the pattern to the end.

Number 8

1. Make a part. Put a 1x1 button on top of a 1x1. Put a FS 1x1 on top.
2. Repeat to make another such part.
3. Put one part in the left back corner of the platform.
4. Put a 2x1 handle ver to the front, handle to the right.
5. Repeat.
6. Repeat.
7. Put a 2x1 handle to the left of the same part in the corner, hor, handle to the back.
8. Put another handle to the left the same way.
9. Repeat.
10. Put the other part to the left.

Number 9

1. Make a part. Put 1x1 flowers and 1x1 buttons on top of a F 4x2 piece. put two 2x2 discs underneath, side by side. Install this part hor in the left back corner.
2. Make a part. Put 1x1 flowers and 1x1 buttons on top of a F 4x1. Put two twig pircrs on top of the flowers. Install ver to the front of the rightmost button of the PP.

Number 10

1. Go to the left wall, to the back. skipping one button to the front, put a 6x1 ver on.
2. Put an 8x1 ver to the front.
3. Go to the vertical partition in the back. skipping the back button, put a 1x1 on it.
4. Put a 6x1 ver to the front.
5. Put a 1x1 to the right.
6. Skipping four buttons to the right, put a 3x1 hor on the horizontal partition.
7. Put a 6x1 ver to the front, on the right wall.
8. Put a 1x1 to the front.
9. Make a part. Insert a connector of a 2x1 piece with the connector into a hinge of a 2x1 with the hinge.
10. Repeat to make another such part.
11. Install one such part, bent at 90 degrees, the hinge to the right and to the back, at the front right corner, to the left of vertical curved 2x1 piece, vertically, and then to the left and to the back horizontally.
12. Repeat symm to the left.

Number 11

1. Go to the back of the left wall. Skipping the back button, put an 8x1 ver to the front.
2. Put a 6x1 ver to the front.
3. Go to the vertical partition. Put a 6x1 ver skipping one button from the back.
4. Put a 2x1 hor to the front and to the right.
5. Skipping four buttons to the right, put 2x1 hor to the right.
6. Put an 8x1 ver to the right and to the front.
7. Put a F 3x2 ver to the front and to the left.
8. Put a F 6x1 hor to the left, on the front.
9. Put a F 8x2 hor to the left.
10. Put a F 8x1 hor to the back.

Number 12

1. Put a 6x1 ver on the back end of the left wall.
2. Put an 8x1 ver to the front.
3. Put a 2x1 ver to the back end of the vertical partition.
4. Put a 1x1 to the front.
5. Repeat.

6. Put a 3x1 ver to the front.
7. Make a part. Insert a narrow end of a cone into the handle of a 1x1 handle piece. put a 1x1 button upside down onto the cone. Install this part to the right of the PP, handle to the back.
8. Put a 1x1 on the front end of the right wall.
9. Put a 6x1 ver to the back.
10. Put a 3x1 hor to the back and to the left.

Number 13

1. Insert the panes into the window frames.
2. Put two tall windows, hor, side by side, on the 4th row, skipping four columns from the right.
3. Put a shorter window, hor, on the 3<sup>rd</sup> row, skipping three columns from the left, on top of the two F 2x1 pieces with one button.
4. Make a part. Stack two curved 2x1 pieces.
5. Repeat to make two such parts.
6. Put one ver to the right and to the front of the PP.
7. Put the other to the left and to the front.

Number 14

1. Put a tall 2x1 slide piece to the left of the PP, slide to the front.
2. Put a tall 2x1 slide piece to the right, skipping four buttons (to the right of the right curved pieces).
3. Put a tall 1x1 slide piece to the right, slide to the front.
4. Put a tall 1x1 slide piece to the right, skipping four buttons (the windows), slide to the front.
5. Put a tall 2x1 slide piece to the right, slide to the front.
6. Make a part. Put a F 8x2 hor on the table. Put four tall 2x1 slide pieces on it, side by side, slides to the back. put a F 8x1 hor on top. Put two F 4x1 hor on top, side by side.
7. Install the way it is on the back wall, starting at the left end.

Number 15

1. Put a 6x1 ver on the front end of the left wall.
2. Put an 8x1 ver to the back.
3. Put a 2x1 ver on the back end of the partition wall.
4. Put a 1x1 to the front.
5. Repeat.
6. Put a 2x1 ver to the front.
7. Put a 2x1 hor to the front and to the right.
8. Skipping four buttons to the right, put a 2x1 hor on the horizontal partition wall.
9. Put an 8x1 ver to the right and to the front.
10. Put a 1x1 to the right of the leftmost tall 2x1 slide piece on the front wall (on the back button of the curved piece).
11. Put a F 2x1 with one button ver to the right, on the window, overhanging to the front and to the back.
12. Repeat.

Number 16

1. Put a F 1x1 on the left end of the front wall.
2. Put a F 6x1 hor to the right.
3. Put a F movable 2x1/2x1 piece hor to the right and ver to the right and to the back, on the leftmost button of the window and overhanging to the back.
4. Put a F 1x1 to the right.
5. Repeat.
6. Put another movable piece symm to the right.
7. Put a F 1x1 to the right.
8. Put a 1x1 hammer piece to the front of the F 6x1 piece, on the left curved piece and on the 2x1 piece with one button, the button side to the right.
9. Repeat symm to the right.

Number 17

1. Put a F 4x1 hor on the left end of the front wall.
2. Put a F 4x1 hor to the right.
3. Put a F 6x1 hor to the right.
4. Put a F 2x1 hor to the right.

5. Put two FS 2x2 pieces to the back of the F 6x1 piece, on the windows.
6. Put a F 4x1 hor on the left end of the back wall.
7. Put a F 4x1 hor to the right.
8. Make a part. Put a F 2x1 piece with one button on top of a F 2x1. Put a 1x1 button on top. Install hor on top of the two hammer pieces on the left window.

Number 18

1. Put an 8x1 slide piece hor on the back wall, slide to the back.
2. Put a 6x1 ver to the front, on the left wall.
3. Repeat.
4. Put an 8x1 slide piece hor to the front, on the front wall, slide to the front.
5. Put a 2x1 slide piece hor on the right end of the front wall, slide to the front.
6. Put a 6x1 ver to the back, on the right wall.
7. Put a 3x1 hor to the back and to the left.
8. Skip four buttons to the left and put a 1x1 on.
9. Put a 6x1 ver to the left and to the back.

Number 19

1. Insert the door into the frame, install the 1x1 button as a handle and install hor in the horizontal partition gap, so that it opens to the back and to the left.
2. Put a 1x1 long slide piece on the front wall, to the right of the 8x1 slide piece, slide overhanging to the front.
3. Skip one button to the right and repeat.
4. Put another such piece to the right.
5. Skip one button and repeat.
6. Put two long slides from a sep bag in the gaps.

Number 20 (all FS)

1. Put a 6x1 ver on the back end of the left wall.
2. Put a 2x1 ver to the front.
3. Put a 4x1 with two buttons ver to the front.
4. Put a 2x1 ver to the front.
5. Put a 2x1 hor to the right.
6. Put a 6x1 hor to the right.
7. Repeat.
8. Put a 2x1 ver to the right and to the back.
9. Put a 4x1 with two buttons ver to the back.
10. Put a 2x1 ver to the back.
11. Put a 3x1 hor to the left.
12. Put a 2x1 hor to the left.
13. Put a 3x1 hor to the left.
14. Put a 6x1 ver to the back.
15. Put a 6x1 hor to the left.

Number 21

Install this floor on top of the main structure.

The roof.

Number 1.

1. Put a F 8x6 hor on the table. Put a FS 8x1 hor on the back edge.

Number 2

1. Put a F 16x8 hor to the front and to the right, aligned on the left.

Number 3

2. Put a FS 8x1 ver on the back end of the left edge, to the front of the horizontal 8x1.
3. Skip two buttons to the right and put a F 8x2 ver on.
4. Skip two buttons to the right and put FS 6x1 ver on.
5. Put a FS 8x1 hor to the right, on the back edge.
6. Put a FS 6x1 ver to the front, on the right edge.

Number 4

1. Put a F 1x1 to the front.
2. Put a 4x1 fence hor to the left.

3. Put a F 1x1 to the left.
4. Repeat steps 2-3.
5. Repeat.
6. Put a 1x1 slide piece to the back, slide to the front.
7. Put a 1x1 slide piece to the back, slide to the back.

Number 5

1. Make a part. Put a F 2x1 on top of a 2x1 curved piece. Put two cylinders on top, side by side. Install ver on top of the two PPs.
2. Put four cones, wider end down, on the front wall, on top of the F 1x1 pieces.

Number 6

1. Install the roof on top of your structure.

Hooray, end of Book 1!

## 10218 Pet Shop Book 2

### Bag 1. Number 1.

1. Put a flat 32x16 ver on the table.
2. Put a flat smooth 6x1 hor on its left front edge.
3. Put a flat smooth 4x1 hor to the right.
4. Put a flat smooth 6x1 hor to the right.

### Number 2.

1. Put a flat smooth 2x1 hor to the front, starting on the right edge.
2. Put a flat smooth 2x1 hor to the left.
3. Skipping two buttons to the left, put a FS (flat smooth) 2x1 hor to the left.
4. Put a grate hor to the left.
5. Put a FS 2x1 hor to the left.
6. Repeat.
7. Repeat.
8. Put a FS 2x2 to the front.
9. Put a FS 2x2 to the right.
10. Repeat.
11. Repeat.
12. Repeat.
13. Put a FS 2x1 hor to the right of the PP's back row.
14. Put a FS 2x2 to the right, so that there is a 2x2 gap.
15. Put a FS 2x2 to the right.
16. Put a FS 2x2 to the back.
17. Put a FS 2x2 to the left.
18. Repeat.

Keep an extra piece separately.

### Bag 2 Number 3

1. Put a FS4x1 hor to the back, starting on the left edge.
2. Put a FS 6x1 hor to the right.
3. Put a FS 2x1 ver to the back of the rightmost button of the PP.
4. Put a FS 1x1 to the left of the front button of the PP.
5. Skip one button to the left and put a FS 1x1.
6. Repeat.
7. Repeat.
8. Skip one button to the left and put a FS 2x1 ver to the left and to the back of the PP.
9. Put a FS 1x1 to the right of the back button of the PP.

10. Skip three buttons to the right and put a FS 1x1.
11. Skip one button to the right and put a FS 1x1.
12. Now open a separate bag and put four FS 1x1 pieces from it between the FS 1x1 pieces that are already there, EXCEPT the third button from the left on the back row (the seventh from the front edge).
13. Skip one column from the right edge and put a FS 2x1 ver to the back of the FS 2x2.
14. Put a FS 2x2 hor to the left of the front button of the PP.
15. Put a FS 2x1 from the previous bag hor to the bag.
16. Put a FS 2x1 ver to the left of the two PPs.

#### Bag 3 number 4

1. Skip one column from the left edge and put a F 2x1 with one button ver to the back of the FS 1x1.
2. Repeat seven times.
3. Put a FS 2x1 hor to the back of the two PPs.
4. Put a FS 2x1 hor to the left.
5. Put a F 4x1 hor to the left.
6. Make an outline of the shop. Put a FS 8x1 ver to the back of the leftmost button of the PP.
7. Put a F 4x1 hor to the back and to the right.
8. Put a FS 1x1 to the right.
9. Put a F 4x1 to the back.
10. Put a FS 8x1 to the right of the back button of the PP.
11. Put a F 1x1 to the right.
12. Put a FS 2x1 ver to the front.
13. Repeat.
14. Put a F 4x1 to the front and to the left.
15. Put a FS 1x1 to the left.
16. Put a F 4x1 to the front.
17. Put a FS 2x2 to the left and to the front of the front button of the PP.

#### Bag 4 number 5

Do not mix the pieces with the ones from the previous bag.

1. Put two FS 1x1 pieces to the left, ver.
2. Put a F 2x1 ver to the left.
3. Put a FS 2x2 from the previous bag to the left.
4. Use the rest of the FS 2x2 pieces from the previous bag to make a checkered board inside the shop outline.
5. Fill in the checkered spaces with the FS 2x2 pieces from this bag.

#### Bag 5 number 6.

1. Put a 2x1 ver on the right edge, on the 7<sup>th</sup> and 8<sup>th</sup> rows (to the right of the FS vertical 2x1 piece)
2. Put a 1x1 to the back.
3. Insert a connector into 2x1 and put it ver to the back, connector as usual.
4. Put a 4x1 ver to the back.
5. Repeat.
6. Put a connector into a 2x1 and put it ver to the back.
7. Put a 2x1 hor to the back and to the left.
8. Put a 4x1 hor to the left.
9. Put a 4x2 hpr to the left of the 1x1 piece and of the front connector piece.
10. Put a corner piece to the left, in the shape of Braille H.
11. Put a corner piece to the front, in the shape of the Braille F.
12. Put a 4x1 ver to the back, starting in the inside corner of the H.
13. Put a 1x1 to the back, on top of the F vertical 4x1 piece.
14. Skip two buttons to the back and put a cut-off corner piece to the back and to the right, in the shape of the Braille I ,cut-off corner to the left and to the back, partially on top of the two F 4x1 pieces and a FS 1x1 piece.
15. Skip two buttons to the right and put a 1x1 on top of the horizontal F 4x1 piece.

#### Number 7

1. Put a 2x1 ver on the left edge, to the left of the leftmost F 2x1 piece with one button.
2. Put a 2x1 with the hole ver to the back.





5. Put a joystick piece on the roll from the front.
6. Put a hammer piece on the left front button, button to the back.
7. Put a wedge piece on top of the button, tall side to the front.
8. Put a FS 2x1 ver to the right.
9. Repeat.
10. Install the register ver, joystick to the back and to the left, in the middle of the store, on top of the two vertical buttons on the floor (these two buttons under the two right front buttons of the register).
11. Put four FS 4x1 pieces on tops of the bracket pieces and adjacent pieces to connect them.

Bag 8 number 13

1. Put a 2x1 ver on the front end of the left wall.
2. Put a 4x1 ver to the back.
3. Repeat.
4. Put a 6x1 ver to the back.
5. Put a 6x1 hor to the back and to the right.
6. Skip four buttons and put a 6x1 hor to the right (in the right side of the back wall).
7. Put a 6x1 ver to the front.
8. Repeat.
9. Put a 4x1 ver to the front.
10. Put a 4x2 hor to the left, on top of the second row of the other 4x2, to make steps.
11. Put a 6x1 ver to the left, on top of the other 6x1.
12. Put a 3x1 ver to the left, on top of the other 3x1.
13. Put a candlestick piece, wide ring to the bottom, on the F horizontal 4x1 piece on the right from the left wall, on its leftmost button.
14. Skip one button to the right and put another candlestick.
15. Put a 3x1 arch hor on the candlestick.
16. Put two parrots on the arch.

Bag 9 number 14

1. Make a fish tank. Put a 4x2 hor on the table. Put a 1x1 button on the second button from the left, on the back row.
2. Put another 1x1 button on top.
3. Put a cone on top.
4. Put a 1x1 button from a separate bag to the right.
5. Put a F 1x1 clasp on top.
6. Put another button from a separate bag on top.
7. Insert a fish in the clasp.
8. Put a 4x2 bracket (it's transparent) on the free buttons of the 4x2.
9. Cover with a S curved 4x2 piece, thinner side to the front.
10. Install hor inside the front back corner.
11. Put a 1x1 on the front end of the right wall (on top of the wall, skipping the first flat button. Keep doing it by default it is said specifically to use the first button).
12. Put a 6x1 ver to the back.
13. Repeat.
14. Put a 4x1 ver to the back.
15. Put a 4x1 hor to the left.
16. Put a 1x1 to the left.
17. Put a 4x1 from a separate bag hor on top of the 4x2, on its back row, to make another step.
18. Put a 2x1 with the groove ver to the left and to the back, on the back two buttons of the vertical 6x1 piece, groove to the right.
19. Put a 1x1 to the front.

Number 15

1. Make a postbox. Put the door in, put a FS 2x1 letter inside, and install to the front and to the left of the PP, door to the right.
2. Put a 1x1 wedge on the left back corner of the postbox, thinner side to the left.
3. Put a 1x1 to the front, on the right.
4. Put a 1x1 from a separate bag to the left.

5. Put a 2x1 ver on the front end of the left wall.
6. Put a 1x1 to the back.
7. Put a 6x1 ver to the beack.
8. Put a 4x1 ver to the back.
9. Repeat.
10. Put a 4x1 hor to the right.
11. Put a 1x1 to the right.

Bag 10 number 16

1. Put a 4x1 ver on the front end of the left wall.
2. Put a F 6x1 ver to the back.
3. Put a 6x1 ver to the back.
4. Put a 6x1 hor to the back and to the right.
5. Skip four buttons (the gap) to the right and put a 6x1 hor on the right side of the back wall.
6. Put a 6x1 ver to the front, on the right wall.
7. Put a 4x1 ver to the front.
8. Skip one button to the front and put a 1x1.
9. Put a 4x1 ver to the front.

Number 17

1. Make a shelf with the pet toys. Put a F 6x2 hor on the table.
2. Put a F 6x1 hor on top of its front row.
3. Put three F 2x1 corniced pieces on its back row.
4. Stack two 1x1 buttons, put a wedge on top and put it on the rightmost back button.
5. Put a 1x1 with the side button to the left, side button to the back.
6. Put a wedge on top.
7. Stack two buttons and put them to the left.
8. Put a cone to the left.
9. Put a frog to the left, skipping one button.
10. Put a F 6x1 hor on the front row.
11. Install ver on the left wall, on top of the F 6x1, toys to the right.

Bag 11 number 18

1. Make the stair piece. Put a F 4x1 hor on the table. Put a F 2x1 hor on top, in the middle.
2. Put 1x1 with the hole to the right.
3. Insert a connector from the right.
4. Put a 1x1 with the hole from a separate bag to the right, inserting the right end of the connector into it.
5. Repeat steps 2-4 symm on the left.
6. Put the bottom 2x1 part of the stairs into your part, the stairs climbing to the back.
7. Put a F 2x1 hor on the top 2x1 part of the stairs.
8. Install the stairs, the way they are, on top of the other steps, putting the left and the right ends on the bottom into the gap in the right wall and to the back of the postbox (skipping two buttons).

Number 19.

1. Swing the top part of the stairs forward.
2. Put a 2x1 ver on the front end of the left wall.
3. Put a 1x1 to the back.
4. Put a 6x1 ver to the back.
5. Put a 4x1 ver to the back.
6. Repeat.
7. Put a 4x1 hor to the right.
8. Put a 1x1 to the right.
9. Skipping the 4x1 gap, put a 1x1 to the right on the right side of the back wall.
10. Put a 4x1 hor to the right.
11. Put a 4x1 ver to the right and to the front.
12. Put a 6x1 ver to the front.
13. Repeat.
14. Put a 1x1 to the front.

15. Skipping four buttons to the left, put a 6x1 ver on the postbox wall.
16. Put a 2x1 ver to the left of its two front buttons.

Bag 12 number 20

1. Make a door. Put a four-holes door into the door frame, put the 1x1 button for the knob and install it into the gap in the back wall, opening to the back and to the right (when the door is closed, the knob should be facing front and on the left).

Number 21

2. Make a glass door, put the knob in and install in the middle of the front wall, to the left of the postbox wall, knob to the front and on the right.
3. Put a glass pane into a frame and put this part to the left of the PP.

Number 22

1. Put a F 8x1 on top of the two PPs.
2. Put a 2x1 ver to the right.
3. Put a 6x1 ver to the right.
4. Put a 2x1 ver on the front end of the left wall.
5. Put a 4x1 ver to the back.
6. Repeat.
7. Put a 6x1 ver to the back.
8. Put a 4x1 slide hor to the back and to the right, slide to the back.
9. Put an 8x1 slide hor to the right, slide to the back.
10. Put a 4x1 slide hor to the right, slide to the back.
11. Put a 6x1 ver to the front, on the right wall.
12. Repeat.
13. Put a 4x1 ver to the front.

Number 23

1. Put a 1x1 button on the rightmost button of the F 8x1 piece over the front door and window.
2. Put two grate pieces hor upright on a 2x1/4x1 corner piece, on the 4x1 upright side, and install this part over the front wall, grates to the front and upright, to the left of the 1x1 button.
3. Put a 1x1 button to the left.
4. Make a striped awning. Put a hammer piece to the left, slide to the front. Put a hammer piece from a separate bag to the left.
5. Put a hammer to the left.
6. Put a hammer from a separate bag to the left.
7. Put two tall columns to the front of and at the sides of the stairs, on the buttons in front of the right wall and of the postbox wall.

Bag 13 number 24

1. Put a 6x1 ver to the back of the left column.
2. Put a 2x1 ver to the left.
3. Put a 1x1 on the left wall, skipping two buttons to the back from the front.
4. Put a 6x1 ver to the back.
5. Repeat.
6. Put an 8x1 slide hor to the back and to the right, as before.
7. Put an 8x1 slide hor to the right.
8. Put a 4x1 ver to the front.
9. Repeat.
10. Put a 6x1 ver to the front.
11. Put a 1x1 to the front.

Number 25

1. Put a F 2x1 ver on the front end of the left wall.
2. Put four F 2x1 pieces with one button hor on top of the front door and window.
3. Put a F 2x1 ver to the right.
4. Put a 2x1 with the groove ver to the right (to the back of the left column), groove to the left.

Bag 14 number 26

1. Make a light part. Insert the long end of a long connector into a 2x2 piece with the hole.
2. Put a cone in the middle of the 2x2 piece, between the buttons.
3. Put a globe over it (it's transparent).

4. Insert a ribbed side of a connector into the long connector.
5. Turn the part upside down and insert the connector into the hole of a 2x1 piece with the hole.
6. Turn it so that the 2x1 piece is on the left (and it is still upside down), install this part over the stairs, the 2x1 piece ver on the postbox wall, to the back of the left column.
7. Make an over-the-door part. Put a F 10x2 piece hor on the table. Put a F 2x1 with the cornice on the left end, on the front row.
8. Put a F 8x1 cornice piece hor to the right.
9. Put a F 1x1 on the leftmost button of the back row.
10. Skip four buttons to the right and put a F 1x1.
11. Put a FS 4x1 hor on the front row, skipping the leftmost button.
12. Skip one button to the right and put a FS 4x1 hor.
13. Install this part, the way it ism over the front door and window.

Number 27

1. Stack two F 2x1 pieces and put them ver on top of the PP, in the middle, between the two FS pieces.
2. Put a 2x1 ver on the front end of the left wall, to the left of the FS piece.
3. Put a 4x1 ver to the back.
4. Repeat.
5. Put a 6x1 ver to the back.
6. Put a 4x1 hor to the right.
7. Put a 6x1 hor to the right.
8. Put a 4x1 hor to the right.
9. Put a 6x1 ver to the right and to the front.
10. Put a 6x1 ver to the front.
11. Put a 4x1 ver to the front.
12. Put a 6x1 arch hor to the front and to the left, over the columns.

Bag 15 number 28

1. Put a 1x1 on the front end of the left wall, skipping two buttons to the back.
2. Put a 6x1 ver to the back.
3. Repeat.
4. Put a 6x1 hor to the back and to the right.
5. Put a 4x1 hor to the right.
6. Put a 6x1 hor to the right.
7. Put a 4x1 ver to the front.
8. Repeat.
9. Put a 6x1 ver to the front.
10. Make a hanger for the "Pets" sign. Put a 1x1 with the two side buttons on top of a F 1x1 piece. put two sticks into the two side buttons. Put the other ends of the sticks into the side buttons of two 1x1 pieces with one side button. Install this part over the front door and window, on the second row (put the left 1x1 piece on the front end of the left wall, skipping one button to the back, put the middle 1x1 piece on the back button of the F vertical 2x1 piece, and put the right 1x1 piece on the back button of the 2x1 vertical part of the light).

Bag 16 Number 29.

1. Make a part. Take a FS 2x1 from a separate bag, turn it upright, tall side up, and hang it on a 1x1 piece with the side button so that it hangs down. Put this part on the front end of the left wall, FS piece to the right.
2. Make a part. Put a F 1x1 on a 1x1 button with the side button, hang a FS 2x1 piece on them so that it hangs down and put this part on the button in the middle (between two FS 4x1 horizontal pieces), FS side to the left.
3. Make a part. Put a F 6x1 hor on the table. Put 1x1 shoe piece ver on the right edge, toe to the front. Put another shoe to the left. Put a F 2x1 with one button hor to the left, on the first row. Put another shoe to the left. Repeat. Put a F 6x1 hor on the back row. Put a frog on the front row in the middle. Install this part hor over the arch on the front wall.

Bag 17 number 30

1. Make a part (of the sign). Sandwich a F 1x1 between two F 1x1 pieces from a separate bag. Put a 1x1 piece with the upright clasp on top. Put a FS 1x1 on top. Install this piece, clasp to the

back, to the left of the middle part between the two sticks.

2. Make another part (of the sign). Put a F 1x1 with the flat clasp on the table, clasp to the back. Put a F 1x1 piece from a separate bag to the right. Connect with a FS 2x1. Stand it upright, tall, smooth side to the right, and install on the right end of the right stick.

#### Bag 18 number 31

1. Make another part (of a sign) by repeating step 1 of bag 17. Install to the left of the previous part.
2. Make another part (of the sign). Put a F 1x1 with the flat clasp on the table, clasp to the back. put a F 1x1 to the left. Connect with a FS 1x2. Stand it upright, tall, smooth side to the left, and install to the left of the previous part.

#### Bag 19 number 32

1. Make another part (of a sign). Put a 1x1 with the side button on the table, side button to the left. Put a F 1x1 with the upright clasp on top, clasp to the back. Put a FS 2x1 upright, tall, on the side button. Put a FS 1x1 on top. Install to the left of the previous part.
2. Make the last part of the sign. Stack up two F 1x1 pieces from a separate bag, put a F 1x1 on top, put a F 1x1 with the upright clasp on top, put a FS 1x1 on top. Install on the left, in the available spot.
3. Put a F 4x1 from a sep. bag ver to the left of the previous part, on the front end of the left wall.
4. Put a F 10x2 hor to the right, over the sign.
5. Put a F 6x1 ver to the back of the 4x1 piece, on the left wall.
6. Put a F 6x1 ver to the back.
7. Put a F 6x1 hor to the right, on the back wall.
8. Put a F 2x1 with the cornice hor to the right, cornice to the back.
9. Put a F 6x1 hor to the right.
10. Put a F 3x1 ver to the right and to the front.
11. Put a grate/2x1 piece ver to the front, grate upright hanging to the left.
12. Put a F 3x1 ver to the front.
13. Put a F 8x1 ver to the front.

#### Bag 20 number 34

1. Put two F 8x1 pieces with the cornices hor on the front wall, cornices to the front.
2. Put a FS 1x1 to the back, on the front end of the left wall.
3. Put a FS 6x1 ver to the back.
4. Repeat.
5. Repeat steps 2-4 on the right wall.
6. Put a FS 6x1 hor on both ends of the back wall.
7. Put a F 4x1 with two buttons hor in between.
8. Put a FS 6x1 hor on the top row of the stairs, on top of the 2x1.
9. Make a display stand. Insert a 2x2 with the handle into the pew pieces and install in front of the front window, on the two buttons in the platform, turning the 2x2 piece so that it faces front and up.

#### Bag 20 number 35.

1. Make a lantern and install it in front.
2. Make a part. Put a FS 4x2 hor on the table. Put a FS 1x1 from a sep. bag on the back row, on the second button from the right. Put a large corner piece from the right, so that they make a square on the base. Put four small corner piece on the left so that they make a box. Put a ball in the box. Put two bones on the right side. Install on the display stand.

#### Large bag 4

##### Bag 1. Number 1

1. Put a F 16x2 ver on the table.
2. Put a F 8x6 hor, its leftmost column on top of the first six buttons on the right.
3. Put a F 8x4 hor, its leftmost column on top of the back four buttons on the right side.

##### Number 2.

1. Put a F 16x8 ver, its rightmost column on top of the left side of the 16x2.

##### Number 3.

1. Flip over and rotate, so that the F 16x8 piece is ver and on the right.
2. Put a F 6x1 hor on the front edge, on the right, to the right of the 16x2 piece.
3. Put a F 8x1 ver to the right and to the back, on the right edge.

4. Put a F 8x1 ver to the back.
5. Put a F 6x1 hor to the left, on the back edge.
6. Skip the 16x2 and put a F 6x1 hor to the left, on the back edge.
7. Skip 1.5 rows to the front and put a F 6x2 hor on the edge, so that it half overhangs the edge.
8. Put a F 6x2 hor , skipping the gap, so that it overhangs to the back.
9. Put two F 8x1 ver on the left edge.

#### Bag 1A

##### Number 4

1. Flip and rotate, so that the gap is ho and on the right.
2. Put a F 6x1 ver on the right edge, on the right edge of the gap.
3. Put a F 4x1 hor to the left of its last button, on the back edge of the gap.
4. Put a F 6x1 ver to the left and to the front, on the left edge of the gap.
5. Put a F 6x2 ver to the left.

##### Number 5

1. Go to the front end of the right edge. Skipping two buttons to the back, put a F 6x1 ver on the edge.
2. Put a F 6x1 ver to the back.
3. Put a F 3-button corner piece to the back and to the left.
4. Put a F 6x1 hor to the left.
5. Repeat steps 1-4 symm on the left.
6. Put a bench piece ver on the second column from the left, on the 6<sup>th</sup> and 7<sup>th</sup> rows, the upright side to the right.

#### Bag 1a

##### Number 6

1. Put a F three-button corner piece on the left front edge, letter H.
2. Put a F one-button 2x1 ver to the right.
3. Repeat.
4. Put a F 2x1 hor to the right, on the edge.
5. Put a F one-button 2x1 ver to the right.
6. Repeat.
7. Repeat.
8. Repeat.
9. Put a F 2x1 hor to the right, on the edge.
10. Put a F one-button 2x1 ver to the right.
11. Repeat.
12. Put a F three-utton corner piece to the right, letter J.
13. Insert a flame into the side button of a 1x1 piece with the side button. Put it, flame to the back, to the front of the bench piece on the left side.
14. Put a 1x1 with the side button to the back of the bench piece, side button to the front.

#### Bag 2

##### Number 7

1. Put a 1x1 on the second row of the left wall (on the first dot of the H letter).
2. Put a 4x1 ver to the back.
3. Repeat.
4. Put a 6x1 ver to the back.
5. Put a 2x1 with the groove hor to the right, groove to the front.
6. Repeat steps 1-5 symm on the right.
7. Put two cylinders on top of the 1x1 pieces with the side buttons, on the fireplace.

##### Number 8.

1. Put a 4x1 ver on the front end of the left wall (skipping the first row).
2. Put a 6x1 ver to the back.
3. Put a 4x1 ver to the back.
4. Put a 2x1with the groove hor to the back and to the right, groove to the front.
5. Put a 1x1 to the right.

6. Repeat steps 1-5 symm on the right.

Number 9

1. Put a 1x1 on the front end of the left wall (skipping the first row).
2. Put a 4x1 ver to the back.
3. Repeat.
4. Put a 6x1 ver to the back.
5. Put a grooved 2x1 hor to the right, groove to the front.
6. Repeat steps 1-5 symm on the right.

Bag 3 number 10.

1. Make a coffee machine part. Stack two 2x1 pieces. Put a F 2x1 on top. Put a pot on the front button. Put a 1x1 on the back button. Put a 1x1 button on top. Put a F 2x1 on top. Put a FS 2x1 on top. Install hor in the left back corner.
2. Put a 4x1 ver on top of the two cylinders, on the fireplace.

Number 11

1. Make a sink piece. Put a 1x1 piece from a sep bag in the left front corner of a F 2x2 piece. Put three S small corner pieces on to make a sink. Put a faucet on the 1x1 piece. Put a cylinder underneath the part, in the middle. Install, the way it is, to the front of the coffee machine.
2. Put two F corniced 2x1 pieces ver, side by side, on top of the fireplace.

Number 12.

1. Make a stove part. Put a stove box on the F 2x2 piece from a sep bag. Insert the door so that it opens downwards. Put four 1x1 buttons on top. Put a frying pan on. Install to the front of the sink, door to the right.
2. Put two 1x1 slide pieces ver on top of the fireplace, slides away from each other.

Number 13.

1. Stack two curved 2x1 pieces and put them ver on top of the fireplace.
2. Put a 4x1 ver on the front end of the left wall (skipping the first row).
3. Put a 6x1 ver to the back.
4. Put a 4x1 ver to the back.
5. Put a grooved 2x1 hor to the back and to the left, groove to the front.
6. Repeat steps 2-5 symm on the right.

Bag 4.

Put a 1x1 piece to the right of the grooved piece on the back left wall, and to the left of the back right wall.

Number 14

1. Put a 1x1 on the front end of the left wall (skipping the front row).
2. Put a 4x1 ver to the back.
3. Repeat.
4. Put a 6x1 ver to the back.
5. Put a grooved 2x1 hor to the right.
6. Repeat steps 1-5 symm on the right.
7. Install the door in the frame, put a button handle in and install hor on the back edge of the gap, the door opening to the back and to the right.

Number 15.

Make a part - a diagonally cut piece of the wall.

1. Put an 8x1 ver on the table.
2. Put a 2x1 ver on the last two buttons.
3. Put a 2x1 lip piece ver to the front, the lip overhanging to the left (the two buttons ver).
4. Put a 2x1 ver to the front.
5. Put a 1x1 slide piece ver to the front, slide to the front.
6. Put a 3x1 ver on top of the last three buttons.
7. Put a 2x1 ver to the front.
8. Put a 1x1 slide ver to the front, slide to the front.
9. Put a 2x1 ver on top of the last two buttons.
10. Put a 2x1 ver to the front.
11. Put a 1x1 slide ver to the front, slide to the front.
12. Put a F 2x2 piece with one button on top of the lip piece, to the left of the part.
13. Put a 3x1 ver on top of the last three buttons.



14. Put a slide to the front as before.
15. Put a 2x1 ver on top of the last two pieces.
16. Put a slide piece as before.
17. Install this part ber, slides to the front, on the left edge of the gap, to the left and to the front of the door.

Bag 5 number 16

1. Put a F 1x1 on the rightmost button of the door.
2. Skip two buttons to the left and put a F 2x1 hor to the left.
3. Put a F 2x1 ver to the front, on the diagonal wall.
4. Put a 4x1 ver on the front end of the left wall (skipping the first row).
5. Put a 6x1 ver to the back.
6. Put a 4x1 ver to the back.
7. Put a 2x1 hor to the back and to the right.
8. Put a 1x1 to the right.
9. Repeat steps 4-8 symm on the right.

Number 17.

1. Make a stairs part. Put a F 2x2 underneath a F 4x2 piece, in the middle. Put a stair piece on top, climbing backwards, on the two middle buttons of the back row. Install in front of the wall, the top back two buttons on top of the door.
2. Make a chair part. Put a bench piece and a FS 2x1 piece on top of a F 2x2 piece from a sep bag. Put a cylinder underneath, in the middle. Install to the left of the diagonal wall, to the front of the little table. Put a cup on the table.

Bag 6 number 18.

1. Make five stacks of six grooved pieces each.
2. Install four, hor, grooves to the front, on the front edge, on the four F 2x1 horizontal pieces.
3. Install one, hor, gtooves to the front, on the back wall, in the middle (I think skipping four buttons from the right).

Bag 7 number 19.

1. Make a wide window part. Put a F 4x1 hor on the table. Put two F corniced pieces side by side on top, cornices to the front. Put a 4x1 frame on top and install the windowpane from the left upper corners. Install two windowpanes into the two smaller frames and put them side by side on top. Put two cornices pieces on top as before.
2. Repeat to make another window.
3. Install them in the back wall, cornices to the back.

Number 20.

1. Make a narrow window part. Put a 2x1 hor on top of a F 2x2, on the back row. Put a F 2x1 hor to the front.
2. Stack two small frames and put them on top a the 2x1 in the back.
3. Install the windowpanes.
4. Put a F 2x1 with one button hor on top.
5. Put a F 2x2 on top, in the middle (the button underneath should be between the circles).
6. Put some flowers in front.
7. Repeat steps 1-6 to make another window.
8. Install hor at the left and right sides of the front wall, flowers to the front, of course.

Number 21.

1. Make a central window. Put a F 4x2 hor on the table.
2. Put two 2x1 hor side by side on the back row.
3. Stack two small frames. Repeat. Put them side by side on the two 2x1 pieces.
4. Install the windowpanes.
5. Put two F 2x1 pieces with one button hor on top, side by side.
6. Put a F 4x2 hor on top.
7. Put two F 2x1 hor to the front, on the front row.
8. Put some flowers on.
9. Install in the middle of the front wall.

Bag 8 number 22.

1. Mount a disk (clock) on the upright side of a 2x1/2x2 piece. put ver on the first two buttons of the

- diagonal wall, clock hanging down on the left.
2. Put a F 4x1 ver on the front end of the left wall.
  3. Put a F three-button corner piece to the back and to the right, letter F.
  4. Put a F three-button corner piece to the back, letter H.
  5. Put a F 6x1 ver to the back.
  6. Put a F three-button corner piece to the back and to the right, letter F.
  7. Put a F 6x1 hor to the right.
  8. Repeat.
  9. Put a F three-button corner piece to the right and to the front. Letter D.
  10. Put a F 2x1 ver to the front.
  11. Put a F three-button corner piece to the front and to the left, letter D.
  12. Put a F 4x1 hor to the left.
  13. Put a F 4x1 ver to the front of the previous corner piece, on the right wall.
  14. Put a F 6x1 ver to the front.
  15. Put a F 4x2 hor to the left.
  16. Put a F 10x2 hor to the left.

Number 23.

1. Put two F 8x1 corniced pieces hor on the front wall, side by side, cornices to the front.
2. Put a FS 1x1 to the back of the left PP, on the left wall.
3. Put a FS 6x1 ver to the back.
4. Repeat.
5. Put a FS 6x1 hor to the back and to the right.
6. Put a F 4x1 piece with two buttons hor to the right.
7. Repeat steps 2-5 symm on the right. Put aside.

Bag 10

Number 24, the roof, is subdivided into units.

Unit 1.

1. Put a F 10x2 hor on the table.
2. Put a F 6x1 hor on the front row, on the left.
3. Put a F 4x1 hor to the right.

Unit 2

1. Put a F 16x6 hor on the table, its first row on top of the back row of the PP, starting from the second column from the left.
2. Put a F 8x1 ver under the left edge of the 16x6, so that the two front buttons of the 8x1 protrude to the front.
3. Repeat on the right.

Unit 3.

1. Make a part. Put a F 6x1 from a sep bag ver on the table.
2. Put a F three-button corner piece next to it, to the back and to the right and to the front, letter F.
3. Put a F 1x1 to the back, to continue the 6x1 line.
4. Connect the three pieces by putting a F 6x1 ver on top, skipping the first four buttons of the first 6x1.
5. Install this part, the way it is, on the front end of the left edge, putting the last buttons of it on top of the protruding two buttons.
6. Put a F 6x1 ver on the front end of the right edge, on the protruding two buttons.
7. Put a F 8x1 ver underneath the PP, so that its first four buttons protrude to the front.

Unit 4.

1. Put a F 8x4 hor in front, its rightmost column on top of the four protruding buttons of the PP.
2. Repeat symm on the left. The two pieces should touch in the middle.

Unit 5.

1. Flip over so that it's still horizontal and the recess in the gap is on the left and on the back.
2. Put a F 4x1 hor on the back edge of the gap, on the left end (at the edge of the recess).
3. Put a F 8x1 hor on the left end of the front edge.
4. Put a F 6x1 from a sep bag hor to the right.
5. Repeat steps 3-4 at the back edge.
6. Repeat at the front edge of the gap.

Unit 6.

1. Flip over so that it's still horizontal and the recess in the gap is on the right and on the back.
2. Put a FS 2x1 hor on the front edge, skipping two columns from the left.
3. Skip three columns to the right from the PP and put a FS 2x1 hor to the right.
4. Repeat.
5. Skipping two rows to the back from the left front end, put a 1x1 on.
6. Put a 6x1 ver to the back.
7. Repeat.
8. Put a 6x1 hor to the back and to the right.
9. Put a 4x1 hor to the right.
10. Put a 6x1 hor to the right.
11. Put a 6x1 ver to the front.
12. Repeat.
13. Put a 1x1 to the front.
14. Put a curved 2x1 ver on the left side, on the protruding 2x1 space on the left edge of the gap.
15. Skipping four columns to the right from the left wall, put a grooved 2x1 ver on the front edge of the gap, groove to the right,
16. Skipping four columns to the right, put a grooved 2x1 ver, groove to the left.

Bag 7

Unit 11. Make a bed.

1. Put a 6x2 hor on the table.
2. Put a 4x1 roll-down piece hor on the back row, on the right, roll to the back.
3. Put a 4x1 roll-down piece hor on the front row, on the right, roll to the front.
4. Put a F three-button corner piece on the front row, on the left, overhanging to the front, letter F.
5. Put a F three-button corner piece to the back, letter H.
6. Put a S 4x1 roll-down piece ver on the left edge, roll to the right.
7. Put two 1x1 hammer pieces ver to the right, buttons facing each other.
8. Put a FS 2x1 ver on top of the two PPs.
9. Make a checker pattern on the 4x2 space to the right, using four FS 1x1 pieces and four F 1x1 pieces.
10. Install this bed, the way it is, in the left back corner.
11. Put a F 10x2 hor to the front, on the back edge of the gap.

Unit 8.

1. Put two railing pieces hor, side by side, on the front row of the PP, starting on the left.
2. Put a 2x1 hor to the right.
3. Put a 1x1 slide on top, slide to the right.
4. Put a curved 2x1 ver on top of the other curved piece along the left wall.

Unit 11.

1. Put two grooved 2x1 pieces ver on top of the other two grooved pieces in front of the gap.
2. Put a 4x1 ver on top of the left wall.
3. Put a 6x1 ver to the back.
4. Put a 4x1 ver to the back.
5. Put a 4x1 hor to the right.
6. Put a 6x1 hor to the right.
7. Put a 4x1 hor to the right.
8. Put a 4x1 ver to the right and to the front.
9. Put a 6x1 ver to the front.
10. Put a 4x1 ver to the front.
11. Make a lamp. Put a wine glass piece on top of a F 2x1 with one button. Put an inverted saucer on top. Install hor on the leftmost button of the railing.

Bag 12.

Unit 10.

1. Stack four curved 2x1 pieces. Put a F 2x1 on top. Put two 1x1 buttons on top. Install this part on top of the other curved pieces along the left wall.
2. Put three arch frames hor to the back of the three FS 2x1 pieces on the front edge.
3. Put a 1x1 tall slide piece on the right front edge, slide to the front.

4. Put a 1x1 tall slide piece on top of a F 2x1.
5. Install this part to the left of the rightmost arch, in front of the grooved pieces, slide to the front.
6. Put a F 1x1 to the back.
7. Put a 1x1 tall slide to the left of the middle arch, in front of the grooved pieces, slide to the front.
8. Repeat steps 4 and 6 on the left front edge.

Unit 11.

1. Put a 1x1 lip piece to the back, hor, lip to the right.
2. Put a 4x1 ver to the back.
3. Put a 6x1 ver to the back.
4. Put a three-button corner piece to the back and to the right, letter F.
5. Put a F corniced 2x1 hor to the right, cornice to the back.
6. Install the pane in the 2x1 window frame and put the window on top of the cornice, windowpane to the back.
7. Put a 3x1 hor to the right.
8. Repeat steps 5-6.
9. Repeat step 7.
10. Repeat steps 5-6.
11. Put a three-button corner piece to the right and to the front, letter D.
12. Put a 6x1 ver to the front.
13. Put a 4x1 ver to the front.
14. Put a 1x1 lip to the front, ver, lip to the left.
15. Put a 3x1 trapeze (double lip) piece hor on the back button of the left grooved vertical column.
16. Repeat on the right.

Bag 13

Unit 12

1. Stack two 1x1 pieces. Repeat. Put a 4x1 arch on top, using the stacks as legs.
2. Repeat to make three such parts.
3. Install hor in the front wall, over the arch frames.
4. Put a 6x1 ver on the front end of the left wall, starting with the lip piece.
5. Put a 6x1 ver to the back.
6. Put a 2x1 hor to the back and to the right.
7. Repeat steps 4-6 symm on the right wall.

Unit 14.

1. Put two 1x1 buttons on the end buttons of a F 4x1 piece.
2. Repeat to make three such parts.
3. Put one hor on the left lip and on the left end of the left trapeze.
4. Put a 1x1 to the right.
5. Put another part to the right.
6. Put a 1x1 to the right.
7. Put another part to the right.
8. Put a F corniced 2x1 hor on top of the middle two buttons of each front arch, cornices to the front.

Unit 14.

1. Put three F 4x2 pieces ver on top of each PP and the middle two buttons of the three F 4x1 pieces in the back (between the 1x1 buttons), so that the 4x2 pieces overhang to the front. And are aligned at the back.
2. Put four 1x1 tall slide pieces on top of the other tall slide pieces in the front wall, slides to the front, so that they make a continuous diagonal line.

Bag 15

Unit 15

1. Put three F 4x2 pieces hor between the four diagonal counterforces, on the back two rows of the vertical F 4x2 pieces.
2. Put a 1x1 on the back wall, to the right of the left window.
3. Put a 1x1 lip ver to the right, lip to the front.
4. Put a 1x1 to the right.
5. Repeat steps 3-5 between the other two windows on the back.

Unit 16.

1. Put two F 3x1 hor on top of the two PPs, aligned at the back.
2. Put two F 2x2 in the back corners, aligned on the outside.
3. Put two F 10x1 ver to the front, on the left and right walls.
4. Put four 1x1 hammer pieces at the sides of the left 2x2 overhanging over the arch on the front wall, two right ones rolling to the right, and two left ones, to the left.
5. Repeat on the other two arches.

Bag 16

Unit 17

1. Put a F 2x1 from a sep bag hor on the back row of the 2x2 space formed by the hammers over the left arch.
2. Put a F 2x1 with the handle hor to the front, handle to the front.
3. Repeat steps 1-2 on the other two arches.
4. Put a F 1x1 in the left wall, to the back of the counterforce,
5. Skip one column to the right and put a F 2x1 ver to the right, to the back of the left awning.
6. Skip one column to the right and put a F 2x1 ver.
7. Repeat.
8. Repeat.
9. Skip one column to the right and put a F 1x1 to the back of the counterforce.
10. Skip one column of the right and put a F 2x1 ver.
11. Repeat.

Unit 18.

1. Put two F 2x1 with one button hor, one behind the other, on top of the left awning.
2. Repeat on the other two.
3. Skipping the first two rows on the front end of the left wall, put a 4x1 ver on the left wall.
4. Put a 6x1 ver to the back.
5. Put a tall 1x1 slide to the back, ver, slide to the back.
6. Put a tall 2x1 slide to the right, slide to the back.
7. Repeat.
8. Put a 1x1 slide to the right.
9. Put two 2x1 slides to the right.
10. Put a 1x1 slide to the right.
11. Put two 2x1 slides to the right.
12. Put 1x1 slide to the right.
13. Put a 6x1 ver to the front.
14. Put a 4x1 ver to the front.

Bag 17

Unit 19.

1. Put three FS 2x1 pieces ver on tops of the three arches in the front.
2. Put sixteen 1x1 tall slides on top of the front wall, slides to the front, side by side. They will be in the ragged up-down pattern.

Unit 20.

1. Put eight F 1x1 pieces on the "down" 1x1 tall pieces to make them the same height as the "up" ones.
2. Put a 6x1 ver on the front end of the left wall.
3. Put a 4x1 ver to the back.
4. Repeat steps 2-3 on the right.
5. Make a finishing decoration part for the arch in front. Flip a F 1x1 with the clasp upside down. put a smaller end of a cone on top. Repeat to make two more. Install on the handles in front of the awnings.

Bag 18.

Unit 21

1. Put a FS 4x2 ver on the front end of the left wall, aligned on the outside.
2. Put a F 4x1 with two buttons ver to the back.
3. Put a FS 4x2 ver to the back, as before.
4. Put a FS 2x1 hor to the right.
5. Put a FS 8x1 hor to the right.

6. Put a FS 2x1 hor to the right.
7. Repeat steps 1-3 on the right.
8. Repeat steps 4-6 on the front.

Put this structure on top of the second floor.

Bag 19 number 25.

Unit 1.

1. Put a F 6x6 on the table.
2. Put a F 4x2 hor to the right, next to the back two rows of the 6x6.
3. Put a F 6x6 to the right, symm to the one on the left.

Unit 2.

1. Connect them with two FS 8x1 pieces. Put them hor on the back row, side by short side.
2. Put a F 16x6 hor to the front of your part.

Unit 3.

1. Connect it to your part with the two FS 8x1 pieces. Put them ver on the right and left edges, starting to the front of the two horizontal FS 8x1 pieces at the back.
2. Make a skylight over the gap. Put two wide slide pieces hor over the gap, button sides facing each other.
3. Put two 1x1 long slide pieces ver to the left, bttons facing each other. Repeat on the right.
4. Put a 2x1 curved piece ver on the second column from the left, on the 3<sup>rd</sup> and 4<sup>th</sup> rows.

Unit 4.

1. Put a 1x1 in the front left corner.
2. Put a F 2x1 with one button hor to the right.
3. Repeat.
4. Repeat.
5. Put a 1x1 to the right.
6. Repeat.
7. Put a F 2x1 with one button to the right.
8. Repeat.
9. Repeat.
10. Put a 1x1 to the right.

Bag 20

Unit 5.

1. Stack two 1x1 buttons. repeat. Put them side by side on a F 2x1. Put a FS 2x1 on top. Install on the curved 2x1 on the left side of the structure.
2. Put a FS 1x1 on top of a 1x1 button. Repeat to make six such parts. Install on the front edge, on the F 2x1 pieces with one button, so that the 1x1 FS pieces are turned diamond-like.

Unit 6.

1. Put two FS 8x1 hor over the PP, side by shor side, on top of the four 1x1 pieces on the front wall.
2. Install on the roof.
3. Connect all floors.

Enjoy!

Thank you so much for building this set!

Visit [legofortheblind.com](http://legofortheblind.com) for more accessible instructions!

**Abbreviation definitions:**

- F = flat (Plate.)
- FS = flat smooth (tile)
- Slide = slope.
- Lip = inverted slope.
- Ribbed stick = Technic axle.
- Connector = Technic pin.

Stubby or Short connector = Technic pin with stud.  
Long connector = elongated Technic pin.  
Nail = technic axle with end stop.  
Fat nut = Technic joiner.  
Thin nut = Technic stop.  
Elbow = technic joiner 90 dg.  
1x1, 2x1, 3x1... means a 1x1, 2x1, 1x3... brick.  
Ver = vertically.  
Hor = horizontally.  
Symm = symmetrically.  
LMA = Lay Momentarily Aside.  
PP = previous piece.  
Sep bag = separate bag.  
Braille letters (for placing corner pieces):  
D = open corner to the front left.  
F = open corner to the front right.  
J = open corner to the back left.  
H = open corner to the back right.