

43011 Lionel Messi – Soccer Highlights

Adapted by Maria Goldoriole and blind builder Laia Isus. Tested by Peter Durieux.

Kids cheer on a soccer legend with the LEGO® Lionel Messi – Soccer Highlights (43011) building set for boys and girls ages 10 and up. Soccer fans will have lots of fun crafting this collectible display model that celebrates Messi. The base forms his name and features the colors of Argentina, his national team, and a large 10, which is one of his iconic jersey numbers. A Lionel Messi minifigure brings the set to life and there's also a collectible plaque displaying his player stats and name, plus lots of Easter eggs that nod to his life and career. The finished set becomes a cool piece of Messi merch and soccer decor that fans can show off proudly. This creative toy makes a great sports gift for boys, girls and Messi fans on birthdays and special occasions. Instructions are available digitally in the LEGO Builder app, where star players can track their progress, zoom in and rotate their creations in 3D. Set contains 500 pieces.

- **SOCCER BUILDING SET FOR KIDS** – Score a creative goal with the LEGO® Editions Lionel Messi – Soccer Highlights (43011) for boys, girls, and sports fans ages 10 and up.
- **SPORTS FAN MERCHANDISE** – The base is formed in the shape of Messi's initial and features the colors of the Argentinian team, a number 10, and a collectible plaque with player stats and Messi's name.
- **LEGO® SOCCER PLAYER MINIFIGURE** – A Lionel Messi minifigure brings the scene to life and the set includes lots of Easter eggs that nod to his background and career.
- **SOCCER DECOR** – This display model becomes a piece of collectible sports decor that kids can show off on its own or alongside other LEGO® Editions Soccer Highlights sets (sold separately)
- **GIFT FOR SPORTS LOVERS** – The set makes a great gift for boys, girls and soccer fans on birthdays, holidays, and other special occasions.
- **LEGO® EDITIONS** – Show your love for more legendary sports stars with other sets (sold separately) in the collection.
- **A HELPING HAND** – Budding soccer stars can access instructions digitally in the LEGO® Builder app, where they can track progress and zoom in and rotate their soccer model in 3D.
- **DIMENSIONS** – The 500-piece Messi display set measures over 5 in. (13 cm) high, 9.5 in. (24 cm) wide and 6 in. (15 cm) deep.

The front of the LEGO Editions 43011 Lionel Messi – Football Highlights box shows the completed model in the center against a white background. The build features a large vertical golden "10", with a small Messi minifigure wearing the Argentina jersey in front of it, posed mid-shot as he kicks a FIFA-style ball in blue, black, white, and coral. The base is shaped like an M, Messi's initial, combining green, blue, and white colors. A blue nameplate with "MESSI" spelled out in white elements is visible along the front edge. The LEGO logo appears in the upper-left corner. In the lower-left corner are the recommended age 10+, the set number 43011, the set name Lionel Messi – Soccer Highlight, and the piece count 500. The word "Editions" is placed in the lower-right corner. The overall impression is bold and celebratory, highlighting Messi's iconic number and the colors of Argentina.

The back of the box keeps the same white background and shows the model from a different angle. The large golden "10" appears again, emphasizing the depth and stacking of the bricks,

and the Messi minifigure is shown in another action pose. The base displays its green pitch stripe, the blue and white Argentina colors, and the “MESSI” nameplate at the front. A small inset shows the Messi minifigure from behind, with his head turned slightly to the left.

This set contains 500 pieces, and it is for ages 10+.

Bag 1: contains the pieces to build the M shaped base.

Bag 2: contains the pieces to build the M shaped base.

Bag 3: contains the pieces to build 4 buildings and the goal.

Bag 4: contains the pieces to build the large number 10, a plaque with the letters Messi, a plaque with Messi stats, and the Lionel Messi minifigure scoring a goal.

Welcome to Text-Based Building Instructions from Bricks for the Blind. Here is some helpful information on how to best use screen readers and browsers: bricksfortheblind.org/help-with-screen-readers. Before you start building, here are some terms we will be using:

- - In Front of/Front: towards you.
- - Behind/Back: away from you.
- - Up: towards the ceiling.
- - Down: towards the floor.
- - Stud: the bump on a LEGO brick. Example: A 2x1 brick has two studs on it.
- - Vertically: with the longest side going from front to back
- - Horizontally: with the longest side going from left to right.
- - Upright: pointing up towards the ceiling.
- - Standing upright: The piece is perpendicular to the ground, like a wall.
- - Lying flat: The piece is parallel to the ground, like a piece of toast which fell off the table.
- - That one/ppp: previously placed piece.
- - Plate: piece with studs.
- - Tile: smooth piece without studs (unless otherwise specified)
- - A jumper plate is a 1x2 plate with a single stud on top, or a 1x3 plate with only two studs on top.
- - Anti-stud is a term for the portion of a LEGO piece which accepts studs, like the bottom of a plate or brick.
- - Left/ right wedge parts: these are parts that when placed in front of you and are pointing to the back, their wedge or cut corner is on the left/ right side of the part.
- - Symmetrically: a mirror image. Example: If you place a 2x1 brick with technic connector on the front wall at the right, connector to the front, and then place another such piece symmetrically on the back wall, at the right, the technic connector of the second piece should point to the back, since it will be placed symmetrically.
- - Centered-vertically: even amount of space in front of and behind piece
- - Centered-horizontally: even amount of space left and right of piece.
- - Row: studs lined up horizontally (left to right/side to side).
- - Column: studs lined up upright or vertically (top to bottom/back to front).
- A note on LEGO Technic™ part names. These parts are different from regular LEGO bricks. Here are some definitions in case the builder or helper is not familiar with LEGO Technic™.
- - Axles - An axle is a connector which has an X shaped cross-section. Because their cross section is not round, anything connected to an axle using an axle-hole will rotate with that axle. Axles are longer than they are wide, and the length of an axle corresponds with how many bricks long it is. Aka a 3L axle is three bricks long. Axles come in a variety of lengths, with a 2L axle being the shortest available. They may be

combined with pins or have circular stops on them. A stop prevents the axle from sliding through an axle-hole at a specific point on the axle.

- - Pins - A pin is a connector which has a circular cross section and a flanged notch out of one or both ends. This flanged notch allows them to click into bricks with a pinhole. Pins come with and without friction ridges, which are small bumps on the pin which prevent them from rotating freely. For standard pins, black is a high friction pin, and gray is a low friction pin. A standard-length pin is two brick lengths long, with a stop in the middle. This prevents a brick from being pushed from one side of the pin to the other. A 1L pin is one brick long and still retains the stop; however, it also includes a hollow stud at the other end. A 3L pin is three bricks long, and only contains a stop at one side, allowing two bricks to be pushed onto the other side of the pin. Pins may also have one side which is an axle.
- - Technic brick - a brick which contains one or more holes which accept technic pins.
- - Lift-arms - A lift-arm is a basic structural element, like a brick or a plate, but usually without any studs. It is a beam with rounded ends and with holes in it, with the same spacing as the studs on a LEGO brick. lift-arms come in a variety of lengths, including a 1x1 lift-arm which looks like a cylinder. Thick lift- arms are as wide as a LEGO brick, and thin lift-arms are half as wide as a LEGO brick, but not the same thickness as a LEGO plate! The holes in a lift-arm arm may accept axles or pins. They also come in a variety of shapes, including tees, ells, and triangles.
- - Gears - A gear is a functional element. They are typically discs with teeth on the outside; there are also worm gears which look like a spiraling cylinder! Gears connected by axles transmit or even transform rotational motion!
- - Axle and Pin Connectors - These elements are typically smaller than lift-arms and are used to connect some combination of pins or axles. They might have pins or axles, as well as axle or pinholes. They have a lot of different angle combinations! The simplest just connects two axles or pins together in a straight line.
- - Bushes/Bushings - LEGO Technic™ uses bushes largely as spacers, but they also can reduce friction between rotating parts or can form useful elements such as bars. Bushes are typically light gray, cylindrical, and have an axle-hole running through the middle. They have a flange at the front and back to make it easier to pull on and off.

For builders with low vision, or a sighted building partner who may want to follow along with the printed visual instructions that come with each kit, PDF versions are always online at LEGO.com: (<https://www.lego.com/en-us/service/building-instructions/43011>) As low vision users may benefit from viewing the instructions on a personal device.

Sorting the pieces:

To begin a successful build, it helps to sort the pieces into groups, bags, or small containers. Have a sighted friend or family member do this in advance following the instructions below. You will see that the pieces should be sorted into groups according to the building steps in the set. Doing this in advance makes locating the pieces easier. See below on how to sort the pieces to correspond to the steps in this set. Number the containers using letters A-Z, Numbers, or meaningful names. The parts will be collected into a small Number from steps in the instructions. Example: Steps 1-3 means collecting all the parts used in steps 1, 2 and 3, and putting them in one container.

This set comes with 4 labelled paper bags, and 1 instruction booklet.

Sort the pieces into groups as described below. Note that where there are multiple colors of the same brick in a step, the colors will be split across two groups to make telling the difference easier for the builder! LEGO includes a few spare parts in case you lose something.

Book 1

Bag 1

Group 1: contains the pieces for steps 1-8.

Group 2: contains the pieces for steps 9-10.

Group 3: contains the pieces for steps 11-17.

Group 4: contains the pieces for steps 18-23.1.

Group 5: contains the pieces for step 23.2.

Group 6: contains the pieces for step 24.1.

Group 7: contains the pieces for step 24.2.

Group 8: contains the pieces for step 25.1.

Group 9: contains the pieces for step 25.2.

Group 10: contains the pieces for step 26.1.

Group 11: contains the pieces for step 26.2.

Group 12: contains the pieces for step 27.1.

Group 13: contains the pieces for step 27.2.

Group 14: contains the pieces for steps 28-30.1.

Group 15: contains the pieces for steps 30.2-32.

Group 16: contains the pieces for steps 33-45.

Group 17: contains the pieces for steps 46-48.

Group 18: contains the pieces for steps 49-50.

Group 19: contains the pieces for steps 51-52.

Bag 2

Group 20: contains the pieces for steps 53-54.

Group 21: contains the pieces for steps 55-56.

Group 22: contains the pieces for steps 57-61.

Group 23: contains the pieces for steps 62-63.

Group 24: contains the pieces for steps 64-71.

Group 25: contains the pieces for steps 72-79.

Group 26: contains the pieces for steps 80-83.

Group 27: contains the pieces for steps 84-90.

Group 28: contains the pieces for steps 91-92.

Group 29: contains the pieces for steps 93-97.

Group 30: contains the pieces for step 98.

Bag 3

Group 31: contains the pieces for steps 99-104.

Group 32: contains the pieces for steps 105-106.1.

Group 33: contains the pieces for steps 106.2-108.1.

Group 34: contains the pieces for step 108.2.

Group 35: contains the pieces for steps 108.3-111.1.

Group 36: contains the pieces for steps 111.2-114.

Group 37: contains the pieces for step 115.

Group 38: contains the pieces for steps 116-117.1.

Group 39: contains the pieces for steps 117.2-118.1.

Group 40: contains the pieces for steps 118.2-127.

Group 41: contains the pieces for steps 128-131.1.

Group 42: contains the pieces for steps 131.2-135.

Group 43: contains the pieces for steps 136-147.

Group 44: contains the pieces for steps 148-150.

Group 45: contains the pieces for steps 151-158.

Bag 4

Group 46: contains the pieces for steps 159-161.

Group 47: contains the pieces for step 162.

Group 48: contains the pieces for steps 163-164.

Group 49: contains the pieces for steps 165-170.

Group 50: contains the pieces for steps 171-176.

Group 51: contains the pieces for steps 177-182.

Group 52: contains the pieces for steps 183-185.

Group 53: contains the pieces for steps 186-196.

Group 54: contains the pieces for steps 197-208.

Group 55: contains the pieces for steps 209-212.

Description:

When the model is fully built, it represents a celebratory scene of Lionel Messi running toward the goal after kicking the ball, all placed on a special base shaped like an M, his initial. This M is stylized like two connected mountains, with the left mountain taller than the right, creating a

height difference that is easy to feel by touch. The base combines green at the front like a soccer field and blue and white in the center forming the vertical stripes of Argentina's official jersey. To imagine its final orientation, picture the M rotated 90 degrees counterclockwise, so the mountains point to the left and the front edge faces you. On the front left corner there is a blue plaque with MESSI spelled out in white bricks, large and tactile, and on the front right corner there is a printed tile showing his statistics and a small photo, smooth to the touch and rectangular. At the exact center of the base stands the minifigure of Messi, leaning forward in a running pose with one leg ahead and the other behind, his head slightly turned toward the goal. The ball is no longer at his feet: he has already kicked it, and a blue cloud-shaped element connects his left foot to the ball, showing the fast upward trajectory of the shot. He wears Argentina's official jersey with blue and white stripes and the number 10 on his back. The minifigure recreates Messi's real appearance, with short dark brown hair, a full beard, and a focused, determined expression, matching his look during his Argentina career. In the back right corner rises the white frame of the goal, tall and open like a rectangular arch. In the back left corner stand four buildings symbolizing key moments of his life: an orange building for his childhood in Rosario, a blue-and-maroon one for his years at FC Barcelona, a blue one for his time at Paris Saint-Germain, and a pink one representing his era at Inter Miami. The entire model conveys movement, history, and celebration, with Messi already sending the ball toward the goal while his journey and colors surround him in the scene.

General placement guidelines

Start Building

Step 1

Rows and Columns Across the Whole Build:

Unless we say otherwise, rows are counted from front to back or back to front, and columns are counted from left to right or from right to left across the entire build.

Example: Vertically place a tan 1x2 plate on the 4th and 5th rows from the front on the 3rd column from the left. or place a white 2x2 tile with stud on the 2 back rows on the 3rd and 4th columns from the right.

This uses the full build's row and column Layout.

Step 2

Why We Sometimes Count Columns from a Specific Row:

Each row can have a different number of columns. This happens when the build becomes narrower or wider toward the sides, or when certain rows have cutouts, curves, or irregular shapes.

So, if a row is shorter or wider than the rows above or below it, counting columns across the whole build becomes misleading. To avoid confusion, we count columns within that specific row.

Example: Instead of: Place the 1x2 plate on the front row on the 2nd and 3rd columns from the right. We say: Place the 1x2 plate on the 2nd and 3rd columns from the right of the front row.

This makes it clear that the row itself is the reference, not the whole build.

Step 3

Why We Sometimes Count Rows from a Specific Column:

Each column can have a different number of rows. This happens when one column extends further back than the next, another extends forward, some columns are tall, others short, or the

shape is staggered or irregular. When columns vary in height or depth, counting rows across the entire build becomes confusing. To avoid this, we count rows within that specific column.

Example: Place a tan 1x1 round plate on the 3rd row from the back of the 2nd column from the right.

This avoids the problem of columns with different lengths.

Step 4

Using Landmarks for Tactile Orientation:

When rows and columns alone aren't enough, we add landmarks—nearby pieces that help the builder feel where the new piece belongs.

Example: Vertically place a green 2x4 plate on the 2nd through 5th rows from the back on the 2nd and 3rd columns from the left, so the back row sits on the front row of the back left 2x2 corner plate, and the front row sits on the back row of the front left 2x2 corner plate.

These tactile cues confirm the correct placement.

General technic guidelines

Step 1

In this set, you will use Technic elements such as liftarms, pins, axles, and connectors. Liftarms may appear in different shapes (for example, straight, L-shaped, bent, or T-shaped), and they may include both pin holes (round) and axle holes (cross-shaped). Liftarms also come in two thicknesses, which affects how far pins and axles extend when inserted.

Liftarm Thickness: Thick vs. Thin:

- A thick liftarm is the standard type and is 1L thick.
- A thin liftarm is 0.5L thick (half the thickness of a regular liftarm).

When a step uses a thin liftarm, the instruction will always say so. If the instruction does not mention thickness, you should assume the liftarm is the standard 1L thick type.

This is important because they are half as thick, and a pin or axle inserted through a thin liftarm will extend 0.5L farther on 1 side compared to the same pin inserted through a thick liftarm.

Example

- In a 3L thick liftarm, inserting a 2L pin from front to back leaves 1L extending toward the front.
- In a 3L thin liftarm, inserting the same 2L pin from front to back leaves 1.5L extending toward the front.

Step 2

Counting the Holes

- When a liftarm has both pin holes and axle holes, we count all holes in order, from one end of the liftarm to the other.
- Unless the instruction specifically says, in the axle hole or in the pin hole, you should assume the counting includes both types of holes together.
- The instruction will always tell you which direction to count from: from the right or from the left.

Examples

- Insert a tan 2L pin into the 2nd back-facing hole from the right.

Count all holes (pin and axle) starting at the right end. Place the pin in the second hole.

- Insert a black 2L axle into the 3rd hole from the left.

Count all holes from the left end until the third one, regardless of type.

- Insert a blue pin into the axle hole in the 4th position from the right.

Here, the instruction specifies axle hole, so place the pin in the cross-shaped hole at that position.

Step 3

Directional Guidance for Inserting or Attaching Pieces

To make Technic building smoother for blind builders, we always specify the exact direction a pin, axle, or connector moves when it is inserted or attached.

We use the following terms:

- front to back — the piece moves away from you
- back to front — the piece moves toward you
- top to bottom — the piece moves downward
- bottom to top — the piece moves upward

Examples

- Insert a black 2L pin from front to back into the second front-facing hole from the right of your 5L lifarm.

- Insert a 3L pin from back to front into the 3rd back facing pin hole from the left, so 2L of the pin extends to the back. Attach the leftmost front facing hole of your 7L lifarm from back to front onto the 2L back extending pin.

Step 4

Specifying How Far a Pin or Axle Extends

After inserting or attaching a piece, we always tell you how much of the pin or axle extends in each direction, using Technic length units (L).

This measurement automatically accounts for whether the lifarm is thick or thin.

Examples

- Insert a black 2L pin from front to back into the second front-facing hole from the right of the 5L lifarm, so 1L of the pin extends toward the front.

- Attach the leftmost back-facing hole of a 7L lifarm from front to back onto the 1L pin extending at the front.

These technic guidelines help to make Technic-set building easier for blind builders.

Let's get to building!

Building Instructions (Bag 1, Book 1):

Group 1:

Step 1

Vertically place a grey 3x8 left wedge plate in front of you, so the long straight edge is on the left and the cut corner is on the front right. vertically place a nougat 1x2 brick with 2 side studs on top of the ppp on the back right corner, so the side studs face the right.

Step 2

Horizontally place a green 2x4 brick to the left of the ppp, so 2 columns overhang to the left.

Step 3

Horizontally place the back right corner of a grey 4x12 plate underneath the left overhanging columns.

Step 4

Place a green 2x4 brick horizontally to the left of the previous one on the 2 back rows. Place a lime 1x1 round brick to the left of the back row of the ppp. Horizontally place a dark grey 1x2 brick with axle hole to the left of the ppp. Horizontally place a dark orange 1x4 brick to the left of the ppp, so 1 column overhangs to the left.

Step 5

Horizontally place the 6 right columns of a tan 1x8 brick on the 6 left columns of the 2nd row from the back of your build (here, we are counting only the columns within this mentioned row), so 2 columns overhang to the left.

Step 6

Place a grey 2x2x2/3 short, ribbed brick with axle hole on the 3rd and 4th rows from the back, so it is centered horizontally on these 2 rows. Place a black 2x2x2/3 curved slope brick to the right of the ppp, so it slopes to the right. Place another to the right of the ppp, so it slopes to the left. Horizontally place a medium blue 1x2 brick to the right of the back row of the ppp. Place a yellow 2x2 round brick with axle hole in front of the ppp. Vertically place a medium blue 1x2 brick in front of the left column of the ppp.

Step 7

Vertically place a dark grey 1x2 rounded plate on the 6th column from the left of the 3rd and 4th rows from the back (here, we are counting only the columns within these 2 mentioned rows). Vertically place another on the 3rd column from the left of the 3rd and 4th rows from the back (here, we are counting only the columns within these 2 mentioned rows). Horizontally place the leftmost column and the rightmost column of a white 2x4 plate on the 2 ppps.

Step 8

Vertically place the 4 back rows of a black 2x14 plate to the left of your build, so the 2 back row attach underneath the left overhanging columns.

Group 2:

Step 9

Horizontally place the right column of a dark grey 1x2 brick with axle hole on the leftmost column of the back row of the ppp, so 1 column overhangs to the left. Horizontally place the rightmost column of a green 1x4 plate underneath the left column of the ppp. Place a yellow 1x1 brick with 1 side stud on the leftmost column of the ppp, so the side stud faces the left. Horizontally place a dark orange 1x2 log brick to the right of the ppp.

Step 10

Horizontally place a white 2x4 plate on the 4 left columns of the 3rd and 4th rows from the back (here, we are counting only the columns within these 2 mentioned rows), so it sits to the left of

another horizontal 2x4 plate. Vertically place a nougat 1x2 brick with 2 side studs on one long side in front of the leftmost column of the ppp, so the side studs face the left.

Group 3:

Step 11

Let's make a part! Horizontally place a grey 2x12 plate in front of you. Horizontally place a white 2x4 plate on top of the ppp on the 4 right columns.

Step 12

Place 2 consecutive gold 1x1 round plates to the left of the front row of the ppp. Repeat symmetrically to the back.

Step 13

Place 2 consecutive white 1x1 tiles with upright clip to the left of the 2 back ppps, so the hands of the clip face the left and the right. Horizontally place a white 1x2 half round tile in front of the 2 ppps, so the rounded edge faces the front.

Step 14

place 2 consecutive gold 1x1 round plates to the left of the ppp. Repeat both placements symmetrically to the back. Horizontally place a white 2x4 plate to the left of the ppps, so 2 columns overhang to the left.

Step 15

attach the front bar of a tan cow horn on the right clip so the corn points to the back right. Repeat symmetrically to the left.

Step 16

Bring back your main build and position it horizontally in front of you, so the 2x14 plate faces the front vertically. Horizontally place the 2 left columns of your part on the 5th and 6th columns from the left counting the entire build, so it is centered vertically and it sits on the vertical black 2x14 plate.

Step 17

Horizontally place a dark grey 1x2 rounded plate on the 4th row from the front counting the entire build. Vertically place a nougat 1x2 brick with 2 side studs on 1 long side behind the left column of the ppp, so the side studs face the left.

Group 4:

Step 18

Let's make a part! Horizontally place a black 4x10 plate in front of you. Horizontally place a white 2x4 plate on the back right corner.

Step 19

Horizontally place 2 consecutive dark grey 1x2 rounded plates to the left of the back row of the ppp. Repeat both placements symmetrically to the front. Place the 2 right columns of a white 2x4 plate on top of your part on the 2 back rows on the 2 left columns, so 2 columns overhang to the left.

Step 20

Place a black 4x4 plate with open center on top of your part, so it is centered horizontally and sits on the 4 1x2 rounded plates.

Step 21

Horizontally place a green 1x4 plate on the front row of the ppp, so there's no overhang.

Step 22

Bring back your main build and place it horizontally in front of you so the 2x14 plate faces the front. Horizontally place the 2 left columns of your Part on the 2nd and 3rd rows from the front of your main build, so they sit on the vertical 2x14 plate.

Step 23.1

Vertically place a white 1x2 plate on the leftmost column of the 3rd and 4th rows from the back. Place a white 2x2 triangular tile to the right of the ppp, so the right angle faces the front left.

Group 5:

Step 23.2

Place an orange 2x2 triangular tile to the right of the ppp, so the right angle faces the back right. Place an orange 1x2 plate vertically to the right of the ppp.

Group 6:

Step 24.1

Vertically place a red 1x2 plate on the leftmost column of the 7th and 8th rows from the back. Place a red 2x2 triangular tile to the right of the ppp, so the right angle faces the front left.

Group 7:

Step 24.2

Place a black 2x2 triangular tile to the right of the ppp, so the right angle faces the back right. Vertically place a black 1x2 plate to the right of the ppp.

Group 8:

Step 25.1

Vertically place a yellow 1x2 plate on the 7th and 8th rows from the back on the 4th column from the right counting the entire build. Place a red 2x2 triangular tile to the left of the ppp, so the right angle faces the front right.

Group 9:

Step 25.2

Place a blue 2x2 triangular tile to the left of the ppp, so the right angle faces the back left. Vertically place a yellow 1x2 plate to the left of the ppp

Group 10:

Step 26.1

Vertically place a dark blue 1x2 plate on the leftmost column of the 3rd and 4th rows from the front, so it sits in front of a 1x2 rounded plate. Place a white 2x2 triangular tile to the right of the ppp, so the right angle faces the front left.

Group 11:

Step 26.2

Place a red 2x2 triangular tile to the right of the ppp, so the right angle faces the back right. Vertically place a dark blue 1x2 plate to the right of the ppp.

Group 12:

Step 27.1

Vertically place a pink 1x2 plate on the rightmost column of the 3rd and 4th rows from the front. Place a white 2x2 triangular tile to the left of the ppp, so the right angle faces the front right.

Group 13:

Step 27.2

Place a black 2x2 triangular tile to the left of the ppp, so the right angle faces the back left. Vertically place a pink 1x2 plate to the left of the ppp.

Group 14:

Step 28

Let's make a sub build! Horizontally place a green 1x4 plate in front of you. Horizontally place a nougat 1x5 plate on the ppp, so 1 column overhangs to the left.

Step 29

Place a black 1x1 plate with 1x1 upright side stud underneath the left overhang, so the side stud faces the left.

Step 30.1

Place a reddish brown 1x1 short brick with a round side and a side stud upright on the left facing side stud, so the rounded edge points to the back, the side stud points to the front, and the top stud faces the left. Insert the bar of a black 1x1 round tile with upright bar into the front facing open stud of the ppp.

Group 15:

Step 30.2

Place a silver 1x1 round tile with upright bar upright on the left facing side stud, so the bar points to the left.

Step 31

Horizontally place a dark orange 1x2 curved half arch brick on top of your part on the leftmost column, so the arch faces the left and 1 column overhangs to the left. Horizontally place a nougat 1x3x2 inverted half arch brick on the 3 right columns, so it slopes to the left.

Step 32

Horizontally place a dark orange 1x2 plate in front of you. Horizontally place the left column of a nougat 1x2 inverted arch brick on the rightmost column of the ppp, so it slopes and overhangs by 1 column to the right.

Group 16:

Step 133

Place a yellow 1x1 brick with side stud on the leftmost column, so the side stud faces the front.

Place the bar of a black 1x1 round tile with upright bar into the front facing side stud of the ppp.

Step 34

Horizontally place the right column of a dark orange 1x2 curved half arch brick on top of the ppp, so it slopes to the right and overhangs to the left by 1 column. Place a green 1x1 plate on top of the ppp.

Step 135

Place the left column of a nougat 1x2x3 arch brick on the ppp, so it slopes to the right and connects with the 1x2 inverted arch brick. Place a 1x1 quarter round tile on top of the ppp, so the right angle faces the front right and the rounded edge faces the back left.

Step 36

Horizontally place the left column of a nougat 1x2x3 arch brick underneath the rightmost column of your sub build, so it slopes to the right

Step 37

Horizontally place a tan 1x3 plate underneath the 3 leftmost columns of your sub build.

Step 38

Bring back your sub build and place it horizontally in front of you, so the bar faces the left. Place the 3 right columns of your part on the 3 leftmost columns of your sub build, so the nougat 1x3x1 2/3 half arch curved top brick attaches on the 3rd column from the left of your sub build.

Step 39

Rotate your part 90 degrees clockwise, Flip it so it sits on its left side and the antistuds face the right. Bring back your main build and position it vertically in front of you so the straight long side faces the left. Attach your sub build on the front left facing side studs.

Step 40

Place a dark orange 1x1x3 brick upright to the right of the attached sub build. Then horizontally place the right column of a dark orange 1x2 curved half arch brick on the ppp, so the arch faces the right, and the left column sits on a 1x3x2 inverted half arch brick.

Step 41

Place a dark grey 1x2 rounded plate horizontally on the 5th rows from the front on the 3rd and 4th columns from the left counting the entire build. Horizontally place another on the back row of the 3rd and 4th columns from the right (here, we are counting only the rows within the 2 mentioned columns), so it sits on a horizontal pink 1x2 plate.

Step 42

Horizontally place a nougat 1x2 brick with 2 side studs on a long side to the right of the ppp, so the side studs face the back. Horizontally place a green 1x2 plate with upright clip and 1 stud upright on the back facing side studs of the ppp, so the clip is on the right.

Step 43

vertically place a nougat 1x2 brick with 2 side studs on a long side on the 2nd and 3rd rows from the back of the rightmost column (here, we are counting only the rows within this mentioned column), so the side studs face the right. Place a yellow 1x1 brick with a side stud in front of the ppp, so the side stud faces the right. Then, vertically place a nougat 1x2 brick with 2 side studs on a long side 2 front rows of the rightmost column (here, we are only counting the rows within this mentioned column), so the side studs face the right.

Step 44

Let's make a part! Place a black 4x4 plate with open center in front of you. Place the left column of a white 3x3 corner plate on the rightmost column of the ppp, on the 3 back rows, so the right angle faces the front left, and 2 columns overhang to the right. Horizontally place a grey 1x2 rounded plate to the left of the back row of the ppp. Horizontally place a medium blue 1x2 plate on the ppp. Rotate your part 90 degrees counterclockwise, so the overhang is on the back. Bring back your main build and position it vertically in front of you, so the long straight edge is on the left. Place the 2 overhanging rows on the 2 front rows of the 2nd column from the right (here, we are counting only the rows within this mentioned column).

Step 45

Let's make a part Vertically place a dark orange 1x4 brick in front of you. Horizontally place a black 1x2 plate underneath the 2 back rows of the ppp. Bring back your main build, so it is vertically in front of you and the long straight side faces the left. Place the 2 front rows of your part on the 3rd and 4th rows from the front of the rightmost column (here we are counting only the rows within this mentioned column), so it sits on the 4x4 plate with open center.

Group 17:

Step 46

Vertically place a tan 1x4 brick with 4 side studs on a long side in front of the ppp, so the side studs face the right and 2 rows overhang to the front. Vertically place a black 1x2 plate underneath the front overhanging rows of the ppp.

Step 47

Horizontally place a tan 1x4 brick with 4 side studs on the 3rd row from the front on the 2nd and 3rd columns from the right counting the entire build, so the side studs face the front, it sits on the front row of the 4x4 plate with open stud, and 1 column overhangs to the left.

Step 48

Horizontally place a tan 1x2x2/3 brick with 2x2 side studs upright on the 2 right columns of front facing side studs, so the 2x2 side studs face up. Horizontally place a 1x3x2 curved inverted half arch brick upright to the left of the ppp, so it slopes to the left.

Group 18:

Step 49

Let's make a part! Stack 2 tan 1x3 plates. Place your stack horizontally in front of you. Horizontally place a dark orange 1x2 plate on the 2 right columns of the ppp. Then place the right column of a dark orange curved half arch brick to the left of the ppp, so the arch faces the right and 1 column overhangs to the left. Horizontally place a nougat 1x3x2 curved inverted half arch brick on top of your part, so there is no overhang and it slopes to the left. Place a dark orange 1x1 quarter round tile on top of the ppp, so the right angle faces the front right and the rounded edge faces the back left. Bring back your main build and position it vertically in front of you so the long straight side faces the left. Horizontally place your part on the 3 columns of front facing side studs, so the back right corner of your part aligns with the front right corner of your main build.

Step 50

Horizontally place a grey 1x12 plate on top of your build on the 10th row from the front on the 2nd through 13th columns from the right counting the visible studs. Vertically place a dark orange 4x6 plate in front of the 4 right columns of the ppp.

Group 19:

Step 51

Horizontally place a green 4x6 plate on the 4th through 7th rows from the back on the 3rd through 8th columns from the left counting the entire build. Place 2 green 3x3 plates one in front of the other in front of the 3 left columns of the ppp.

Step 52

Horizontally place a green 1x4 plate on the 11th row from the front on the 2nd through 5th columns from the right counting the visible studs, so it sits behind the 4 right columns of the horizontal 1x10 plate, and 1 column overhangs to the left. Vertically place a green 4x6 plate behind the ppp.

You've started shaping the big M at the heart of this tribute, laying down the first strong pieces of the base. Keep going — every brick you place builds the foundation of a champion's story!

Building Instructions (Bag 2, Book 1):

Group 20:

Step 53

Vertically place a green 1x3 jumper plate on the 3 back rows on the leftmost column. Vertically place another in front of the ppp.

Step 54

Let's make a part! Horizontally place a green 1x2 plate in front of you. place a green 1x2 plate with clip on 1 short side on the ppp, so the clip faces the right. Place a green 1x1 plate with 1x1 side stud hanging down on the left column of the ppp, so the side stud faces the back. Horizontally place a green 1x2 curved slope tile on top of your part, so it slopes to the right. Place a black 1x1 round tile upright on the back facing side stud. Bring back your main build and position it vertically in front of you so the vertical 1x2 consecutive jumper plates from the previous step are on the back left. Place your part horizontally upright on the back left facing side studs, so the clip faces the right.

Group 21:

Step 55

Let's make a part! Horizontally place a dark tan 1x10 plate in front of you. Horizontally place the left column of a green 1x2 plate with bar handle on 1 short side on the rightmost column of the ppp, so the bar handle faces the right and 1 column overhangs to the right. Repeat symmetrically to the left.

Step 56

Horizontally place 2 green 1x4 plates one to the right of the other to the right of the ppp.

Group 22:

Step 57

Horizontally place a green 1x10 plate on top of your part on the 10 right columns.

Step 58

Horizontally place a green 1x3 curved slope tile on top of your part on the 3 left columns, so it slopes to the left.

Step 59

Horizontally place a green 1x2 plate on top of your part on the 4th and 5th columns from the right. Place the 2 right columns of a green 1x6 slope tile on the ppp, so it slopes to the left.

Step 60

Bring back your main build and position it vertically in front of you so the clips face the front. position your part horizontally, so the antistuds face the back. Attach the bar handles of your part to the 2 front facing clips.

Step 61

Let's make a part! Take a green 1x6 slope tile and position it horizontally so it slopes to the left. Horizontally place a green 1x2 plate underneath the 2 right columns. Horizontally place the 3 left columns upright on the front facing side studs, so it slopes to the left and it sits to the right of another 1x6 slope tile.

Group 23:

Step 62

Let's make a sub build. Horizontally place a dark tan 1x10 plate in front of you. Horizontally place a dark orange 1x2 plate on the 2 left columns of the ppp.

Step 63

Horizontally place the right column of a nougat 1x2 slope tile with cutout on the left column of the ppp, so it slopes to the left and 1 column extends to the left. Horizontally place a green 1x2 curved slope tile to the right of the ppp, so it slopes to the right.

Group 24:

Step 64

Horizontally place a nougat 1x2 plate with a stud and a slope tile to the right of the ppp, so it slopes to the left. Horizontally place a green 1x10 plate to the right of the ppp, so 5 columns overhang to the right.

Step 65

Place a green 1x1 plate with 1x1 side stud hanging down on the leftmost column of the ppp, so the side stud faces the back. Place a green 1x1 corner slope tile on the back facing side stud of the ppp, so the right angle faces the bottom right.

Step 66

Horizontally place a green 1x2 curved slope tile on top of your sub build on the 2 left columns of visible studs, so it slopes to the left.

Step 67

Horizontally place a nougat 1x2 plate with a stud and a slope tile to the right of the ppp, so it slopes to the left.

Step 68

Place a green 1x1 plate with 1x1 side stud hanging down to the right of the ppp, so the side stud faces the front. Place a black 1x1 round tile upright on the front facing side stud.

Step 69

Horizontally place the 5 left columns of a green 1x10 plate underneath the right overhang, so 5 columns are exposed to the right.

Step 70

Place the left column of a green 1x2 curved slope tile on the rightmost column of the ppp, so it slopes to the right, and 1 column extends to the right. Horizontally place a green 1x6 slope tile to the left of the ppp, so it slopes to the right. Horizontally place another to the left of the ppp, so it slopes to the right.

Step 71

Bring back your main build and position it horizontally in front of you, so the side with 9 side studs faces the front. Horizontally place your sub build upright on the front facing side studs so the leftmost column aligns with the front left corner of your main build.

Group 25:

Step 72

Horizontally place a light blue 1x2 curved slope tile on the 2nd row from the back on the rightmost column of visible studs, so it slopes to the left. Place the back left corner of a light blue 2x2 left wedge plate underneath the right column of the ppp, so the cut corner faces the front right, and the studs face the left.

Step 73

Place a light blue 1x1 slope tile to the left of the 1x2 curved slope tile from the previous step on the 2nd row from the back, so it slopes to the left. Horizontally place the back row of a light blue 2x2 tile to the left of the ppp.

Step 74

Horizontally place a light blue 1x3 inverted half arch brick to the right of the front row of the ppp, so it slopes to the left.

Step 75

Horizontally place a light blue 1x2 curved slope tile in front of the 2 left columns of the ppp, so it slopes to the left. Place the back left corner of a light blue 2x2 left wedge plate underneath the right column of the ppp, so the cut corner faces the front right and the studs face the left.

Step 76

Place a light blue 1x1 slope tile on the 4th row from the back on the rightmost column of visible studs, so it slopes to the left, and it sits to the left of a light blue horizontal 1x2 curved slope tile. Vertically place the back row of a light blue 1x2 plate to the left of the ppp.

Step 77

Horizontally place a light blue 1x3 inverted half arch brick to the right of the front row of the ppp, so it slopes to the left.

Step 78

Vertically place the 3 right columns of a white 4x6 left wedge plate in front of the ppp, so the long straight side faces the left, and the cut corner faces the front right.

Step 79

Place a green 1x1x2/3 corner double slope tile on the back row on the 5th columns from the right of visible studs, so it sits to the left of a horizontal 1x3 jumper plate. Place another to the right and to the front of the ppp on the 2nd row from the back, so it sits in front of the left column of the left horizontal 1x3 jumper plate, so the right angle faces the back right. Place the back row of a light blue 4x4 triangular tile to the right of the ppp, so the right angle faces the front right.

Group 26:

Step 80

Horizontally place a grey 1x4 plate on the back row on the 6th through 9th columns of visible studs from the right. Vertically place a light blue 1x2 plate in front of the left column of the ppp. Vertically place another to the right of the ppp. Place a light blue 2x2 tile to the right of the ppps. Place a light blue 2x2 left wedge plate to the right of the ppp, so the cut corner faces the front right and the studs face the left. The right column should sit to the left of a 1x1x2/3 double corner slope tile and in front of the back 1x1x2/3 double corner slope tile.

Step 81

Place the right column of a light blue 2x2 left wedge plate in front of the left column of the ppp, so the studs face the left and the cut corner faces the front right. Vertically place a light blue 1x2 plate to the left of the ppp. Horizontally place another to the left of the back row of the ppp. Horizontally place a light blue 1x2 jumper plate in front of the ppp. Place the front row of a light blue 4x4 slope tile to the left of the ppp, so the right angle faces the front right.

Step 82

Place the back row of a nougat 2x2 triangular tile to the left of the front row of the ppp, so the right angle faces the back left. Vertically place a grey 1x4 plate behind the left column of the ppp. Place a grey 4x4 plate with cut corner to the right of the ppp, so the right angle faces the back left.

Step 83

Place the 3 right columns of a grey 4x4 plate with cut corner on the 4 back rows on the 3 left columns of visible studs, so the right angle faces the back right. Vertically place the 4 back rows of a dark orange 1x6 plate to the right of the ppp.

Group 27:

Step 84

Horizontally place a white 6x10 plate on the 5th through 10th rows from the front on the 4th through 13th columns from the right of visible studs. Place the 4 front rows of a white 6x6 plate with cut corner to the left of the ppp, so the right angle faces the front right. Place a white 2x2 triangular tile to the left of the 2 front rows of the ppp, so the right angle faces the front right.

Step 85

Horizontally place the left column of a light blue 1x2 curved slope tile on the rightmost column of the 4th row from the front (here, we are counting only the columns within this mentioned row, so it slopes to the left. Place the back left corner of a light blue 2x2 left wedge plate underneath the right column of the ppp, so the studs face the left and the cut corner faces the front right.

Step 86

Place a light blue 1x1 slope tile on the rightmost column of visible studs of the 4th row from the front, so it slopes to the left and sits to the left of a horizontal 1x2 curved slope tile. Horizontally place the leftmost column of a light blue 1x3 inverted half arch brick in front of the ppp, so it slopes to the left. Place the front row of a light blue left wedge plate to the left of the ppps, so the studs face the right, and the cut corner faces the back left.

Step 87

Horizontally place a light blue 1x2 right wedge tile to the left of the back row of the ppp, so the cut corner face the front right. Horizontally place a light blue 1x2 jumper plate to the left of the ppp. Place a light blue 1x1 slope tile to the left of the ppp, so it slopes to the left. Place the back row of a light blue 2x2 left wedge plate to the left of the ppp, so the studs face the right, and the cut corner faces the back left. Horizontally place a jumper plate to the right of the front row of the ppp. Then, horizontally place a light blue 1x2 right wedge tile to the right of the ppp, so the point faces the back right.

Step 88

Place a light blue 1x1 slope tile to the left of the ppp on the stud of the jumper plate, so it slopes to the left.

Step 89

Place the left column of a light blue 2x2 left wedge plate on the rightmost column of the 2 front rows (here, we are counting only the columns within these 2 mentioned rows), so the studs face the left and the cut corner faces the front right. Horizontally place a light blue 1x2 plate to the left of the back row of the ppp.

Step 90

Place a light blue 1x1 slope tile to the right of the ppp, so it slopes to the left. Horizontally place the right column of a light blue 1x2 curved slope tile in front of the ppp, so it slopes to the left. Place a light blue 1x1 slope tile to the left of the ppp, so it slopes to the front. Place the front row of a light blue 2x2 left wedge plate to the left of the ppp, so the studs face the right, and the cut corner faces the back left. Place a green 1x1x2/3 double slope corner tile to the left of the front row of the ppp, so the right angle faces the back right.

Step 91

Horizontally place a light blue 1x2 right wedge tile to the left of the ppp, so the point faces the right. Horizontally place the left column of another behind the right column of the ppp, so the point faces the right. Horizontally place a light blue 1x2 plate to the left of the ppp. Place a light blue 1x1 slope tile in front of the left column of the ppp, so it slopes to the left. Place the front row of a light blue 2x2 left wedge plate to the left of the ppp, so the studs face the right, and the cut corner faces the back left. Place a green 1x1x2/3 double slope corner tile to the left of the front row of the ppp, so the right angle faces the back right.

Step 92

Place the front row of a light blue 4x4 triangular tile to the left of the ppp, so the right angle faces the back left. Horizontally place a light blue 2x4 tile to the left of the 2 front rows of the ppp. Place the 2 front rows of a light blue 4x4 triangular tile to the left of the ppp, so the right angle faces the front right. Place a light blue 2x2 tile to the right of the 2 back rows of the ppp. Horizontally place 2 light blue 1x2 plates one in front of the other to the right of the ppp.

Group 29:

Step 93

Vertically place the back row of a dark orange 1x2 right wedge tile on the back row on the leftmost column of visible studs, so the point faces the front. Vertically place the back row of another to the right of the front row of the ppp, so it points to the front. Place a dark orange 1x1 quarter round tile behind the ppp, so the right angle faces the back right, and the rounded edge faces the front left.

Step 94

Vertically place the back row of a nougat 1x3 slope brick to the right of the ppp, so it slopes to the front. Place a green 1x1 plate with a tooth hanging down on the ppp, so the tooth faces the left.

Step 95

Horizontally place a dark orange 1x2 masonry brick to the right of the ppp, so the masonry pattern faces the front. Horizontally place a dark orange 1x4 brick to the right of the ppp.

Step 96

Vertically place a dark orange 1x2 jumper plate in front of the rightmost column of the ppp. Vertically place another to the left of the ppp. Horizontally place a dark orange 1x4 tile to the left of the back row of the ppp. Horizontally place a dark orange 2x4 tile with 2 studs in front of the ppp.

Step 97

Horizontally place a dark orange 1x6 plate to the right of the front row of the ppp. Horizontally place a dark orange 1x4 tile behind the 4 right columns of the ppp. Horizontally place a dark orange 2x4 tile with 2 studs behind the ppp. Vertically place the back row of a dark orange 1x4 tile to the right of the ppp.

Group 30:

Step 98

Place a yellow 1x1 tile on the 2nd column from the left counting the visible studs of the 5th row from the back (here we are counting only the visible columns of studs within this mentioned row). Let's make a circle. Place the leftmost column and the back row of a yellow 3x3 curved corner tile in front of the ppp, so the outward curve faces the back right. Place another symmetrically in front of the ppp. Then, place 2 another more symmetrically to the left of the ppps finishing the circle. Place a white 2x2 round tile on the center of the circle. Vertically place a yellow 1x2 left wedge tile on the 4th and 5th rows from the front on the 4th column of visible studs from the left, so the back row sits on a jumper plate, and the point faces the front.

You've strengthened the M-shaped base, giving it its full form and solid structure. Keep building — every piece you add brings the whole tribute closer to shining like a champion's story!

Building Instructions (Bag 3, Book 1):

Group 31:

Step 99

Horizontally place a blue 1x3 plate on the back row on the 2nd through 4th columns from the left of visible studs. Horizontally place another to the right of the ppp.

Step 100

Horizontally place the right column of a red 1x2 tile on the leftmost column of the ppp. Horizontally place another to the left of the ppp. Place a green 1x1 slope tile to the left of the ppp, so it slopes to the left.

Step 101

Let's make a sub build! Let's build the Rosario building. Horizontally place an orange 2x3 plate in front of you. Place 2 orange 1x1 round bricks one in front of the other on the rightmost column of the ppp.

Step 102

Place a white 1x1 brick with side stud and bottom lip on the front row on the 2nd column from the right, so the side stud points up and the antistud faces the front. place an orange 1x1 plate on top of the ppp.

Step 103

Vertically place an orange 1x2 brick on top of your sub build on the leftmost column.

Step 104

Horizontally place the leftmost column of an orange 1x3 plate on the back row of the ppp. Horizontally place an orange 1x2 rounded plate in front of the 2 right columns of the ppp.

Group 32:

Step 105

Insert the bottom bar of a reddish brown paint brush with green bristles pattern from top to bottom into the right open stud of the ppp. Place a turquoise 1x1 half cylinder tile to the left of the ppp, so the flat sides face the right and the left. Place a turquoise 1x1 slope tile to the left of the ppp, so it slopes to the left.

Step 106.1

Horizontally place a red 1x2 plate on top of your sub build on the back left corner. Place a red 1x1 short brick with a round side and a side stud on the left column of the ppp, so the side stud faces the left. Place a white 1x1 brick with side stud and bottom lip on the ppp, so the side stud faces up and the antistud faces the front. Place a red 1x1 plate on the ppp. Vertically place the bottom row of a red 1x2 tile upright on the left facing side stud.

Group 33:

Step 106.2

Horizontally place a black 1x1 short brick with a round side and a side stud on top of your sub build on the back row, so it is centered horizontally and the side stud faces the right. Place a white 1x1 brick with side stud and bottom lip on the ppp, so the side stud faces up and the antistud faces the front. Place a black 1x1 plate on the ppp. Vertically place the bottom row of a black 1x2 tile upright on the right facing side stud. Horizontally place a reddish brown 1x2 slope tile on the back row on the 2 left columns, so it slopes to the right.

Step 107

Bring back the main build so the higher wall is on the back left. Place your sub build horizontally on the 2nd and 3rd rows from the back, on the 2 left columns of visible studs, so it attaches to the studs of a horizontal 2x4 tile with 2 studs.

Step 108.1

Let's make a sub build! Let's build the Barça building. Vertically place a blue 1x3 plate in front of you.

Group 34:

Step 108.2

Stack a red 1x3 plate on the ppp.

Group 35:

Step 108.3

Stack a blue 1x3 plate on the ppp.

Step 109

Vertically place the 1x2 plate of a red 1x2 tile with 1x2 upright plate on the 2 front rows of the ppp, so the antistuds of the tile face the front.

Step 110

Place a yellow 1x1 brick with side stud and bottom blip on the back row of the ppp, so the side stud faces up and the antistud faces the right. Place another behind the ppp in the same position as the ppp.

Step 111.1

Place a blue 1x1 plate on top of your sub build on the front row.

Group 36:

Step 111.2

Place a red 1x1 plate on the ppp.

Step 112

Place a red 1x1 plate with 1x2 side studs hanging down on the back row of your sub build, so the side studs face the back.

Step 113

Place a gold 1x1 round plate on each side stud of the ppp, so there are 2 in total.

Step 114

Vertically place a light orange 1x2 ingot tile upright on the back facing side studs.

Group 37:

Step 115

Let's make a part! Place a blue 1x1 plate with 1x2 upright side studs in front of you, so the side studs face the back. Vertically place the back row of a red 1x3 plate on the ppp, so 2 rows overhang to the front.

Group 38:

Step 116

Vertically place the 2 back rows of a blue 1x3 plate underneath the front overhanging rows, so 1 row is exposed to the front.

Step 117.1

Place a blue 1x1 plate on the back row of your part.

Group 39.

Step 117.2

Place a red 1x1 plate on the ppp. Then, place a blue 1x1 tile on top of the ppp.

Step 118.1

Place a yellow 1x1 brick with side stud and bottom lip on top of your sub build on the 2nd row from the back, so the side stud faces up and the antistud faces the right.

Group 40:

Step 118.2

Place a blue 1x1 plate in front of the ppp.

Step 119

Place a yellow 1x1 brick with side stud and bottom lip in front of the ppp, so the side stud faces up and the antistud faces the right.

Step 120

Vertically place a red 1x2 plate on top of your part on the 2 front rows.

Step 121

Vertically place a blue 1x3 plate on top of your part on the 3 front rows.

Step 122

Place a gold 1x1 round plate on each back facing side stud, so there are 2 in total.

Step 123

Vertically place a light orange 1x2 ingot tile upright on the back facing side studs.

Step 124

Place a gold 1x1 round plate on top of your part on the 2nd row from the front. Place another behind the ppp.

Step 125

Place a reddish brown 1x1 round plate with horizontal bar on the ppp, so the bar faces the back. Slide a green 1x1 flower plate using the open stud from back to front through the back facing bar. Attach a green 1x1 plant flowers with open stud and small pin hole to the ppp.

Step 126

Bring back your sub build and position it vertically so the side studs face the back. Place your part vertically on top of the sub build, so 1 row overhangs to the back.

Step 127

Bring back your main build and position it horizontally in front of you, so the higher wall is on the back left. Place your sub build horizontally on the back row of your main build, so the 2 right columns of your sub build attach to the 2 left columns of visible studs of the back row.

Group 41:

Step 128

Let's make a sub build! Let's build the Paris Saint Germain building. Horizontally place a dark blue 1x3 plate in front of you. Place a dark blue 1x1 brick on top of your part on the rightmost column.

Step 129

Place a white 1x1 plate to the left of the ppp. Place a red 1x1 brick with side stud and bottom lip on the ppp, so the antistud faces the front and the side stud faces up.

Step 130

Place a dark blue 1x1 brick to the left of the ppp.

Step 131.1

Place a blue 1x1 plate on the ppp. Repeat symmetrically to the right.

Group 42:

Step 131.2

Place a white 1x1 plate to the left of the ppp.

Step 132

Horizontally place a dark blue 1x2 jumper plate on top of your sub build on the 2 right columns. Place a dark blue 1x1 round tile with upright bar to the left of the ppp.

Step 133

Place a gold 1x1 round plate on the stud of the jumper plate. Place a lime 1x1 half cylinder tile on the ppp, so the flat sides face the front and the back.

Step 134

Place a dark grey 1x1 inverted cone brick to the left of the ppp, so it attaches to the upright bar.

Step 135

Bring back your main build so it is horizontally in front of you so the higher wall is on the back left. Place your sub build horizontally on the 2nd and 3rd rows from the back on the 2 left columns of visible studs of these 2 rows, so it sits on 2 vertical 1x2 jumper plates.

Group 43:

Step 136

Let's make a sub build. Let's build a pink building representing Messi's Miami era with Inter Miami FC. Horizontally place a pink 2x4 plate in front of you. Place a pink 2x2 brick on the 2 left columns of the ppp.

Step 137

Place a white 1x1 brick with side stud and bottom lip to the right of the front row of the ppp, so the antistud faces the front and the side stud faces up. Place a pink 1x1 plate on top of the ppp.

Step 138

Vertically place a pink 1x2 brick on top of your sub build on the rightmost column.

Step 139

Place a pink 1x1 brick on top of your sub build in the front left corner. Vertically place a pink 1x2 brick behind the ppp, so 1 row overhangs to the back.

Step 140

Place a white 1x1 brick with side stud and bottom lip on the front row on the 2nd column from the left, so the antistud faces the front and the side stud faces up. Place a pink 1x1 plate on top of the ppp.

Step 141

Place a pink 2x2 plate on top of your sub build on the 2 left columns, so its back right corner overhangs.

Step 142

Vertically place 2 black 1x2 slope tiles with grille one to the right of the other on top of the ppp, so they both slope to the front.

Step 143

Place a black 2x2 tile with studs on one edge on top of your sub build on the 2 right columns, so the studs face the left. Place a white 1x1 short brick with a round side and a side stud on the back row of the ppp, so the side stud faces the right. Place a black 1x1 slope tile on the ppp, so it slopes to the right. Place a gold 1x1 round plate in front of the ppp. Then, place a black 1x1 slope tile on top of the ppp, so it slopes to the right.

Step 144

Place a reddish brown 1x1 round plate with horizontal bar upright on the right facing side stud, so the bar faces up. Slide a green 1x1 flower plate using the open stud from top to bottom through the top facing bar. Attach a green 1x1 plant flower with open stud and small pin hole to the ppp. Place a green 1x1 flower plate upright on the right facing side stud.

Step 145

Bring back your main build and position it horizontally in front of you, so the higher wall and the 2 buildings face the back. Horizontally place your pink building to the right of the 2 previous buildings, so it sits on a horizontal dark orange 2x4 tile with 2 studs.

Step 146

Locate the 6 columns with visible studs in front of the buildings on the 4th row from the back of your main build. Horizontally place 3 gold 1x2 half round plates 1 to the right of the other on the columns you found, so their straight edge face the back.

Step 147

Let's make 3 identical parts. Place a gold 1x1 star on the stud of a transparent 1L angled bar with hollow stud. You should now have 3 identical parts. Insert the bottom bar of each part into the open stud of the 3 half round plates from the previous step, so the stars face the front.

Group 44:

Step 148

Place a green 1x1 slope tile on the back row on the 4th column from the right of visible studs of this mentioned row. Place a reddish brown 1x1 round plate with horizontal bar to the right of the ppp, so the bar faces the back.

Step 149

Horizontally place the left column of a green 1x3 curved slope tile on the ppp, so it slopes to the right.

Step 150

Place a white 1x1 round plate on the rightmost column of the 7th row from the back (here, we are counting only the columns within this mentioned row), so the bar faces the front. Vertically place the front row of a white 1x2 curved slope tile on the ppp, so it slopes to the back, and it sits in front of a horizontal 1x3 inverted half arch, Bric.

Group 45:

Step 151

Let's make a sub build. Let's build a goal. Horizontally place a white 1s10 plate in front of you. Horizontally place a white 1x4 half cylinder tile on top of the ppp, so it is centered horizontally.

Step 152

Place a white 1x1 half cylinder tile to the right of the ppp, so the flat sides face the left and the right. Repeat symmetrically to the left.

Step 153

Place the back row of a half cylinder corner tile to the left of the ppp, so the right angle faces the back left and 1 row overhangs to the front. Repeat symmetrically to the right.

Step 154

Vertically place the back row of a white 1x3 plate underneath the front overhanging row of the ppp, so 2 rows are exposed to the front. Repeat symmetrically to the left.

Step 155

Vertically place the 2 back rows of a white 1x4 half cylinder tile on the leftmost column on the 2 front rows, so 2 rows are exposed to the front. Repeat symmetrically to the right.

Step 156

Vertically place a white 1x2 plate with clip on 1 short side underneath the 2 front overhanging rows of the ppp, so the clip faces the front. Repeat symmetrically to the left.

Step 157

Hold your goal upright so the clips are on the bottom. Bring back your main build and position it horizontally, so the buildings face the back left. Locate the back protruding bar on your main build. Then, locate the front facing bar from the 1x1 round plate with bar from step 150. Attach the bottom clips to these bars, so the goal faces the front left.

Step 158

Place a white 1x1x3 brick on the leftmost column of visible studs of the back row, so it sits on the Miami building. Place a white 1x1x2/3 pyramid tile on the ppp.

You've just built a whole journey of my career, piece by piece, like a true champion.

Now four buildings stand proudly in front of you: the bright orange Rosario building, where everything began; the blue and red Barcelona building, full of magic and unforgettable goals; the deep blue Paris building, marking a new chapter; and the vibrant pink Miami FC building, where the story keeps growing. And right there beside them, the clean white goal, waiting for the next shot. You've built history with your hands. Step by step, brick by brick, just like every match I ever played. And you're doing it beautifully. Take a breath, smile, and get ready for the final push. Open Bag 4 and keep building — the last chapter is waiting for you, and you're playing like a true legend!

Building Instructions (Bag 4, Book 1):

Group 46:

Step 159

Rotate your build 180 degrees, so the buildings face the front. locate 2 front facing axle holes. Insert a grey 3L axle from front to back into each axle hole, so 2L of each axle extends to the front.

Step 160

Let's make a sub build. Let's build the large number 0. Horizontally place a black 2x3 plate in front of you. Vertically place a light blue 1x2 plate on top of the ppp, so it is centered horizontally.

Step 161

Place a light blue 2x2 plate with cut corner to the left of the ppp, so the right angle faces the front right and 1 column overhangs to the left. Repeat symmetrically to the right.

Group 47:

Step 162

Let's make 2 identical parts! Vertically place a black 2x4 plate in front of you. Vertically place a light blue 2x6 plate centered vertically on the ppp. Place a black 2x2 plate with cut corner underneath the back overhanging row so the right angle faces the front right. Repeat symmetrically to the front. You should now have 2 identical parts! Bring back your sub build and position it horizontally in front of you. place the leftmost column of your sub build on the back row of one of your parts. Repeat symmetrically to the right.

Group 48.

Step 163

Horizontally place a black 2x3 plate in front of you. Vertically place a light blue 1x2 plate on top of the ppp, so it is centered horizontally. Place a light blue 2x2 plate with cut corner to the left of the ppp, so the right angle faces the back right and 1 column overhangs to the left. Repeat symmetrically to the right. Bring back your sub build and position it vertically so the open side faces the front. Place the leftmost column and the rightmost column of your part on the front row of your sub build creating the number 0.

Step 164

Vertically place a gold 1x2 tile on top of your sub build on the 2 back rows, so it is centered horizontally. Horizontally place a gold 1x2 right wedge tile to the left of the back row of the ppp, so the point faces the left. Place a gold 1x2 left wedge tile symmetrically to the right. Place the back row of a gold 2x2 corner tile with cut corner in front of the right column of the ppp, so the cut corner faces the back right. Place the right column of another in front of the left column of the ppp, so the cut corner faces the front left. Repeat the 2 placements symmetrically to the left.

Group 49:

Step 165

Vertically place a gold 1x2 tile on the leftmost column on the 2 back rows of visible studs. Vertically place a gold 1x2 plate to the right of the ppp. Vertically place a gold 1x2 tile in front of the ppp. Vertically place another to the left of the ppp. Vertically place 2 gold 1x2 tiles on the 2 right columns on the 2 back rows of visible studs. Place a gold 1x2 plate in front of the right ppp. Place a gold 1x2 tile to the left of the ppp.

Step 166

Vertically place a gold 1x2 plate on top of your 0 build on the 2 front rows, so it is centered horizontally. Horizontally place a gold 1x2 left wedge tile to the left of the front row of the ppp, so the point faces the left. Place a gold 1x2 right wedge tile symmetrically to the right. Place the front row of a gold 2x2 corner tile with cut corner behind the right column of the ppp, so the cut corner faces the front right. Place another behind and to the left of the ppp, so the right angle faces the back left. Repeat the 2 placements symmetrically to the left.

Step 167

Turn your build upside down. Place a black 2x2 plate with bottom pin connector on the 2 front rows on the 3rd and 4th columns from the right of antistuds, so the pin connector faces the front with its pin holes facing the front and the back.

Step 168

Horizontally place the right column of a black 1x2 curved inverted slope tile on the back left corner of the ppp, so it slopes to the left.

Step 169

Insert the pin end of a black 3L pin axle from front to back into the front facing pin hole, so the 2L axle end extends to the front. Vertically attach the back facing hole of a black 3L axle connector from front to back to the front facing axle. Insert a red 2L axle from front to back into the front facing axle hole of the ppp, so 1L protrudes to the front. Take a black axle and pin connector angled 90 degrees and orient it so 1 axle hole faces the back, and 1 axle hole faces the bottom front, and the pin holes of the pin connector face the left and the right. Attach the back facing axle hole onto the 1L front protruding axle.

Step 170

Bring back your main build and position it Horizontally, so the buildings face the front. Hold your 0 build vertically upright, so the antistuds face the front and the axle hole faces the left. Attach the back facing axle hole onto the front left protruding axle of your main build.

Group 50:

Step 171

Let's make a sub build. Let's build the number 1. Vertically place an upside down light blue 2x4 plate in front of you. Horizontally place a black 1x2 plate on top of the ppp on the back row of antistuds.

Step 172

Horizontally place the 2 left columns of a black 1x4 plate in front of the ppp, so 2 columns overhang to the right.

Step 173

Vertically place a black 2x6 plate in front of the 2 left columns of the ppp, so 4 rows overhang to the front. Turn your 1 build right side up, so the ppp is on the front. place the front row of a light blue 2x2 right wedge plate on the 2nd row from the back on the 2 leftmost columns, so the studs face the front, and the cut corner faces the back left, and 1 row overhangs to the back.

Step 174

Vertically place a light blue 2x6 plate on the 2 front rows of your 1 build, so 2 rows overhang to the front.

Step 175

Horizontally place a black 1x4 plate underneath the 2nd row from the front, so it is centered horizontally. Horizontally place a black 1x6 plate underneath the front row of your 1 build, so it is centered horizontally.

Step 176

Place a light blue 2x2 plate with cut corner on the 2 front rows on the 2 right columns, so the right angle faces the front left, and it sits on the 2 ppps. Repeat symmetrically to the left.

Group 51:

Step 177

Place a gold 2x2 right wedge plate on the 2 back rows of your 1 build on the 2 left columns, so the side studs face the front, and the cut corner faces the back left, and it sits on a light blue 2x2 right wedge plate. Horizontally place a gold 1x2 tile to the right of the back row of the ppp. Vertically place 2 gold 1x2 tiles 1 to the right of the other in front of the ppp. Vertically place another in front of the right ppp. Place a gold 1x2 plate to the left of the ppp. Vertically place a gold 1x2 tile in front of the ppp. Vertically place another to the right of the ppp.

Step 178

Vertically place a gold 1x2 plate in front of the ppp. Then, place a gold 1x2 tile vertically to the left of the ppp. Place the back row and the right column of a gold 2x2 corner tile with cut corner to the left of the ppp, so the cut corner faces the back left. Horizontally place a gold 1x2 tile to the right of the front row of the ppp. Repeat both parts symmetrically to the right.

Step 179

Turn your part upside down. Place a black 2x2 plate with bottom pin connector on top of your 1 build on the 2 front rows of antistuds, so it is centered horizontally and the pin connector is on the front with its pin holes facing the front and the back.

Step 180

Place the front row of 2 black 1x2 curved inverted slope tiles on the back row of the ppp, so they both slope to the back.

Step 181

Insert the pin end of a black 3L pin axle from front to back into the front facing pin hole, so the 2L axle end extends to the front. Vertically attach the back facing hole of a black 3L axle connector from front to back to the front facing axle. Insert a red 2L axle from front to back into the front facing axle hole of the ppp, so 1L protrudes to the front. Tack a black axle and pin connector angled 90 degrees and orient it so 1 axle hole faces the back, and 1 axle hole faces the bottom front, and the pin holes of the pin connector face the left and the right. Attach the back facing axle hole onto the 1L front protruding axle.

Step 182

Bring back your main build and position it Horizontally, so the buildings face the front. Hold your 1 build vertically upright, so the antistuds face the front and the axle hole faces the back. Attach the back facing axle hole onto the front right protruding axle of your main build.

Group 52:

Step 183

Rotate your build 180 degrees. Vertically place 2 consecutive white 1x2 plates with a stud and upright clip on the 2 left columns of visible studs of the 5th and 6th rows from the front (here, we are counting only the columns of visible studs within these 2 mentioned rows), so the clips are on the front.

Step 184

Place the front row of a white 2x2 curved slope tile on the back row of the 2 ppps, so it slopes to the back. Place a dark pink 2x2 triangular tile to the right of the ppp, so the right angle faces the back left. Place the right column of another behind the left column of the ppp, so the right angle faces the front right.

Step 185

Vertically place a dark pink 1x2 jumper plate to the right of the ppp. Place the left column of a dark pink 2x2 triangular tile behind the ppp, so the right angle faces the front left. Place a dark pink 1x1 plate in front of the right column of the ppp. Place the left column of a grey 2x2 corner plate in front of the ppp, so it looks like a braille letter H. Place a dark pink 2x2 triangular tile in front of the ppp, so the right angle faces the back left.

Group 53:

Step 186

Let's make a part! Horizontally place a dark pink 1x3 plate in front of you. Horizontally place a pink 1x2 plate on the 2 right columns.

Step 187

Vertically place the front row of a pink 1x2 plate on the rightmost column of the ppp, so 1 row overhangs to the back.

Step 188

Vertically place the front row of a pink 1x2 plate underneath the overhanging row of the ppp, so 1 row overhangs to the back. Vertically place the 2 front rows of a dark pink 1x4 hinge plate underneath the ppp, so the rounded hinge part faces the right. Push the 2 back rows forward so it creates a right angle.

Step 189

Horizontally place the 3 right columns of a pink 1x4 curved left slope wedge tile on the front row of your part, so it slopes to the left and 1 column extends to the left. Vertically place a pink 1x4 curved right slope wedge tile behind the rightmost column of the ppp, so it slopes to the back, and 1 row overhangs to the back.

Step 190

Horizontally place the left column of a pink 1x2 plate on the rightmost column of the hinge plate, so 1 column overhangs to the right.

Step 191

Vertically place the front row of a dark pink 1x4 plate underneath the right column of the ppp.

Step 192

Vertically place a pink 1x2 half arch brick with 1x1 plate on the two front rows of visible studs on the rightmost column, so it slopes to the back.

Step 193

push the moving part forward, so it angles 45 degree. Diagonally place the front row of a pink 1x4 curved left slope wedge tile on the front row of the ppp, so it slopes to the back, and 1 row overhangs to the back.

Step 194

Place a pink 1x1 brick with side stud on the rightmost column of the moving section, so the side stud faces the right. Insert a transparent clear 1L angled bar with hollow stud into the side open stud of the ppp.

Step 195

Horizontally place a pink 1x2x1 2/3 curved slope tile to the left of the 2 ppps so it faces the right.

Step 196

Bring back your main build and position it horizontally, so the number 10 is on the back. Hold your sub build with the ppps on the front right. Find the gray 2x2 corner plate which looks like a braille letter H and place the 3rd and 4th anti stud of your part on the front row of the 2x2 corner plate.

Group 54:

Step 197

Horizontally place a light blue 2x6 plate in front of you. Vertically place the 2 back rows of a light blue 1x3 plate on the rightmost column of the ppp, so 1 row overhangs to the front.

Step 198

Horizontally place a light blue 1x6 plate to the left of the back row of the ppp, so 1 column overhangs to the left.

Step 199

Horizontally place a light blue 2x4 plate in front of the 4 right columns of the ppp, so 1 row overhangs to the front.

Step 200

Horizontally place the back right corner of a light blue 2x4 plate underneath the left overhang of your part.

Step 201

Horizontally place the 3 right columns of a light blue 2x4 plate on the 3 left columns of the ppp, so 1 column overhangs to the left and 1 row overhangs to the back.

Step 202

Horizontally place a light blue 2x6 plate in front of the ppp, so 1 column overhangs to the left and 1 row overhangs to the front.

Step 203

Vertically place a white 1x3 tile on top of your part on the front left corner. Place the left column of a white 1x2 left wedge tile behind the ppp, so the point faces the right. Vertically place a white 1x2 left wedge tile in front of the right column of the ppp so the point faces the front. Place a white 1x2 right wedge tile vertically to the right of the ppp, so the point faces the front. Horizontally place the left column of a white 1x2 right wedge tile behind the ppp, so the point faces the left. Vertically place a white 1x3 tile in front of the right column of the ppp.

Step 204

Horizontally place a white 1x2 right wedge tile on back row of the 5th and 6th columns from the left, so the point faces the left. Place a white 1x1 half round tile in front of the right column of the ppp, so the rounded edge faces the right. Place a white 2x2 corner tile with cut corner to the left and in front of the ppp, so the cut corner faces the front left.

Step 205

Horizontally place a white 1x2 half round tile on the back row of the 4th and 5th columns from the right, so the rounded edge faces the back. Place a white 1x1 quarter round tile in front of the left column of the ppp so the right angle faces the back right and the rounded edge faces the front left. Place another to the right of the ppp, so the right angle faces the front left, and the rounded edge faces the back right. Then, place a white 1x2 half round tile in front of the 2 ppps, so the rounded edge faces the front. Repeat the 4 placements to the right of the 4 ppps.

Step 206

Place a white 1x1 round tile on the back row of the rightmost column of your part. Vertically place a white 1x2 tile in front of the ppp.

Step 207

Turn your part upside down, so the M faces the bottom right. Place a white 2x2 plate with bottom bar on top of your upside down part on the 5th and 6th columns from the left of antistuds, so the bar is on the back.

Step 208

Turn your part right side up. Bring back your main build and position it horizontally in front of you, so the number 10 faces the back. Locate 2 upright clips on the left side of your main build. Attach the bottom bar of your part to those clips. Push the front side of your part slightly down so the plaque with the name of Messi you have just attached slopes to the front.

Group 55:

Step 209

Horizontally place a black 1x2 hinge base brick on the 2 right column of visible studs of the 2nd row from the front, so it sits to the left of a blue 1x1 slope tile, and the open side faces the front. Attach a grey 2x2 hinge top plate to the ppp, so the hinge part is on the bottom back.

Step 210

Horizontally place a black and light blue 2x6 tile displaying Messi's player stats and name with a small photo of Messi on the ppp, so it is centered horizontally.

Step 211

Let's build Lionel Messi minifigure. Locate a light-blue and white pair of legs printed with white socks and black shorts featuring the number 10 in gold; a light-blue and white torso printed with the official Argentina jersey colors, including tattoos on the right arm and blue and gold captain's

armband on the left wrist. On the back of the printed shirt, read MESSI and the number 10 in black; a tan head printed with a reddish-brown beard, black eyes, and a smiling expression; and a reddish-brown hair piece. Locate a transparent blue cloud with bar ends, 2 transparent clear 1x1 round plates with open stud and the official Fifa white, black, medium blue and coral soccer ball.

Assemble your Leo Messi minifigure. Ask a sighted helper to help you check that the face is facing forward. Push

His left leg upward, so the antistud of the left foot faces the front. Then, place a transparent clear 1x1 round plate with open stud upright on the front facing antistud. Insert a bar of the transparent blue cloud with bar ends into the front facing antistud of the ppp. Next, attach the antistud of a transparent clear 1x1 round plate with open stud onto the front facing bar, so the open stud faces the front. Now, attach the hole of the blue, white black and coral soccer ball to the ppp. Messi has a running goal score position.

Step 212

Bring back your main build, so the name plaque and the stats plaque are facing the front. Messi is facing toward the goal. Attach the antistud of his right leg, the one it is not kicking, onto the hollow stud of the 1L angled bar with hollow stud from step 194.

You've just finished a truly special part of this build — a celebration of my whole journey, captured in bricks with your hands guiding every moment.

Now the large golden number 10 stands tall, shining like the number that followed me from Rosario to Barcelona, Paris, and Miami. You placed it with care, giving it the strength and pride it deserves. Beside it, you built the plaque with my name, a simple piece that carries so many memories. And next to that, the plaque with my stats, showing the goals, the matches, and the moments that shaped my career. These two plaques together feel like a tribute — and you built them beautifully. And then comes the moment of action: You positioned the Messi minifigure scoring a goal, captured right at the perfect instant. The ball is flying, the pose is full of energy, and the whole scene feels alive — like a goal that makes the stadium roar! Take a moment to look at the entire build you've created from start to finish. At the base, you built the M-shaped platform, strong and steady, with its blue and white center carrying the colors of Argentina — the place where everything began.

Around it stand the four buildings, each one representing a chapter of my career: The orange Rosario building, where the dream started; the blue and red Barcelona building, full of magic and unforgettable nights; the deep blue Paris building, marking a new adventure; the pink Miami building, where the story continues with new goals and new fans. And now, Bag 4 completes the tribute with the golden number 10, the name plaque, the stats plaque, and the Messi minifigure scoring a goal — the perfect final change to the entire display.

Congratulations on finishing your build! Would you like to inspire other blind people to build LEGO sets? Let's feature your build on our [Builders page](#). It's easy and we will do all the work! Just contact us at info@bricksfortheblind.org and together we will make it happen!

We hope you enjoyed building your LEGO set! Bricks for the Blind is able to create these text-based building instructions thanks to generous donations from our builders. If you enjoy the instructions we create, please consider making a \$5 donation at <https://www.gofundme.com/f/bricks-for-the-blind-gofundme>. Bricks for the Blind is a registered tax exempt 501(c)(3) corporation.

Please [sign up](#) for our newsletter and follow us on [Facebook](#) and [Instagram](#) to be the first to know when new instructions are available!

At the end of the instruction booklets is an advertisement for the set 43015 Lionel Messi – Soccer Legend.