

76329 Miles Morales' Mask

Adapted by Timothy Richards and tested by Peter Durieux.

Buildable Super Hero Display model for adults.

Adult Marvel enthusiasts can celebrate the iconic Spider-Verse character Miles Morales with the collectible LEGO® I Marvel Miles Morales' Mask (76329). This authentically detailed buildable Super Hero figure makes a thoughtful gift for the Super Hero in your life, whether it's a present for boyfriends, girlfriends, dads on Father's Day or moms on Mother's Day.

The buildable model stands over 7.5 in. (19 cm) tall and sits on a sturdy stand incorporating a nameplate. The satisfying building project is complemented by a digital version of the set's building instructions, which can be found on the LEGO Builder app.

The extensive LEGO Sets for Adults range offers model-builders a truly immersive and rewarding experience. Contains 487 pieces.

Adult building set – LEGO® I Marvel Miles Morales' Mask is a realistically detailed, buildable Super Hero figure that provides a rewarding model-making experience for adult Marvel enthusiasts

LEGO® I Marvel collectible to build and display – The Miles Morales' Mask sits on a sturdy stand incorporating a nameplate

Rewarding challenge – This immersive adult building project kit lets model-makers lose themselves as they construct a Marvel character that is part of comic-book history

Buildable display piece – This Super Hero building set for experienced model-makers can be displayed at home or in the office for all to admire

High-quality instructions – A coffee-table-style guide provides step-by-step building instructions, design details and more, and the LEGO® Builder app includes a digital version of the same guide

More building sets for adults – This buildable model is part of the LEGO® Sets for Adults range (each set sold separately), delivering a rewarding and immersive escape for any model-making enthusiast

The front of the box displays the front of the mask on the display stand with the Miles Morales nameplate on display. The title 'Miles Morales' is written in a unique red font to match the aesthetic of the Spider-Verse movies. On the back is another photo of the mask from a slight right angle. There are also 3 smaller photos. One image shows the mask with the height measurement (19.5 cm / 7.5 in.). The other two images are drawings of Miles from the comics; one with his mask off and a white hoodie on over his costume, the other is him in full costume swinging through the air between massive skyscrapers.

Welcome to Text-Based Building Instructions from Bricks for the Blind. Here is some helpful information on how to best use screen readers and browsers: bricksfortheblind.org/help-with-screen-readers. Before you start building, here are some terms we will be using:

- In Front of/Front: towards you.
- Behind/Back: away from you.
- Up: towards the ceiling.
- Down: towards the floor.
- Stud: the bump on a LEGO brick. Example: A 2x1 brick has two studs on it.
- Vertically: with the longest side going from front to back
- Horizontally: with the longest side going from left to right.
- Upright: pointing up towards the ceiling.
- Standing upright: The piece is perpendicular to the ground, like a wall.
- Lying flat: The piece is parallel to the ground, like a piece of toast which fell off the table.
- That one/ppp: previously placed piece.

- Plate: piece with studs.
- Tile: smooth piece without studs (unless otherwise specified)
- A jumper plate is a 1x2 plate with a single stud on top, or a 1x3 plate with only two studs on top.
- "Anti-stud" is a term for the portion of a LEGO piece which accepts studs, like the bottom of a plate or brick.
- Symmetrically: a mirror image. Example: If you place a 2x1 brick with technic connector on the front wall at the right, connector to the front, and then place another such piece symmetrically on the back wall, at the right, the technic connector of the second piece should point to the back, since it will be placed symmetrically.
- Centered-vertically: even amount of space in front of and behind piece
- Centered-horizontally: even amount of space left and right of piece.
- Row: studs lined up horizontally (left to right/side to side).
- Column: studs lined up upright or vertically (top to bottom/back to front).

For builders with low vision, or a sighted building partner may want to follow along with the printed visual instructions that come with each kit, or PDF versions are always online at LEGO.com for each set: (<https://www.lego.com/en-us/service/building-instructions/76329>). As low vision users may benefit from viewing the instructions on a personal device where they can zoom in on content and use assistive technologies to enhance the visuals.

Sorting the pieces:

To begin a successful build, it helps to sort the pieces into groups, bags, or small containers. Have a friend or family member do this in advance following the instructions below. You will see that the pieces should be sorted according to the building steps in the kit. Doing this in advance makes locating the pieces for each step easier. See below on how to sort the pieces to correspond to the steps in this set. Number the containers using letters A-Z, numbers, or meaningful names. The parts will be sorted into one or a small number of steps in the instructions. Example: Steps 1-3 means collect all the parts used in steps 1,2 and 3 and put them in one container.

This LEGO set comes with 5 bags labeled 1-5, 1 coffee table-style instruction guide, 1 sticker sheet and 1 orange building tool. Sort the pieces into groups or piles as described below. Note that where there are multiple colors of the same brick in a step, the colors will be split into 2 groups to make telling the difference easier for the builder!

LEGO includes a few spare parts in case you lose something. Set these into their own group away from the rest, in case you need them later.

Bag 1 – Building tool, display stand and the bottom structure of the mask.

- Group 1 – Steps 1 – 10
- Group 2 – Steps 11 – 16
- Group 3 – Steps 17 – 20
- Group 4 – Steps 21 – 23
- Group 5 – Steps 24 – 30

Bag 2 – The inner structure of the mask

- Group 6 – Steps 31 – 36
- Group 7 – Steps 37 – 38.1 (2 lime green 1x2 plates and 2 dark grey 1x2 plates with side studs)
- Group 8 – Steps 38.2 – 39
- Group 9 – Step 40.1 (2 lime green 1x2 plates)
- Group 10 – Steps 40.2 – 50
- Group 11 – Steps 51 – 63

Bag 3 – The top and back of the mask

- Group 12 – Steps 64 – 72 (stickers #2 – 5 for step 70)
- Group 13 – Steps 73 – 86
- Group 14 – Steps 87 – 90

Bag 4 – The sides of the mask

Group 15 – Steps 91 – 92
Group 16 – Steps 93 – 99.1 (1 black 1x3 plate)
Group 17 – The rest of step 99
Group 18 – Steps 100 – 104 (stickers #9 for step 100, #3 for step 101 and #7 for step 102)
Group 19 – Steps 105 – 112.1 (1 black 1x3 plate)
Group 20 – The rest of step 112
Group 21 – Steps 113 – 116 (Stickers #8 for step 113, #6 for step 114 and #1 for step 115)

Bag 5 – The front of the mask

Group 22 – Steps 117 – 138
Group 23 – Steps 139 – 145
Group 24 – Steps 146 – 149
Group 25 – Steps 150 – 175
Group 26 – Steps 176 – 185

At the beginning of the guide book there are some quotes and statements about Spider-Man and the lego set.

There is not only one Spider-Man:

Young Miles Morales is the latest member of the Spider-Society. Alongside a diverse group of fellow Spider-People from the 'Arachno-humanoid poly-multiverse,' he has battled villains from countless dimensions – all in addition to dealing with the regular pressures every teenager faces, of course.

"Anyone can wear the mask"
- Spider-Man

"My name is Miles Morales. I was bitten by a radioactive spider."

You can build the mask:

"We're so excited to welcome Miles Morales to our LEGO® Marvel Masks collection. Our team worked closely together to achieve optimal visual representation of the webbing and recreate every distinctive curved angle and design detail. This display model represents the character and his intricate web of fun, action-packed stories."

- The LEGO® Marvel Design Team

Now, let's build this thing!

Building Instructions:

Bag 1

Group 1 – Let's start by building the display stand for the mask.

Step 1

Locate a black 1x2 plate and lay it horizontally in front of you. Locate a black 2x3 plate and vertically attach the back row to the 1x2 plate.

Step 2

Locate a black 1x10 plate and horizontally attach the middle studs under the 2nd row of the ppp.

Step 3

Locate 2 black 1x3 plates and horizontally attach each of them to the ppp to the left and right of the 2x3 plate.

Step 4

Locate a light grey 2x2 plate and attach back 2 studs under the front row of the 2x3 plate.

Step 5.1

Locate 2 black 1x8 plates and 2 black 1x10 plates. Attach one of the 1x10 plates on top of one of the 1x8 plates so that it overhangs by 1 stud on either end. Repeat with the other 1x10 and 1x8 plates.

Step 5.2

Vertically attach the back of one of the 1x10 plates to rightmost stud of the build. Repeat symmetrically on the left.

Step 6

Locate another black 1x8 plate and black 1x10 plate. Attach the 1x8 on top of the 1x10 centered. Horizontally attach the left and right studs of the 1x10 under the front of the 2 ppps. You should now have a connected square outline.

Step 7.1

Set the main build aside for now. Locate a light grey 6x6 plate and set it down in front of you.

Step 7.2

Locate a black 4x4 technic brick with a 2x2 space in the center. The front and back should have 3 holes on the side and the left and right should have 1 hole each. Attach the brick to the center of the ppp.

Step 7.3

Locate 4 white 1x1 round plates and flip the mini build upside down. Attach a round plate to each of the 4 corners of the mini build.

Step 7.4

Flip the mini build right side up again. On the main build, find the studs in the middle of the back row and attach the center-back of the mini build to the first row of studs.

Step 8.1

Locate 3 black 4x3 slopes and 2 black 3x3 corner slopes. Attach a 4x3 slope horizontally with the slope facing backward, behind the technic brick so they are squared.

Step 8.2

Attach a corner slope to the right of the ppp so the slope faces the back-right corner of the build.

Step 8.3

Attach another 4x3 slope vertically with the slope facing to the right in front of the ppp.

Step 8.4

Attach the other corner slope in front of the ppp so the slope faces the front-right corner of the build.

Step 8.5

Attach the 3rd 4x3 slope horizontally with the slope facing forward to the left of the ppp.

Step 9.1

Locate 2 white 1x9 technic lift arms and 1 black pin. Attach the 2 lift arms together by placing the center hole of each onto either side of the pin.

Step 9.2

Locate a dark grey 4L axle with a stopper on one end. Holding the lift arms upward, place the bottom end into the gap in the center of the technic brick, at the same time slide the axle into the hole on the left side of the technic brick so that it goes through the bottom of the lift arms and through the hole on the right side of the technic brick. (This may take some time to feel but you'll know when you've got it lined up.) Now just let the lift arms lean to the back.

Step 10

Locate another black 4x3 slope and 2 more black 3x3 corner slopes. Attach them to the left side of the build symmetrically to the ones on the right.

Group 2

Step 11

Locate 4 black 2x2 corner slopes. Attach one to the back-left corner with the slope facing the corner. Repeat symmetrically for the other 3 corners.

Step 12.1

Locate 2 black 2x2 tall slopes and 2 black 1x2 plates with 2 studs on the sides. Attach each of the plates to the slopes with the side studs facing the flat side of the slopes.

Step 12.2

Attach a slope to the front horizontally-centered studs of the build so the slope faces forward and the side studs of the plate face backward.

Step 12.3

Attach the other slope symmetrically to the back of the build. You may have to lean the lift arms forward so they stay upright.

Step 13

Locate 2 black 2x2 tall slopes and 2 black 1x2 plates. Attach each plate to the tops of the slopes. Attach a slope to the center of the right side of the build so that the slope faces to the right. Repeat symmetrically for the left side.

Step 14

Locate 4 black 1x2 tall bricks and attach them to the top of each of the slopes.

Step 15

Locate a black 4x4 plate with 2x2 center cutout and attach it centered onto the ppps.

Step 16.1

Locate a black 4x4 technic brick with 3 holes in the front and back and 1 hole on each side and attach it onto the ppp.

Step 16.2

Locate a black pin and 2 blue long pins. Insert the black pin into the middle hole at the front of the technic brick so it sticks out towards you.

Step 16.3

Insert the longer end of a blue pin into the hole on the right side. Make sure it goes all the way into the top hole of the lift arm and the short end sticks out to the right. Repeat symmetrically for the left side.

Group 3 – Now let's start building the bottom foundation for the mask itself.

Step 17.1

Set aside the main build for now. Locate 3 black 2x4 plates with side holes underneath, 6 black 1x2 inverted slopes and 6 black 1x1 plates.

Step 17.2

Lay a 2x4 plate with a side hole horizontally and upside-down in front of you. Attach a 1x1 plate to the back left and right corners. Attach the back of an inverted slope vertically onto the left ppp so that the slope faces forward and repeat symmetrically on the right.

Step 17.3

Repeat this mini build 2 more times.

Step 17.4

Bring back the main build and take one of the mini builds and flip it right side up horizontally so that the slopes point forward. Attach the hole in the back to the pin sticking out the front of the main build. Repeat symmetrically to the pins on the left and right side so that the slopes point outward.

Step 18.1

Locate 2 white 1x4 plates, 2 black 1x2 plates with 2 studs on the sides and 2 black 2x3 brackets with 2x2 plates on the top and 1x2 plates on the bottom. Holding a 1x4 plate horizontally, attach 1x2 plate under the left 2 studs so that the side studs are pointing forward.

Step 18.2

Attach the other 1x2 plate with the side studs facing forward to the right of the first.

Step 18.3

Attach the 2nd 1x4 plate on top of the first one.

Step 18.4

Attach the lower part of one of the brackets under the left 2 studs of this mini build so that the top plate is behind, flush with the build. Repeat with the other bracket to the right of the first one.

Step 18.5

Rotate the mini build so that the tops of the brackets are now forward. Attach the front row of the brackets on to the horizontal-center of the back row of the main build.

Step 19

Locate a white 1x4 plate and attach it horizontally in front of the ppp.

Step 20.1

Locate a black 4x8 plate, 2 black 1x2 plates and 4 black 1x2 inverted slopes. Hold the 4x8 plate upside down horizontally and attach a 1x2 plate horizontally to the 2nd row from the front of the 4x8 on the 2 leftmost.

Step 20.2

Attach 2 inverted slopes vertically to the ppp so that the slopes overhang onto the front row of the 4x8 plate. Repeat symmetrically on the right.

Step 20.3

Flip this mini build right side up, making sure the slopes are still facing forward underneath. Attach the back of the mini build to the main build in front of the 1x4 plate from the previous step.

Group 4

Step 21

Locate 6 black 2x2 plates with 2 studs on the side. Attach 2 of them next to each other at the front horizontal center of the build so that the side studs are facing forward. Attach another to the left of the first 2 with the side studs facing left and another one the same way behind it. Repeat symmetrically for the right side.

Step 22

Locate 2 white 1x1 round plates and attach one to the front row of the build into the gap at the 2nd stud from the left. Repeat symmetrically on the right.

Step 23.1

Locate 2 black 1x4 bricks with 4 studs on the side and 3 white 1x2 bricks with 2 studs on the side. Attach a 1x2 brick with studs facing forward to the front horizontal center of the build.

Step 23.2

Attach the other 2 on either side of the first with the studs facing forward.

Step 23.3

Attach the front of a 1x4 brick vertically so the side studs are facing left to the left of the ppp.

Step 23.4

Repeat symmetrically to the right.

Group 5

Step 24

Rotate the build so the 2 studs at the front of the base now face forward. Locate a light grey 2x6 plate and vertically attach the front row to the front of the build centered horizontally.

Step 25

Locate 2 dark grey 1x2 log bricks. Attach one vertically to the front of the 2nd column from the farthest left studs. Repeat symmetrically on the right.

Step 26

Locate 2 black 1x2 plates with 2x2 studs on the side. Attach one vertically to the front-left 2 studs so that the studs on the side face outward. Repeat symmetrically to the right.

Step 27

Locate 2 white 1x2 plates with vertical clips on one end. Attach them side by side vertically with the clips facing forward to the front of the build centered horizontally.

Step 28

Locate 3 dark grey 1x2 log bricks. Attach one horizontally to the back studs of the ppps and attach the other 2 vertically to the right and left of the ppps.

Step 29

Locate 2 black 1x2 plates and attach them to the top of the vertical ppps. Locate a tan 2x2 inverted slope. Attach it with the slope facing forward to the front studs centered horizontally.

Step 30.1

Locate a black 2x3 plate and attach it vertically to the front of the ppp so that it overhangs onto the piece behind.

Step 30.2

Locate 2 dark grey 1x6 arches. Attach one horizontally behind the ppp onto the front studs of the 2 log bricks there. Attach the second arch behind the first.

Bag 2

Group 6 – Now let's start to build up the inner structure that will shape and support the mask.

Step 31

Rotate the build 90° so the studs sticking out at the bottom of the base now face to the left. Locate a light grey 1x6 brick and attach it vertically to the center of the far-right column of the build. Locate a black 1x2 slope and attach it horizontally with the slope facing the left to the 2 studs on the front-left of the build.

Step 32

Locate a light grey 6x6 plate and attach the right column to the 1x6 brick from the previous step so that it is flush on the right side and at the front and back. Locate 2 light grey 1x1 tall bricks with 2 studs on the sides. Attach them on the right side with the studs facing right, one at the front and one at the back.

Step 33

Locate 2 tan 1x2 plates and a dark grey 1x2 log brick. Attach the plates to the top and bottom of the brick. Attach this to the front of the build to the left of the ppp.

Step 34

Locate a tan 1x2 tall brick with 4 studs on the side. Attach it to the left of the ppp with the studs facing forward.

Step 35

Rotate the build so the studs at the base now face to the right. Locate a black 1x2 slope and attach it horizontally to the front 2 studs on the right so the slope faces to the right.

Step 36.1

Locate 2 tan 1x2 plates and a dark grey 1x2 log brick. Attach the plates to the top and bottom of the brick and attach this to the front of the build to the right of the tall brick on the far-left.

Step 36.2

Locate a tan 1x2 tall brick with 4 studs on the side. Attach it to the right of the ppp with the studs facing forward.

Group 7

Step 37

Locate 2 light grey 1x3 bricks and attach them horizontally to the 2x3 plate centered on the right side of the build, one behind the other.

Note: Steps #38 and #40 have been split between 2 groups to avoid confusion of similar pieces with different colours.

Step 38.1

Locate 2 dark grey 1x2 plates with studs on the sides and 2 lime green 1x2 plates. Attach the green plates to the tops of the grey plates and lay these 2 mini builds horizontally in front of you with the side studs of each facing forward.

Group 8

Step 38.2

Locate 2 tan 1x2 plates and attach them to the tops of each mini build.

Step 38.3

Locate 2 light grey 1x2 plates with 2x2 vertical studs. Attach them to the bottom of the mini builds with the vertical studs facing forward.

Step 38.4

Attach one of the mini builds with the side studs all facing forward in front of the 2 left columns of the 2x3 plate. Repeat symmetrically in the back.

Step 39.1

Locate a black 1x2 tile and attach it vertically to the 2 right-most studs.

Step 39.2

Locate a dark grey 4x4 plate and attach it centered vertically to the left of the ppp.

Step 39.3

Locate 2 tan 1x2 plates and attach one horizontally in front of the 2 left columns of the ppp. Repeat

symmetrically in the back.

Group 9

Step 40.1

Take 2 lime green 1x2 plates and attach one horizontally to the front left studs of the main build and attach the other one symmetrically to the back.

Group 10

Step 40.2

Locate 2 tan 1x2 plates and attach them to the tops of the ppps.

Step 41

Locate 3 white 1x2 tall bricks. Attach them all vertically in a line to the left column of studs between the ppps.

Step 42

Locate a dark grey 1x6 arch and attach it vertically to the right of the ppps.

Step 43

Locate a white 1x2 brick with 2 studs on the side and a tan 1x2 tall brick with 4 studs on the side. Attach the smaller brick with the studs facing forward to the studs at the front left of the build. Attach the tall brick with the studs facing forward to the right of the first brick.

Step 44

Repeat symmetrically at the back.

Step 45

Rotate the build so the studs on the base are now facing left. Locate 2 black 2x4 slopes. Attach one vertically to the left of the ppp with the slope facing left. Attach the other slope behind the first with the slope facing left.

Step 46

Locate 2 white 1x8 plates and attach one on top of the other. Attach this vertically to the top of the ppps.

Step 47.1

Locate a tan 4x6 plate and vertically attach the left side centered on the ppp.

Step 47.2

Locate 2 black 2x2 slopes and attach one to the front 2 rows on the left side of the build with the slope facing forward. Repeat symmetrically behind.

Step 48

Locate a dark grey 2x2 inverted slope and a light grey 2x6 brick. Attach the slope vertically on the left studs of the ppp so the slope faces left. Attach the 2x6 brick horizontally to the right of the slope.

Step 49

Locate 2 black 2x4 plates and attach one on top of the other. Attach this horizontally to the far-left studs. Locate a dark grey 1x2 log brick and attach it vertically to the far-right studs of the 2x6 brick.

Step 50

Locate 2 tan 1x2 tall bricks with 4 studs on the side. Attach one horizontally with the studs facing forward to the front left studs of the build. Attach the other tall brick to the right of the first with the side studs facing

forward.

Group 11

Step 51.1

Rotate the build so the studs at the base are facing to the right. Locate 2 white 1x2 tall bricks and attach one vertically to the far-left studs in the 3rd and 4th row from the front. Attach the other one vertically behind the first.

Step 51.2

Locate 2 tan 1x2 tall bricks with 4 studs on the side. Attach one vertically behind the ppps with the side studs facing left. Attach the other one symmetrically in the front.

Step 51.3

Locate another 2 tan 1x2 tall bricks with 4 studs on the side. Attach one horizontally with the studs facing forward to the front of the build to the right of the ppp. Attach the other one with the studs forward to the right of the first.

Step 52

Locate 2 light grey 2x6 plates with 4 studs on the sides. Attach one horizontally with the side studs facing forward to the front left of the build. Repeat symmetrically to the back.

Step 53

Locate 2 white 1x8 plates. Attach one vertically along the left studs of the ppps. Repeat symmetrically along the right of the ppps.

Step 54.1

Locate a tan 1x4 brick and attach it centered vertically on the ppp.

Step 54.2

Locate 2 yellow 1x1 bricks with 1 stud on the side. Attach one with the stud facing left to the front of the ppp. Repeat symmetrically to the back.

Step 54.3

Locate 2 light grey 1x1 bricks with a stud on the front and the side. Attach one in front of the ppp so that a stud is facing to the left and to the front. Repeat symmetrically in the back.

Step 55.1

Set aside the main build for now. Locate a light grey 1x5 plate and a white 1x2 jumper plate with 1 stud on top. Set the 1x5 plate down horizontally in front of you and attach the jumper plate horizontally to the studs on the right side of the 1x5 plate.

Step 55.2

Locate a black 1x3 jumper plate with 2 studs on top. Attach it horizontally to the left of the ppp.

Step 55.3

Locate a dark grey 1x2 plate with 1 stud and 1 clip on top and attach it horizontally with the clip on the left side on top of the ppp.

Step 55.4

Repeat this mini build so you have 2 identical ones.

Step 55.5

Bring the main build back and rotate it so the studs on the base are facing left. Find on the right side of the build, 1 column from the left and find a 1x2 log brick. Attach the right end of one of the mini builds horizontally to the front stud of the log brick. The clip that's on top of the mini build should be facing to the left. Attach the 2nd mini build behind the first, facing the same way.

Step 56

Locate a tan 2x2 jumper plate with 2 studs on top. With the studs facing the left side, attach the jumper plate to the right of the clip plates from the previous step.

Step 57

Locate 2 black 1x1 bricks and 2 1x4 bricks with 4 studs on the side. Attach a 1x1 brick to the front-left of the build. Attach a 1x4 brick horizontally with the side studs facing forward to the right of the 1x1 brick. Repeat symmetrically to the back.

Step 58

Locate 2 white 1x2 jumper plates with a stud on top. Attach one horizontally to the right of the front clip in the middle of the build. Attach the other one horizontally behind the first.

Step 59

Locate 2 black 2x2 plates with 2 studs on the sides. Attach one to the 3rd and 4th row on the rightmost columns of the build so that the side studs are facing right. Attach the other one behind the first with the studs facing right as well.

Step 60

Locate 4 white 2x2 corner plates. Attach 2 of them to each other and attach this to the build at the front right corner in a braille letter "J" pattern. Repeat symmetrically at the back.

Step 61.1

Locate 2 light grey 1x3 plates and attach them to each other.

Step 61.2

Locate a black 1x2 slope with 2/3rds cutout in the back. With the plates horizontal, attach the back of the slope to the left stud so they slope faces to the left.

Step 61.3

Attach this mini build horizontally to the front left of the main build with the slope still facing the left.

Step 61.4

Locate 2 more light grey 1x3 plates and another black 1x2 slope with 2/3rds cutout in the back and repeat symmetrically to the back of the build.

Step 62

Locate a lime green 1x2 plate and a dark grey 1x2 log brick. Attach the brick to the top of the plate and attach this vertically to the 2 studs on top and in the middle of the build to the right of the clips.

Step 63.1

Rotate the build so the studs on the base are facing to the right. Locate 2 black 1x4 bricks with 4 studs on the side. Attach one horizontally to the front left so the side studs are facing forward.

Step 63.2

Repeat symmetrically to the back.

Step 63.3

Locate 3 white 1x2 bricks with 2 studs on the side. Attach each of them vertically along the left side of the build, with the side studs facing left, between the 2 ppps.

Bag 3

Group 12 – Now let's assemble to the top of the mask.

Step 64

Set the main build aside for now. Locate a black 4x8 plate and 2 medium azure 2x3 plates. Place the 4x8 plate horizontally in front of you. Attach a 2x3 plate vertically to the back 3 rows 3 columns from the left. Attach the 2nd one to the right of the first.

Step 65

Locate 2 black 1x2 plates with 2 studs on the sides. Attach them with the side studs facing forward in front of the ppps.

Step 66

Locate 2 black 2x4 plates and attach one vertically to the horizontal center of the mini build. Attach the 2nd one to the top of the first.

Step 67

Locate 4 black 2x3 slopes and attach one horizontally with the slope facing left, to the left of the front of the ppps. Attach another slope behind the first facing the same way. Repeat symmetrically to the right.

Step 68

Locate 2 black 1x2 wedges. Attach one wedge horizontally to the right 2 side studs at the front of the mini build so that the wedge points downward. Attach the other wedge the same way to the left of the first.

Step 69

Locate a black 1x2 tile and a black 2x4 tile. Attach the 1x2 tile horizontally to the back row of the build. Attach the 2x4 tile vertically in front of the 1x2 so that the front overhangs on top of the wedges.

Step 70.1

Locate stickers #2 - #6. Note: Stickers #3 and #6 have duplicates but you only need 1 of each for this step. These stickers display the web design of Miles' mask. You may want to ask a sighted friend to assist in applying the stickers to ensure the web design lines up.

Step 70.2

Locate sticker #2 and apply it horizontally to the slope on the front left of the mini build. The longer line should point to the right.

Step 70.3

Locate sticker #3 and apply it horizontally to the slope behind the first one. The longer line should again point to the right and the line that points down should connect with a line pointing up from the first sticker.

Step 70.4

Locate sticker #4 and apply it vertically to the 2x4 tile in the front center of the mini build. The smaller lines should curve slightly downward and connect with the line on the sticker to the left.

Step 70.5

Locate sticker #5 and apply it horizontally to the slope on the front right of the mini build. The lines should be symmetrical to the sticker on the front left slope.

Step 70.6

Locate sticker #6 and apply it horizontally to the slope behind the previous one. The lines should be symmetrical to the sticker on the back-left slope.

Step 71

Bring back the main build, making sure the studs on the base are still facing right. Rotate the mini build so that the wedges now face to the right. Attach the mini build to left column of studs on the main build so that the builds are flush on the left side and the front and back.

Step 72

Set aside the main build again. Locate a black 2x2 plate with 2 studs on the side and place it in front of you

with the side studs facing forward. Locate a tan 1x2 plate and attach it horizontally to the studs on the back of the ppp.

Group 13 – Now let's build the back of the mask.

Step 73

Locate a white 1x4 plate and attach it horizontally centered on the ppp.

Step 74

Locate 4 black 1x2 plates and attach 2 of them together. Take this and vertically attach the back stud under the left side of the ppp that overhangs. Repeat symmetrically to the right.

Step 75

Locate 2 black 1x2 tiles and attach them horizontally beside each other to the front row of studs on the mini build.

Step 76

Locate 2 black 2x2 plates with 2 studs on the sides. Attach each of them with the side studs facing forward to the row of studs behind the ppps so that they overhang the back of the mini build.

Step 77

Locate 3 black 1x2 wedges. Attach one horizontally to the 2 studs on the front of the mini build so that the wedge points upward. Attach the other 2 wedges the same way to the 4 studs on the front of the pieces behind.

Step 78

Rotate the mini build so the wedges now face the back. Locate a tan 1x4 brick and attach it horizontally underneath the studs at the front. Locate a white 1x4 plate and attach it horizontally to the top of the studs at the front.

Step 79

Bring back the main build and rotate it so the studs at the base are facing backward. Flip the mini build up so that the wedge is on top. Attach the bottom row of the mini build to the 4 studs on the back of the main build that are near the top, below a row of 6 studs.

Step 80

Locate 6 black 2x6 half rounded plates. Attach 3 of the plates on top of each other. Flip these plates vertically upright so the flat edge is on the left. Attach this to the right of the ppp so that the tops are flush. Repeat symmetrically to the left.

Step 81

Locate 2 dark grey 1x2 log bricks and attach them horizontally under the ppps. They should be flush with the outside edges.

Step 82.1

Locate a black 2x2 plate with studs on the side and place it in front of you with the side studs facing forward. Locate a white 1x4 plate and horizontally attach the left 2 side to the back 2 studs of the 2x2 plate.

Step 82.2

Locate another black 2x2 plate with studs on the front and attach it to the right of the first one under the 1x4 plate.

Step 82.3

Locate a black 2x4 plate and attach it horizontally on top of the mini build.

Step 82.4

Locate 2 black 1x2 wedges. Attach one horizontally to the right 2 side studs on the front of the mini build so that the wedge points upward. Attach the 2nd wedge to the left of the first pointing the same way.

Step 82.5

Flip the mini build up so the wedges are now on the bottom and the studs are facing forward. Attach the top row of the mini build to the center of the row of 6 studs at the bottom of the front of the main build.

Step 83

Locate 6 more black 2x6 half round plates and attach 3 of them to each other. Flip these plates vertically so the flat edge is on the left and attach the bottom 2 rows to the right of the ppp. Repeat symmetrically to the left.

Step 84

Locate 4 more black 2x6 half round plates and attach 2 of them together. Flip these plates vertically so the flat edge is on the left. Attach the bottom row to the log brick on the right above the ppp. Repeat symmetrically to the left.

Step 85.1

Locate 2 black 1x2 plates, a black 2x6 plate and a black 2x6 half round plate. Flip the round plate horizontally upward with the flat edge on the bottom and attach it under the wedges at the top of the main build.

Step 85.2

Flip the 2x6 plate horizontally upward and attach it under the ppp.

Step 85.3

Flip a 1x2 wedge vertically upward and attach it under the far-left column of the ppp. Repeat symmetrically to the right.

Step 86.1

Locate a dark grey 2x2 plate and a black 1x2 plate. Attach the 1x2 plate to the back 2 studs of the 2x2 plate.

Step 86.2

Locate a black 2x4 slope. Attach the back of the slope vertically with the slope facing forward to the 1x2 plate. Take this mini build and flip it vertically upright with the slope going down. Attach the top left corner below the ppp on the right side. Repeat symmetrically on the left.

Group 14

Step 87

Locate 2 black 1x3 tiles and 2 black 1x1 rounded corner tiles. Attach a 1x3 tile vertically above the right side of the ppp on the right side of the build. Attach a 1x1 tile above the first tile with the corner facing down and left. Repeat symmetrically on the left side.

Step 88

Locate a tan 1x2 plate and 2 black 1x3 slopes. Attach the 1x2 plate horizontally centered in between the 2 corner tiles from the previous step. Attach the 2 slopes horizontally under the 1x2 tile so that the slopes face outward.

Step 89

Locate 2 black 3x3 rounded corner wedges. They both have some of the masks red webbing design. Attach one above the ppp on the right so that the rounded corner of the wedge faces up and right and sits on the right stud of the 1x2 plate. Repeat symmetrically on the left.

Step 90

Locate a black 6x8 curved shell and attach it vertically with the studs at the top under the 2 1x3 slopes from a previous step.

Bag 4

Group 15 – Now let's assemble the right side of the mask.

Step 91

Set the main build aside for now. Locate a black 2x8 plate and place it upside-down horizontally in front of you. Locate a black 1x2 plate and attach it vertically to the leftmost column of the ppp. Locate a light grey 1x2 plate with a ball clip at the end and attach it vertically with the ball clip facing forward to the right of the ppp.

Step 92

Locate a black 3x3 plate and attach it to the right of the ppp so that it overhangs the front of the mini build. Locate 2 dark grey 1x2 plates with vertical clips on the end. Attach one of them to the right of the ppp so the clip overhangs the front. Place the other to the right of the first facing the same way.

Group 16

Step 93

Locate a tan 1x2 plate and attach it horizontally to the right of the ppp in the back so that it overhangs to the right. Locate a black 2x2 right wedge plate and attach it horizontally under the ppp so that the wedge slopes to the right.

Step 94

Flip the mini build up so that the wedge is now on the left and all the clips still face forward. Locate 2 black 2x2 jumper plates with 2 studs on top and attach one to the far-right of the mini build with the studs along the back. Attach the other to the left of the first facing the same way.

Step 95.1

Locate a light grey 1x5 plate and set it horizontally in front of you. Locate a white 1x4 plate and a black 3x3 plate and attach the 1x4 plate horizontally to the right side of the 1x5 plate leaving 1 open stud on the left.

Step 95.2

Attach the back row of the 3x3 plate to the 3 rightmost columns of the ppp then take this and attach the front row of the 3x3 plate to the left of the jumper plates on the mini build.

Step 96.1

Locate 2 black 2x3 right wedge plates and attach them to each other.

Step 96.2

Keeping the studs on the left side, locate a black 2x2 right wedge plate and attach it to the bottom 2 studs of the 2x3 wedge plates. Now attach the wedges horizontally to the rightmost columns of the mini build with the studs along the back.

Step 97

Bring back the main build and rotate it so the studs on the base face to the right. Rotate and flip the mini build vertically so that so that the ppps are on the front at the top of the mini build. Feel from top to bottom on the main build. The first row has 4 studs. Going down, you will find a row of 5 studs, then more rows of 4 studs. Place the top row of anti-studs on the mini build onto the top row of 4 studs below the row of 5 studs on the 2 rightmost columns.

Step 98.1

Locate a dark grey 2x3 brick and 2 black 1x3 plates. Lay the brick horizontally in front of you and attach a plate horizontally to the back row of studs and attach the 2nd plate on top of the first.

Step 98.2

Locate a black 1x2 brick and vertically attach the back of it to the front-right stud of the mini build so it overhangs the front. Locate a black 1x3 slope and attach it horizontally to the left of the ppp so the slope overhangs to the left.

Step 98.3

Locate another dark grey 2x3 brick and horizontally attach the back-right stud under the overhang of the brick in front. Locate a black 2x2 slope and rotate it so the slope faces left, then attach the front stud under the overhang of the slope on the left.

Step 98.4

Locate a black 1x1 wedge and attach it to the back stud of the ppp so that the wedge faces left.

Step 98.5

Flip this mini build up so that the studs now face you and the slopes point to the left. Attach it to the main build to the left of the mini build from the previous step so that the tops of both mini builds are flush.

Step 99.1

Locate a black 1x3 plate and lay it vertically in front of you.

Group 17

Step 99.2

Locate a yellow 1x3 plate and attach it horizontally centered to the back stud of the ppp. Locate a black 1x3 slope and vertically attach the back of it with the slope facing forward to the horizontal center of the ppp.

Step 99.3

Locate 2 black 3x3 rounded corner plates. Hold one with the rounded corner facing forward and right and attach the back-left stud under the right side of the mini build. Repeat symmetrically on the left.

Step 99.4

Locate 2 black 3x3 rounded corner wedges which have some of the red web design on them. Attach one with the rounded corner facing forward and right and attach it onto the ppp on the right side of the mini build. Repeat symmetrically on the left.

Step 99.5

Rotate the mini build so the rounded parts are at the back and the front is now flat. Now, flip the mini build up so the rounded parts face upward and the flat part is facing downward. Attach this mini build to the main build just above the mini builds that were attached previously. This one should overlap to the right.

Group 18

Step 100.1

Locate a black 2x3 plate and lay it horizontally in front of you. Locate a black 1x3 plate and attach it horizontally to the back row of the 2x3.

Step 100.2

Locate a black 1x4 slope and with the slope facing forward, vertically attach the back of the slope to the back-left of the ppp.

Step 100.3

Locate a black 2x4 slope and Sticker #9. With the slope vertically facing forward, apply the sticker so the long curvy red line is on the left. Attach the slope to the mini build to the right of the ppp. Make sure the slopes are both facing forward.

Step 100.4

On the main build, find the row of 4 studs that is 4 rows down from the top. Take the mini build and flip it up so that the slopes now point down and attach the top to the 2 right studs on the main build.

Step 101.1

Locate a black 1x4 plate and lay it horizontally in front of you. Locate a black 1x3 slope and with the slope facing forward, vertically attach the front of the slope to the far-left stud of the plate.

Step 101.2

Locate a black 2x3 slope and sticker #3. Apply the sticker to the slope so that the longer line is to the left with the slope facing forward. Attach the front of the slope to the right of the ppp.

Step 101.3

Take this mini build and flip it up so that the plate is behind the slopes at the bottom. Attach it to the main build under the slopes from the previous step.

Step 102.1

Locate a black 3x8 right curved shell and sticker #7. Lay the slope down horizontally with the studs at the back-left corner.

Step 102.2

Apply the sticker horizontally in front of the studs with the flat end on the left. This sticker has more of the red web design.

Step 102.3

Locate a black 2x6 right curved wedge and attach it horizontally with the studs at the back left, under the front left of the 3x8 shell.

Step 102.4

On the main build, find the studs 3 rows down to the left. Flip the mini build up so that the studs are at the top-right facing forwards. Attach the top-right of the mini build to the 2 left columns of studs on the main build in the spot you found.

Step 103

Locate a black 2x2 slope and attach it with the slope facing up to the top right studs on the front of the build. Locate a black 1x2 slope and with the slope facing up attach it to the left of the ppp.

Step 104

Set aside the main build for now. Locate a black 2x8 plate and lay it upside-down horizontally in front of you. Locate a black 1x2 plate and attach it vertically to the rightmost columns of the 2x8 plate. Locate a light grey 1x2 plate with a ball clip on the end. Attach it vertically with the clip facing forward to the left of the ppp.

Group 19 - Now let's assemble the left side of the mask.

Step 105

Locate a black 3x3 plate and attach the back 2 rows to the left of the ppp. Locate 2 dark grey 1x2 plates with clips on the end. Attach them vertically beside each other with the clips facing forward, to the left of the ppp.

Step 106

Locate a tan 1x2 plate and horizontally attach the right stud to the left of the ppp at the back row. Locate a black 2x2 left wedge plate and attach it horizontally with the wedge on the left in front of the ppp.

Step 107

Locate 2 black 2x2 jumper plates with 2 studs on the top. Flip the mini build horizontally so the 2x8 plate is

now at the top and the clips are all facing forward. Attach a jumper plate with the studs at the back to the 2 leftmost columns of the 2x8 plate. Attach the other one to the right of the first facing the same way.

Step 108.1

Locate a light grey 1x5 plate and set it horizontally in front of you. Locate a white 1x4 plate and a black 3x3 plate and attach the 1x4 plate horizontally to the left side of the 1x5 plate leaving 1 open stud on the right.

Step 108.2

Attach the back row of the 3x3 plate to the 3 leftmost columns of the ppp then take this and attach the front row of the 3x3 plate to the right of the jumper plates on the mini build.

Step 109.1

Locate 2 black 2x3 left wedge plates and attach them to each other.

Step 109.2

Keeping the studs on the right side, locate a black 2x2 left wedge plate and attach it to the bottom studs of the 2x3 wedge plates. Now attach the wedges horizontally to the leftmost column of the mini build with the studs along the back.

Step 110

Bring back the main build and rotate it so the studs on the base face to the left. Rotate and flip the mini build vertically so that so that the ppps are on the front at the top of the mini build. Feel from top to bottom on the main build. The first row has 4 studs. Going down, you will find a row of 5 studs, then more rows of 4 studs. Place the top row of anti-studs on the mini build onto the top row of 4 studs below the row of 5 studs on the 2 leftmost columns.

Step 111.1

Locate a dark grey 2x3 brick and 2 black 1x3 plates. Lay the brick horizontally in front of you and attach a plate horizontally to the back row of studs and attach the 2nd plate on top of the first.

Step 111.2

Locate a black 1x2 brick and vertically attach the back of it to the front-left stud so it overhangs the front. Locate a black 1x3 slope and attach it horizontally to the right of the ppp so the slope overhangs to the right.

Step 111.3

Locate another dark grey 2x3 brick and horizontally attach the back-left stud under the overhang of the brick in front. Locate a black 2x2 slope and rotate it so the slope faces right, then attach the front stud under the overhang of the slope on the right.

Step 111.4

Locate a black 1x1 wedge and attach it to the back stud of the ppp so that the wedge faces right.

Step 111.5

Flip this mini build up so that the studs now face you and the slopes point to the right. Attach it to the main build to the right of the mini build from the previous step so that the tops of both mini builds are flush.

Step 112.1

Locate a black 1x3 plate and lay it vertically in front of you.

Group 20

Step 112.2

Locate a yellow 1x3 plate and attach it horizontally centered to the back stud of the ppp. Locate a black 1x3 slope and vertically attach the back of it with the slope facing forward to the horizontal center of the ppp.

Step 112.3

Locate 2 black 3x3 rounded corner plates. Hold one with the rounded corner facing forward and right and

attach the back-left stud under the right side of the mini build. Repeat symmetrically on the left.

Step 112.4

Locate 2 black 3x3 rounded corner wedges which have some of the red web design on them. Attach one with the rounded corner facing forward and right and attach it onto the ppp on the right side of the mini build. Repeat symmetrically on the left.

Step 112.5

Rotate the mini build so the rounded parts are at the back and the front is now flat. Now, flip the mini build up so the rounded parts face upward and the flat part is facing downward. Attach this mini build to the main build just above the mini builds that were attached previously. This one should overlap to the left.

Group 21

Step 113.1

Locate a black 2x3 plate and lay it horizontally in front of you. Locate a black 1x3 plate and attach it horizontally to the back row of the 2x3.

Step 113.2

Locate a black 1x4 slope and with the slope facing forward, vertically attach the back of the slope to the back-right of the ppp.

Step 113.3

Locate a black 2x4 slope and Sticker #8. With the slope vertically facing forward, apply the sticker so the long curvy red line is on the right. Attach the slope to the mini build to the left of the ppp. Make sure the slopes are both facing forward.

Step 113.4

On the main build, find the row of 4 studs that is 4 rows down from the top. Take the mini build and flip it up so that the slopes now point down and attach the top-right of the mini build to the 2 left studs on the main build.

Step 114.1

Locate a black 1x4 plate and lay it horizontally in front of you. Locate a black 1x3 slope and with the slope facing forward, vertically attach the front of the slope to the far-right stud of the plate.

Step 114.2

Locate a black 2x3 slope and sticker #6. Apply the sticker to the slope so that the longer line is to the right with the slope facing forward. Attach the front of the slope to the left of the ppp.

Step 114.3

Take this mini build and flip it up so that the plate is behind the slopes at the bottom. Attach it to the main build under the slopes from the previous step.

Step 115.1

Locate a black 3x8 left curved shell and sticker #1. Lay the shell down horizontally with the studs at the back-right corner.

Step 115.2

Apply the sticker horizontally in front of the studs with the flat end on the right. This sticker has more of the red web design.

Step 115.3

Locate a black 2x6 left curved wedge and attach it horizontally with the studs at the back right, under the front right of the 3x8 shell.

Step 115.4

On the main build, find the studs 3 rows down to the right. Flip the mini build up so that the studs are at the

top-left facing forwards. Attach the top-left of the mini build to the 2 right columns of studs on the main build in the spot you found.

Step 116

Locate a black 2x2 slope and attach it with the slope facing up to the top left studs on the front of the build. Locate a black 1x2 slope and with the slope facing up attach it to the right of the ppp.

Bag 5

Group 22 – Now let's assemble the cheeks of the mask.

Step 117

Set the main build aside for now. Locate a black 3x3 corner wedge plate and set it down with the flat corner facing the back right. Locate a black 1x2 plate and attach it horizontally to the front right of the wedge plate.

Step 118

Locate a black 2x2 corner wedge tile and attach it behind the ppp in a braille "H" pattern. Locate a black 2x2 left wedge plate with the studs at the front attach it to the back-left corner of the mini build.

Step 119

Locate a black 3x3 corner plate with 2x2 cutout. In a braille "D" pattern, attach the back-right stud under the front left of the ppp.

Step 120

Locate a black 1x2 plate and vertically attach the front to the 2nd stud from the left of the mini build. Locate a black 2x2 right wedge plate with the studs on the right and attach the front to the left of the ppp.

Step 121.1

Locate a black 2x2 plate with 2 studs on the front. Locate a black 1x2 plate and horizontally attach it to the back row of the 2x2 plate.

Step 121.2

Locate a black 1x3 plate and vertically attach the front of it to the left 2 studs of the plates. Take this and attach it to the stud on the left of the mini build on the 2nd row from the back.

Step 122

Locate a black 1x2 slope and vertically attach it with the slope facing backwards to the back 2 studs on the left of the mini build. Locate a black 2x2 corner wedge tile. With the flat corner facing the back-right attach it to the right of the ppp.

Step 123

Locate a black 2x4 curved slope which has some red webbing design. Attach it horizontally with the slope facing right to the front-left of the mini build.

Step 124.1

Flip the mini build over so the side studs are now at the back left. Locate 2 dark grey 1x2 plates with a bar on the end. Attach one vertically with the bar facing forward to the 2nd row from the back on the left of the mini build. Attach the other one to the right of the first facing the same way.

Step 124.2

Locate a black 1x3 plate and horizontally attach it to the right of the back row of the ppp.

Step 125.1

Locate 2 dark grey 2x2 inverted slopes. Attach one with the slope facing the back to the back left of the mini build. Attach the 2nd one to the right of the first so the slope faces back as well.

Step 125.2

Locate 2 black 1x2 inverted slopes and attach one to the right of the ppp with the slope facing backward. Attach the other one horizontally with the slope facing to the right in front of the 2x2 slopes at the 2nd and 3rd columns from the left.

Step 126.1

Flip the mini build back over so the side studs are at the front left again. Locate a black 1x4 plate and a black 1x2 plate. With the 1x4 plate horizontal, attach the 1x2 horizontally to the middle 2 studs.

Step 126.2

Locate a 1x4 curved slope with a 1x2 cutout on the bottom and attach it horizontally on top of the 1x4 plate. Flip this on the side so the slope is facing forward and attach the back left to the studs on the front of the mini build.

Step 127

Bring back the main build and rotate it so the studs on the base face to the left. Rotate and flip the mini build so the ppp is vertical on the left side and the bar plates are at the back. Attach the mini build by connecting the bar plates to the clips near the bottom of the main build.

Step 128

Set the main build aside for now. Locate a black 3x3 corner wedge plate and set it down with the flat corner facing the back left. Locate a black 1x2 plate and attach it horizontally to the front left of the wedge plate.

Step 129

Locate a black 2x2 corner wedge tile and attach it behind the ppp in a braille "J" pattern. Locate a black 2x2 right wedge plate with the studs at the front attach it to the back-right corner of the mini build.

Step 130

Locate a black 3x3 corner plate with 2x2 cutout. In a braille "F" pattern, attach the back-left stud under the front right of the ppp.

Step 131

Locate a black 1x2 plate and vertically attach the front to the 2nd stud from the right of the mini build. Locate a black 2x2 left wedge plate with the studs on the left and attach the front to the right of the ppp.

Step 132.1

Locate a black 2x2 plate with 2 studs on the front. Locate a black 1x2 plate and horizontally attach it to the back row of the 2x2 plate.

Step 132.2

Locate a black 1x3 plate and vertically attach the front of it to the right 2 studs of the plates. Take this and attach it to the stud on the right of the mini build on the 2nd row from the back.

Step 133

Locate a black 1x2 slope and vertically attach it with the slope facing backwards to the back right 2 studs of the mini build. Locate a black 2x2 corner wedge tile. With the flat corner facing the back-left attach it to the left of the ppp.

Step 134

Locate a black 2x4 curved slope which has some red webbing design. Attach it horizontally with the slope facing left to the front-right of the mini build.

Step 135.1

Flip the mini build over so the side studs are now at the back right. Locate 2 dark grey 1x2 plates with a bar on the end. Attach one vertically with the bar facing forward to the 2nd row from the back on the right of the

mini build. Attach the other one to the left of the first facing the same way.

Step 135.2

Locate a black 1x3 plate and horizontally attach it to the left of the back row of the ppp.

Step 136.1

Locate 2 dark grey 2x2 inverted slopes. Attach one with the slope facing the back to the back right of the mini build. Attach the 2nd one to the left of the first so the slope faces back as well.

Step 136.2

Locate 2 black 1x2 inverted slopes and attach one to the left of the ppp with the slope facing back. Attach the other one horizontally with the slope facing to the left in front of the 2x2 slopes at the 2nd and 3rd columns from the right.

Step 137.1

Flip the mini build back over so the side studs are at the front right again. Locate a black 1x4 plate and a black 1x2 plate. With the 1x4 plate horizontal, attach the 1x2 horizontally to the middle 2 studs.

Step 137.2

Locate a 1x4 curved slope with a 1x2 cutout on the bottom and attach it horizontally on top of the 1x4 plate. Flip this on the side so the slope is facing forward and attach the back right to the studs on the front of the mini build.

Step 138

Bring back the main build and rotate it so the studs on the base face to the right. Rotate and flip the mini build so the ppp is vertical on the right side and the bar plates are at the back. Attach the mini build by connecting the bar plates to the clips near the bottom of the main build.

Group 23 – Now let's add the bottom part of the front of the mask.

Step 139

Set the main build aside for now. Locate a black 2x6 plate and lay it horizontally upside down in front of you. Locate a white 2x2 plate and attach it to the left side of the ppp.

Step 140

Locate a light grey 2x3 plate with a bar above it and attach it horizontally to the right of the ppp.

Step 141

Locate a black 2x2 plate with 2 studs on the side. With the side studs facing to the right, attach the right column to the furthest left column of the mini build.

Step 142

Locate a black 6x8 curved shell and horizontally with the studs on the right lay it upside-down in front of you. Attach the mini build to the center of the shell to the far-right.

Step 143

Locate a black 2x2 plate with 2 studs on the side and attach the right column it with the studs facing to the left to the leftmost column of the mini build.

Step 144

Locate a red 1x2 plate and a black 1x2 brick with 2 studs on the side and attach the brick to the top of the plate. Flip this so the top of the brick faces to the left and the side studs are facing down. Attach them to the left column of the ppp.

Step 145

Locate 2 black 1x2 tiles with a bar on top. Set one down with the bar vertical on the left side and the flat side at the back. Attach it to the front 2 studs on the left side of the mini build. Repeat symmetrically behind.

Group 24

Step 146

Locate a black 1x2 plate and a black 1x2 inverted slope. Set the plate horizontally upside down and attach the back of the slope to the left side of the plate so that the slope faces forward. Attach this to the front-right corner of the mini build.

Step 147

Locate a black 1x2 plate and a black 1x2 inverted slope and repeat the last step symmetrically to the back-right of the mini build.

Step 148

Locate a black 1x4 plate and attach it vertically centered to the right column of the mini build.

Step 149

Bring back the main build. Flip the mini build so the 2 bars are at the top and the 6x8 shell is facing to the right. Attach the mini build by the bar on the left in the center to the clip near the bottom on the right of the main build.

Group 25 – Now let's build the eyes of the mask.

Step 150

Set aside the main build for now. Locate a black 2x4 left wedge plate and lay it horizontally with the studs at the front. Locate a red 2x2 corner plate. and attach it to the right 2 studs of the wedge plate in a braille "F" pattern.

Step 151

Locate a red 2x2 corner plate and attach it symmetrically on the left in a braille "D" pattern.

Step 152

Locate a red 1x4 plate and attach it horizontally to the left 3 studs of the build so it overhangs by 1 stud on the left.

Step 153

Locate a red 1x2 tile and horizontally attach it to the ppp centered horizontally. Locate a red 1x2 left wedge curved slope tile and attach it horizontally with the longer side at the back to the left of the ppp.

Step 154

Locate a red 1x2 plate and set it down horizontally. Locate a red 1x4 slope and with the slope facing horizontally to the right, attach the plate under the right side. Take this and attach the left side of the slope to the 2 studs on the back-right of the mini build.

Step 155

Locate a red 4x8 half circle plate and set it down horizontally with the flat edge to the back. Attach the 2 studs in the front of the mini build on to the back center of the half circle plate.

Step 156

Locate 2 white $\frac{1}{4}$ round wedges. Hold one with the round edge facing forward and right. Attach the back-left corner of the wedge to the stud that's on the right of the 2 studs above the back row of the mini build. Repeat symmetrically on the left.

Step 157

Locate 2 red 4x4 round corner tiles. Attach one to the right of the ppp in a braille letter "J" pattern. Repeat symmetrically to the left.

Step 158

Flip the mini build upside-down with the round edge at the back. Locate a red 2x2 left wedge plate and with the studs at the back attach it to the front left of the mini build.

Step 159

Locate a dark grey 2x4 plate and attach it vertically to the vertical and horizontal center of the mini build. Locate a dark grey 2x2 inverted round plate and attach it to the right of the front 2 rows of the ppp.

Step 160

Locate a light grey 2x2 plate with a ball on one side. Attach it with the ball facing to the left centered vertically to the 2x4 plate from the previous step.

Step 161

Locate 2 black 1x2 inverted slopes. Attach one vertically with the slope facing forward to the front-right of the ppp. Repeat symmetrically to the back.

Step 162

Bring the main build back. Flip the mini build up so the round edge is at the bottom and the ball plate is on the back. Attach the ball of the mini build to the ball clip near the top right of the main build.

Step 163

Set aside the main build for now. Locate a black 2x4 right wedge plate and lay it horizontally with the studs at the front. Locate a red 2x2 corner plate and attach it to the left 2 studs of the wedge plate in a braille "D" pattern.

Step 164

Locate a red 2x2 corner plate and attach it symmetrically on the right in a braille "F" pattern.

Step 165

Locate a red 1x4 plate and attach it horizontally to the right 3 studs of the build so it overhangs by 1 stud to the right.

Step 166

Locate a red 1x2 tile and horizontally attach it to the ppp centered horizontally. Locate a red 1x2 right wedge curved slope tile and attach it horizontally with the longer side at the back to the right of the ppp.

Step 167

Locate a red 1x2 plate and set it down horizontally. Locate a red 1x4 slope and with the slope facing horizontally to the left, attach the plate under the left side. Take this and attach the right side of the slope to the 2 studs on the back-left of the mini build.

Step 168

Locate a red 4x8 half circle plate and set it down horizontally with the flat edge to the back. Attach the 2 studs in the front of the mini build on to the back center of the half circle plate.

Step 169

Locate 2 white $\frac{1}{4}$ round wedges. Hold one with the round edge facing forward and right. Attach the back-left corner of the wedge to the stud that's on the right of the 2 studs above the back row of the mini build. Repeat symmetrically on the left.

Step 170

Locate 2 red 4x4 round corner tiles. Attach one to the right of the ppp in a braille letter "J" pattern. Repeat symmetrically to the left.

Step 171

Flip the mini build upside-down with the round edge at the back. Locate a red 2x2 right wedge plate and with the studs at the back attach it to the front right of the mini build.

Step 172

Locate a dark grey 2x4 plate and vertically attach it to the vertical and horizontal center of the mini build. Locate a dark grey 2x2 inverted round plate and attach it to the left of the front 2 rows of the ppp.

Step 173

Locate a light grey 2x2 plate with a ball on one side. Attach it with the ball facing to the right centered vertically to the 2x4 plate from the previous step.

Step 174

Locate 2 black 1x2 inverted slopes. Attach one vertically with the slope facing forward to the front-left of the ppp. Repeat symmetrically to the back.

Step 175

Bring the main build back and rotate it so the studs on the base are facing to the left. Flip the mini build up so the round edge is at the bottom and the ball plate is on the back. Attach the ball of the mini build to the ball clip near the top left of the main build.

Group 26 – Now let's finish off the mask by attaching the forehead.

Step 176

Set the main build aside. Locate a black 2x6 plate and set it down horizontally. Locate a red 1x2 plate and attach it vertically to the far-left of the 2x6 plate.

Step 177

Locate a red 1x2 plate and attach it vertically on top of the ppp.

Step 178

Locate 2 black 1x4 plates and attach them on top of each other, then attach them vertically centered to the far-right of the mini build.

Step 179

Flip the mini build upside-down keeping the 1x4 plates on the right side. Locate a dark grey 2x4 plate and horizontally attach the 3 columns on the right to the left side of the mini build so the plate overhangs by 1 column on the left. Locate a light grey 2x3 plate with a bar above it and attach it horizontally to the right of the ppp.

Step 180

Locate a black 6x8 curved shell and horizontally with the studs on the right lay it upside-down in front of you. Attach the right side of the mini build to the far-right of the shell centered vertically.

Step 181

Locate a black 2x6 right wedge with 2 studs on top. Attach it horizontally with the studs at the back to the front right corner of the mini build. Locate a black 2x6 left wedge and repeat symmetrically to the back.

Step 182

Locate 2 black 1x2 inverted slopes. Take one slope vertically with the slope facing backward and attach the front stud to the back-right corner of the ppp in the front of the mini build. Repeat symmetrically in the back.

Step 183

Bring back the main build and rotate it so the studs on the base are facing forward. Flip the mini build so the bar plate is on the bottom and the slope faces forward. Attach the bar to the 2 clips at the top of the main build.

Step 184

Locate a black 1x2 rocker bearing and a black 2x2 rocker plate. Attach the bearing horizontally with the higher side at the back to the 2 studs at the front of the base of the main build. Attach the plate to the bearing with the rocker attachment in the back and swing the plate forward so it is now vertical.

Step 185

Locate a black 4x6 plate with studs only on 3 edges. Flip it so that it is horizontal with the no-stud edge at the top. Attach the bottom of the back of the plate to the rocker plate. This is the nameplate for the display. It has Miles Morales written on it and it also has the Lego and Marvel logos.

Congratulations on finishing your build! Would you like to inspire other blind people to build LEGO sets? Let's feature your build on our [Builders page](#). It's easy and we will do all the work! Just contact us at info@bricksfortheblind.org and together we will make it happen!

We hope you enjoyed building your LEGO set! Bricks for the Blind are able to create these text-based building instructions thanks to generous donations from our builders. If you enjoy the instructions we create, please consider making a \$5 donation at <https://www.gofundme.com/f/bricks-for-the-blind-gofundme>. Bricks for the Blind is a registered tax exempt 501(c)(3) corporation.

Please [sign up](#) for our newsletter and follow us on [Facebook](#) and [Instagram](#) to be the first to know when new instructions are available!