

10224 Town Hall

Welcome to Text-Based Building Instructions from Bricks for the Blind. Here is some helpful information on how to best use screen readers and browsers: bricksfortheblind.org/help-with-screen-readers. Before you start building, here are some terms we will be using:

Front: towards you.

Back: away from you.

Up: towards the ceiling.

Down: towards the floor.

Stud: the bump on a Lego brick. Example: A 2x1 brick has two studs on it.

Vertically: going from front to back.

Horizontally: going from left to right.

Upright: pointing up towards the ceiling, and down towards the floor.

Symmetrically: a mirror image. Example: If you place a 2x1 brick with technic connector on the front wall at the right, connector to the front, and then place another such piece symmetrically on the back wall, at the right, the technic connector of the second piece should point to the back, since it will be placed symmetrically.

There are also abbreviations defined at the end of this file.

This highly detailed model features large entranceway columns, a coat of arms, a tall bell tower with clock and a large skylight that lets you see inside! On the ground floor, the large hall, tax office and auditorium have everything you need to run the town. Take the working elevator up to the secretary and mayor's offices on the second floor, realistically furnished with desks, chairs, paintings and even a frog sculpture. Hold a meeting and address the town's citizens at the podium! On the third floor, a spacious meeting room features a large conference table, chairs, globe and plants.

Book 1

Bag 1.

Step 1

Take a 32x32 base. Put a 1x1 flat smooth piece at the leftmost button of the first row.

Step 2

Put five 6x1 flat smooth pieces to the right, on the first row.

Step 3

Put a 1x1 flat smooth piece on the rightmost button.

Step 4

Put three 2x2 flat smooth pieces on the left side, on the second row, side by side.

Step 5

Put a grate piece horizontally to the right.

Step 6

Put 8 2x2 flat smooth pieces to the right, side by side.

Step 7

Put a grate piece on the second row, to the right.

Step 8

Put a 2x1 flat smooth piece horizontally to the right.

Step 9

Skip two buttons to the right and put a 2x1 flat smooth piece on the two rightmost buttons of the second row.

Step 10

Put three 2x2 flat smooth pieces on the left side, on the 3rd and 4th rows, side by side.

Step 11

Put a 2x1 flat smooth piece to the right, on the 3rd row.

Step 12

put a 2x1 flat smooth piece vertically, on the 4th and 5th rows, on the 7th column.

Step 13

put a 2x1 flat piece vertically to the right.

Step 14

put a 2x1 flat piece horizontally to the right, on the 4th row.

Step 15

put two 6x1 flat pieces horizontally side by side to the right, on the 4th row.

Step 16

Put a 2x1 flat piece vertically to the right.

Step 17

Put 2x1 flat smooth piece vertically to the right.

Step 18

put a 2x2 flat smooth piece to the right.

Step 19

put a 2x1 flat smooth piece horizontally to the right, on the 4th row.

Step 20

put a 2x2 flat smooth piece to the right. There should remain a 2x2 free space on the second and third rows, on the third and 4th columns from the right.

Bag 2.

Step 1

Put a 2x2 flat smooth piece on the left side, on the 5th and 6th rows, on the 1st and 2nd columns.

Step 2

Put a 2x1 flat piece horizontally to the right, on the 5th row.

Step 3

Put a 2x2 flat smooth piece to the right.

Step 4

Put a 2x1 flat smooth piece horizontally on the 7th row, on the 1st and 2nd columns from the left.

Step 5

Put a 2x2 flat piece with one button to the right, on the 6th and 7th rows.

Step 6

Put a 2x1 flat smooth piece horizontally to the right.

Step 7

Put a 6x1 flat smooth piece horizontally on the 8th row, on the 1st - 6th columns from the left.

Step 8

Put a 1x1 button in the corner on the 5th row, on the 9th column.

Step 9

Repeat steps 1-8 on the right side, symmetrically.

Step 10

Put a 3x1 hor. on the 5th row, to the right of the left 1x1 button.

Step 11

Put an 8x1 hor. to the right.

Step 12

Put a 3x1 hor to the right.

Bag 3.

Step 1

Put a 2x1 ver on the 7th column, on the 6th-8th rows.

Step 2

Skip a column to the right and put a 3x2 hor.

Step 3

Skip a column to the right and put a 2x2 cylinder.

Step 4

Repeat steps 1-3 symmetrically on the right.

Bag 4.

Step 1

Put a 1x1 on the leftmost button of the 9th row.

Step 2

Put a 1x1 slide piece on top of a 1x1 flat piece and put this part to the right of the previous piece, the top of the slide to the back.

Step 3

Put a 2x1 hor to the right.

Step 4

Repeat step 2.

Step 5

Put an 8x1 hor to the right.

Step 6

Repeat steps 1-5 symmetrically on the right.

Step 7

Put a 2x1 piece with the hole ver on the leftmost buttons of the 10th and 11th rows.

Step 8

Put a 4x1 ver to the back.

Step 9

Put a 6x1 ver to the back.

Step 10

Put a 2x1 piece with the hole ver to the back.

Step 11

Put a 2x1 ver to the back.

Step 12

Put a 2x1 hor to the back, on the 1st and 2nd columns.

Step 13

Put a 2x1 ver to the back, on the 1st column.

Step 14

Put a 3x1 hor to the back, on the 1st-3rd rows.

Step 15

Put a 4x1 flat piece hor to the right.

Step 16

Put a 2x1 hor to the right.

Step 17

Put a 1x1 piece with the side button to the right, button to the back.

Step 18

Put an 8x1 hor to the right.

Step 19

Put a 6x1 hor to the right.

Step 20

Put a 4x1 flat piece hor to the right.

Step 21

Put a 4x1 hor to the right.

Step 22

Put a 4x1 ver to the front, on the rightmost column.

Step 23

Insert a connector into a 2x1 piece with the hole and put this part ver to the front, connector to the right.

Step 24

Put a 3x1 ver to the front.

Step 25

Put a 6x1 hor to the front, on the 1st -6th columns from the right.

Step 26

Put a 6x1 ver to the front, on the rightmost column.

Step 27

Insert a connector as before and put the part ver to the front as before.

Step 28

Put a 6x1 hor on the 22nd row, on the 2nd -7th columns from the left (it should be next to the holed piece's front button).

Step 29

Put a 6x1 ver next to and to the back of it (on the 8th column, on rows 22nd -28th).

Bag 5.

Step 1

Put a 3x1 flat piece ver on top of the right two buttons of the left cylinder and on the button in front of it.

Step 2

Repeat on the right cylinder.

Step 3

Put a flat 4x1 hor in between the first buttons of the two previous pieces.

Step 4

Put a flat 6x1 hor on top of these pieces.

Step 5

Put a 4x2 hor on the 8th -12th columns from the left, on the 17th -18th rows.

Step 6

Put a 3x2 ver to the right and to the back, aligning at the front.

Step 7

Put a cut-off 6-button piece to the back and to the left, aligning at the right, cut-off side to the right and to the back.

Step 8

Put a 4x2 ver to the back and to the left, so that its leftmost back button is next to the 1x1 button with the hole.

Step 9

Put a 2x1 ver to the front and to the right of the cut-off piece, so that just their corners touch.

Step 10

Put a 4x1 hor to the right and to the back, so that the back button of the 2x1 and the leftmost button of the 4x1 are next to each other.

Step 11

Put a 2x1 ver to the right and to the front.

Step 12

Put a flat smooth 6x1 on top of a flat 6x1 and put this part hor to the back and to the left and to the right of the 4x1 from step 9.

Step 13

Put a 4x2 ver to the right and to the front and to the back of the 2x1 from step 10.

Step 14

Put a 3x2 hor to the back and to the right, aligning at the back.

Step 15

Put a 4x2 ver to the right and to the front, aligning at the back.

Step 16

Put a cut-off piece to the right and to the back, cut-off side to the left and to the back, so that it is symmetrical to the first one. Put a 4x2 ver to the right and to the back, symmetrical to the first one.

Step 17

Put a flat smooth 2x1 ver on the 5th column from the right on 3rd and 4th rows from the back.

Step 18

Put a flat smooth 2x1 hor to the left and to the back (on the 3rd row from the back, on the 6th column).

Step 19

Put a flat smooth 2x1 to the left and to the front, parallel to the first one.

Bag 6 (number 8).

Step 1

Put a grate into the free space in the middle (see steps 17-19 of the previous bag).

Step 2

Put a grate on a frog piece and put it hor, nose to the front, on the 3rd and 4th columns from the left, on the 9th row from the back (next to and to the back of the 6x1 piece).

Step 3

Put four 1x1 slide pieces hor side by side, top to the back, on the 4th -7th columns from the left, on the 6th row from the back (next to and to the front of the flat 4x1 piece).

Step 4

Put a flat 2x1 ver on each side of the flat 6x1 piece in front of the cylinders, so that they are on

the left side of the right cylinder and on the right side of the left one.

Step 5

Make a part. Put a flat 2x1 ver on the left side of a flat 2x2 piece. put a flat smooth 2x1 ver on top. Put a flat smooth 2x1 on the right side. Put this part as it is on the 6th -7th rows from the back on the 11th -12th columns from the right (next and to the front of the 6x1 piece, in the middle of it).

Step 6

Put a flat smooth 6x1 hor on top of the piece in the middle, on the 12th row from the back, so that there are 1x1 free buttons to the front and to left and to the right of it.
Bag 7. (Number 9)

Step 1

Put a flat smooth 6x1 piece from a separate bag on top of two flat 6x1 pieces and put this part hor on top of the previous piece.

Step 2

Put another piece from the sep. bag hor on the 13th row (that means from the front, by default), on the 9th - 14th columns from the right.

Step 3

Put two frame pieces ver to the sides, aligning at the front.

Step 4

Put a flat smooth 3x1 ver to the back of the right one of these pieces.

Step 5

Put three flat smooth 6x1 pieces hor, side by long side, on top of the middle front part with the cylinders, so that it makes a counter.

Step 6

Put three flat smooth 6x1 pieces hor, side by short side, on top of the buttons in the middle of the 4th row.

Step 7

Put one flat smooth 2x1 hor back to the leftmost one of the previous pieces, and one symmetrically on the right.

Step 8

Put two flat smooth 6x1 pieces hor side by short side in the middle of the next row, on top.

Step 9

Put one flat smooth 4x1 piece ver on each side, to the back, aligning at the front.
Bag 7. (Number 10)

Step 1

Put a 3x1 ver on the second level of the right, in front, skipping the first button.

Step 2

Put an 8x1 ver to the back.

Step 3

Put an 8x1 ver to the back.

Step 4

Put a 3x1 hor to the left of the last button of the previous piece.

Step 5

Skipping four buttons to the left, put an 8x1 hor to the left.

Step 6

Put an 8x1 hor to the left.

Step 7

Put a 10x2 ver to the front of the two leftmost buttons of the previous piece.

Step 8

Put a 2x1 hor to the right of the front row of the previous piece (PP).

Step 9

Put an 8x1 hor to the right.

Step 10

Put ab 8x1 hor to the right.

Step 11

Put a 1x1 to the right.

Step 12

Put a 10x2 ver to the right and to the back.

Step 13

Put a 10x2 hor to the left of the PP, next to its 2nd and 3rd rows.

Step 14

Skipping six buttons to the left, put a 3x2 hor to the left.

Step 15

Put a 1x1 flat smooth piece on top of the 3x1 piece at the back of the left side, on the 5th row from the back, on the 2nd column from the left.

Step 16

Skip one button to the front and put a 1x1 flat piece on top of the right side of the 2x1 piece.

Bag 8 (Number 11)

Step 1

Put a 1x1 to the right of the flat smooth 1x1 piece of step 15.

Step 2

Skipping one button to the left, put a 6x1 ver to the front (starting the next level of the left wall).

Step 3

Put a corner piece to the front, braille letter F.

Step 4

Put a 6x1 hor to the right of the 1 and 4 dots of the F.

Step 5

Put a 6x1 ver to the back of the rightmost button of the PP.

Step 6

Put a 2x1 ver to the front of the 1 and 2 dots of the F.

Step 7

Put an 8x1 hor to the front and to the right.

Step 8

Put an 8x1 ver to the front of the leftmost button of the PP.

Step 9

Put a 3x1 arch hor to the front and right.

Step 10

Put a 3x1 arch hor to the right.

Step 11

Put a 6c1 hor to the right.

Step 12

Put an 8x1 hor to the right.

Step 13

Put an 8x1 hor to the right.

Step 14

Put a 3x1 arch to the right.

Step 15

Put a 3x1 arch to the right.

Step 16

Skip six buttons to the left and put a 3x1 hor to the front of the 6x1 piece on the left.

Step 17

Put a 3x2 hor to the front of the PP.

Step 18

Skip one button to the left and put a 3x2 hor to the left, parallel to the previous 3x2.

Step 19

Put a 3x1 hor to the back.

Step 20

Do two 3x2 and two 3x1 symmetrically on the left side.

Number 12

Step 1

Put a flat 6x1 ver on the back of the left wall.

Step 2

Skipping one button to the left of the last button of the PP, put a flat 1x1 on the 1x1 piece.

Step 3

Put a flat 8x4 hor to the front and to the right of the 6x1 from step 1.

Step 4

Put a flat x1 ver to the back of the rightmost column of the PP.

Step 5

Put a flat 3x1 ver to the back.

Step 6

Put a flat 3x1 hor to the back and to the right.

Step 7

Put a flat 2x1 hor to the right.

Step 8

Put a flat 6x1 hor to the right.

Step 9

Put a flat 6x1 hor to the right.

Step 10

Skipping four buttons to the right, put a flat 1x1 to the right.

Step 11

Put a flat 3x1 hor to the right.

Step 12

Put a flat 6x1 ver to the front, on the rightmost column.

Step 13

Put a flat 3x1 ver to the front.

Step 14

Put a flat 10x6 ver to the front and to the left.

Step 15

Put a flat 10x6 ver to the left.

Step 16

Put a flat 10x6 ver to the left.

Step 17

Put a flat 10x6 ver to the left.

Step 18

Put a flat 10x6 ver to the left.

Step 19

Put a flat 10x2 ver to the left.

Bag 9

Number 13

Step 1

Put a flat smooth 6x1 hor in the middle of the first row of the raised platform, aligned with the three flat smooth pieces in front of the platform.

Step 2

Put a flat smooth 6x1 hor to the back of the PP.

Step 3

Put a flat smooth 2x1 ver to the right of the previous two pieces.

Step 4

Put a flat smooth 2x1 ver to the left of the same pieces.

Keep the rest of the pieces separately and open bag 10.

Step 5

Put a flat 6x1 hor to the back of the two flat smooth 6x1 pieces.

Step 6

Make a checkered black (bag 9) and white (bag 10) 2x2 flat smooth pieces pattern to the back of the flat 6x1 piece. put two white pieces at the sides and a black one in the middle of the space back to the 6x1 piece.

Step 7

Put two black pieces at the sides and a white one to the back.

Step 8

Put two white ones at the sides and a black one to the back.

Step 9

Take a flat smooth 2x1 from a separate bag and put it ver to the left of your pattern, skipping two first buttons on the column left to the pattern.

Step 10

Put the other piece from the same separate bag and put it vet to the back of the PP.

Step 11

Put a flat smooth 3x1 hor on the first row of the left 3x3 base in front of the raised platform.

Step 12

Put a flat smooth 2x1 ver to the back and to the left of the PP.

Step 13

Put a flat smooth 2x1 ver to the back and to the right of the same piece.

Step 14

Repeat steps 11-13 three times on the other three 3x3 bases to the right of this one.

Number 14.

Step 15

Put a 6x1 ver on the front of the leftmost column of the raised platform.

Step 16

Put a 6x1 ver to the back.

Step 17

Put an 8x1 ver to the back.

Step 18

Skipping one button to the right from the last button of the PP, put a 1x1 piece on top of the 1x1 flat piece.

Step 19

Install the doors into the 4x1 frame and put it hor to the right of the PP, doors opening to the back.

Step 20

Put a 3x1 ver to the right and to the front.

Step 21

Put an 8x1 hor to the right of the last button of the PP.

Step 22

Put an 8x1 hor to the right.

Step 23

Skipping four buttons to the right, put a 3x1 hor.

Step 24

Put an 8x1 ver to the right and to the front.

Step 25

Put a 6x1 ver to the front.

Step 26

Put a 6x1 ver to the front.

Step 27

Put two flat smooth 3x1 pieces on top of the 6x1 piece in the middle, in front of the pattern. Put aside.

Bag 11. (Number 15)

Make a decoration with the shield part.

Step 1

Put a 3x2 ver on the table.

Put a flat 2x1 hor on the first row.

Step 2

Put a flat 2x1 with one button on top of the PP.

Put a 1x1 with the side buttons on top of the PP.

Step 3

Put one flat smooth 1x1 piece upright on the left side button of the PP, and one on the right.

Step 4

Put a flat 2x1 piece with the cornice hor on top of the 1x1 piece, the cornice to the front.

Put a flat smooth 2x1 piece hor on top.

Step 5

Hang the shield in front, upright, on the button under the cornice.

Install this part as it is in the middle, in the back, in front of the back wall, to the left of the little steps.

Step 6

Make the first level of the front wall. Skipping the first row, put a 4x1 hor on the left side of the front raised platform - on the second row.

Step 7

Put a 1x1 to the right and to the front, on the first row.

Step 8

Put a 6x1 hor to the right.

Step 9

Put a 2x1 ver to the back of the rightmost button of the PP.

Step 10

Put a 2x1 ver to the right and to the back, so that it protrudes one button to the back of the PP.

Step 11

Repeat steps 6-10 symmetrically on the right.

Step 12

Put three flowers on top of each other on a 1x1 cylinder and install this part on the right, in the corner of the front wall, to the back of the second- to-the leftmost button of the 6x1 hor piece and to the right of the 2x1 ver piece. Put aside.

Bag 12 (number 16)

Step 1

Make a monumental lamp. Put one 2x2 cylinder on top of the other and put them on top of a flat 2x1 piece.

Step 2

Put two flat 2x1 pieces with one button on top.

Step 3

Put a flat 2x1 from a separate bag on top.

Step 4

Put a flat 2x1 with one button on top.

Step 5

Put a 1x1 sphere on top. Install this part on the left side, in front, to the back of the left front wall, in the middle, skipping two buttons to the left of the vertical 2x1 piece. Steps of the lamp are to the front and to the back.

Step 6

Make a table. Put two flat smooth 6x1 pieces side by long side, upside down. Connect them by two flat 2x1 ver at the both short sides.

Step 7

Put two 1x1 cones into each of the previous pieces. Turn right side up and install ver by the left wall, skipping two rows to the back.

Step 8

Make the first level of the inside partition. Put an 8x1 ver on the left partition wall, to the right of the left back door, to the front of the 3x1 ver piece on the right from the door.

Step 9

Put a 1x1 piece to the left of the PP, next to the 5th button of it.

Step 10

Put a 2x1 hor to the right of the first button of the 8x1 piece.

Step 11

Put a 3x1 hor to the right.

Step 12

Put a 1x1 to the front of the rightmost button of the PP.

Step 13

Put a 1x1 on the right side of the pattern, parallel to the first one (from step 9).

Step 14

Put a 6x1 hor to the back and to the right of it.

Step 15

Put a 6x1 hor to the left.

Step 16

Put a 4x1 with the side buttons hot on the first row on the left side, and one on the right.

Bag 13 (number 17)

Step 1

Put a 1x1 on the rightmost button of the front partition wall.

Step 2

Put a 4x1 from a separate bag hor to the left.

Step 3

Put a 4x1 from a separate bag hor to the left.

Step 4

Put a 2x1 from a separate bag hor to the left.

Step 5

Skipping eight buttons to the left, put a 4x1 from a separate bag hor to the left.

Step 6

Put a 1x1 to the left.

Step 7

Put a 3x1 hor to the back.

Step 8

Put a three-buttons corner piece to the back and to the left, Braille J letter.

Step 9

Put a 4x1 ver to the back.

Step 10

Put an 8x1 hor to the back, starting on the leftmost button of the back wall.

Step 11

Make a part. Put a flat 4x2 hor on the table. Put two 2x1 slide pieces hor on the back row of it, tops to the front. Put two flat 2x1 corniced pieces on the front row, cornices to the front. Install this part hor to the right of the PP, cornices to the front.

Step 12

Put a 3x1 hor to the right.

Step 13

Make another such part and install the same way to the right.

Step 14

Put a 3x1 hor to the right.

Step 15

Skipping four buttons, put a 4x1 hor to the right.

Step 16

Put a 3x1 ver to the front.

Step 17

Put an 8x1 ver to the front.

Step 18

Put an 8x1 ver to the front.

Step 19

Put two 2x1 pieces ver to the sides of the front partition wall.

Bag 14 (number 18)

Step 1

Go to the back of the left wall. Put a 6x1 ver on it.

Step 2

Put a corner piece to the front and to the right, braille letter F.

Step 3

Put a 4x1 ver to the front.

Step 4

Put an 8x1 ver to the front.

Step 5

Make a part. Put a flat 4x2 hor on the table. Put a flat 4x1 on the back row of it. Put two 2x1 slide pieces on the front row, tops to the back. put this part hot to the right of the PP, on the two front rows of the left side of the front wall.

Step 6

Put a 6x1 hor to the right, on the front row.

Step 7

Put a 2x1 ver to the right and to the back.

Step 8

Put a corner piece to the back and to the right, Braille J.

Step 9

Do symmetrically on the right side: Braille H, then ver 2x1, then hor 6x1, then the slide part.

Step 10

Put a flat smooth 6x1 upright hor on the left side of the front wall, on the four side buttons, aligning on the left with the front wall.

Step 11

Do symmetrically on the right side.

Bag 15 (Number 19)

Step 1

Go to the back of the left wall. Put a 2x1 ver on it.

Step 2

Put an 8x1 ver to the front.

Step 3

Put an 8x1 ver to the front.

Step 4

Put a 2x1 ver to the front.

Step 5

Go to the front of the right wall. Put a 4x1 ver on it.

Step 6

Put an 8x1 ver to the back.

Step 7

Put a 6x1 ver to the back.

Step 8

Put a corner piece to the back and to the left, braille D.

Step 9

Put a 2x1 hor to the left.

Step 10

Skipping four buttons to the left, put a 3x1 hor.

Step 11

Skipping four buttons to the left, put a 3x1 hor.

Step 12

Skipping four buttons to the left, put a 2x1 hor.

Step 13

Put a 2x1 ver to the left.

Step 14

Put a 1x1 piece with the side button to the left, side button to the back.

Step 15

Put a 4x1 hor to the left.

Step 16

Insert the drawers into the chest and put it ver next to the right wall, to the front of the right front partition wall.

Bag 16 (number 20)

Step 1

Put a 1x1 from a separate bag at the back of the left wall, on the second column from the left, on top of the 1x1 piece back to the table.

Step 2

Put a flat smooth button on the side button of a 1x1 piece and put this part, skipping four buttons to the right of the PP, on top of the protruding appendix, side button to the front.

Step 3

Put an 8x1 ver to the right, on the left partition wall, starting from the back.

Step 4

Put a 2x1 hor to the front and to the right.

Step 5

Put a flat smooth 2x1 hor to the right.

Step 6

Put a 1x1 to the right.

Step 7

Put 2x1 from a separate bag (or ask) ver to the right and to the front.

Step 8

Skipping six buttons to the right, put a 2x1 from the separate bag ver parallel to the PP.

Step 9

Put a 1x1 to the back and to the right.

Step 10

Put a flat smooth 2x1 hor to the right.

Step 11

Put a 4x1 hor to the right.

Step 12

Put a flat smooth 2x1 hor to the right.

Step 13

Put a 2x1 hor to the right.

Step 14

Insert one drawer into the chest and put it ver, drawer to the right, on the tight part, to the back of the front wall, skipping four buttons to the left from the right wall.

Step 15

Put a 2x1 frame hor skipping two rows to the back from the PP, in front of the partition wall, parallel to the PP.

Bag 17 (number 21)

Step 1

Make a counter top. Put a flat 4x2 ver on the table. Put a flat 2x1 with one button ver on the back two buttons of its left row.

Step 2

Put a flat smooth 2x1 ver to the right.

Step 3

Put a flat 2x1 with one button ver to the front.

Step 4

Put a flat smooth 2x1 ver to the left.

Step 5

Make a table lamp by putting a 1x1 button on top of a 1x1 cone and putting a shade piece on top. Put this part on the left back button of the counter top. Put a flat smooth 2x1 money piece from a separate bag on the remaining button. Install this part, as it is, with its two front buttons on top of the one-drawer chest, on its last row two buttons, and with its two last row buttons on top of the 2x1 frame to the back of the chest.

Step 6

Go to the left side of the front wall. Skipping five buttons from the left (including four slide spaces), put a 1x1 on the front wall.

Step 7

Put a 6x1 hor to the right.

Step 8

Put a 2x1 ver to the back of the rightmost button of the PP.

Step 9

Put a 1x1 piece with the handle to the right of the back button of the PP, handle to the front.

Step 10

Put a 1x1 to the back.

Step 11

Do symmetrically the right side of the front wall: 1x1, then handle piece to the front, then 2x1 ver to the front and to the right, then 6x1 hor to the front and to the left, then 1x1.

Bag 18 (number 22)

Step 1

Go to the front side of the left wall. Put an 8x1 ver on it.

Step 2

Put a 4x1 ver to the back.

Step 3

Put a corner piece to the back and to the right, braille F.

Step 4

Put a 6x1 ver to the back.

Step 5

Put a tall 1x1 to the right of it, next to its third button from the back, on top of the flat 1x1 piece, so that it is the same height as the left wall.

Step 6

Go to the left side of the back wall. Put an 8x1 hor on it.

Step 7

Skipping four buttons to the right, put a 3x1 hor.

Step 8

Skipping four buttons to the right, put a 3x1 hor.

Step 9

Skipping four buttons to the right, put a 4x1 hor.

Step 10

Put a 3x1 ver to the front (on the right wall).

Step 11

Put an 8x1 ver to the front.

Step 12

Put an 8x1 ver to the front.

Step 13

Make a strange seat. Put a flat 2x2 on top of a cone piece (in the middle). Put a flat smooth 2x1 on top. Put a flat 2x1 next to it. Put this part to the right of the counter, buttons ver on the right.

Bag 19 (number 23)

Step 1

Make a computer. Put a church bench piece on top of a flat 2x2 piece. install a 2x2 flat piece with the clasp underneath on top of it. Put a 2x1 flat smooth keyboard piece on the other two buttons of the 2x2 piece. put a 2x2 flat smooth screen piece on the 2x2 clasp piece. Recline to the correct angle to imitate computer. Install on the one-drawer chestm facing the seat.

Step 2

Go to the back of the left partition wall. Put a 4x1 ver on it.

Step 3

Put a corner piece to the front and to the left, Braille J.

Step 4

Put a 3x2 ver to the front.

Step 5

Put a 2x1 from a separate bag hor to the front and to the right.

Step 6

Skipping two buttons to the right, put a 2x1 from a separate bag hor to the right.

Step 7

Put a 2x1 ver to the right and to the front.

Step 8

Skipping six buttons to the right, put a 2x1 ver, parallel to the PP.

Step 9

Put a 1x1 to the back and to the right.

Step 10

Skipping two buttons to the right, put a 4x1 from a separate bag hor to the right.

Step 11

Skipping two buttons to the right, put a 21 hor to the right.

Bag 20 (number 24)

Step 1

Put the drawers into a chest and put it on top of the previous two-drawer chest.

Step 2

Go to the left side of the front wall. Put a 6x1 hor on it.

Step 3

Put a 2x1 ver to the right and to the back.

Step 4

Put a corner piece to the back and to the right, braille J.

Step 5

Do symmetrically on the right side: braille H, then a 2x1 ver to the front, then hor 6x1 to the right.

Bag 21 (number 25)

Step 1

Make the door by putting the door board into the frame, putting a 1x1 button for the doorknob and putting a 4x1 slide on top, the slide overhanging the opening side of the door. Rotate your structure 180 degrees and install the door in what is now the left side of the front wall, to the back of the grate-piece threshold, opening to the front.

Step 2

Connect the three branch pieces together to make one long wine and put it upright on the right side of what is now the front wall, on the side button in the side if the first level of the wall, creeping up and to the right. Rotate back. Now your door is on the right side of the back wall.

Step 3

Put a 1x1 piece to the right of it.

Step 4

Skipping one button to the right, put a corner piece, braille D.

Step 5

Put a 6x1 ver to the front.

Step 6

Put an 8x1 ver to the front.

Step 7

Put a 4x1 ver to the front.

Step 8

Put a 3x1 hor to the left of the door.

Step 9

Skipping four buttons to the left, put a 3x1 hor.

Step 10

Skipping four buttons to the left, put a 2x1 hor.

Step 11

Put a corner piece to the left and to the front, Braille D.

Step 12

Put a 4x1 hor to the left.

Step 13

Put an 8x1 ver to the front of the D.

Step 14

Put a 1x1 to the left of the 8x1, next to its 4th button.

Bag 22 (number 27)

Step 1

Install the windows in the 8 frames. Put two pairs into the back wall, and two in the front wall, glass side closer to the outside.

Step 2

Put a 1x1 on each side of the front partition wall, on the front button of the two-button entrance pieces.
(number 28)

Step 3

Make a lantern. Put a 1x1 from a separate bag on top of a 1x1 button. Put a saucer piece on top, curving down. Put a gun on top, handle in the saucer button. Insert a muzzle of the gun into the hole at the side of a 1x1 piece with the side hole. Put this part into the right side of the back wall, into a one-button free space, lantern to the back.

Step 4

Go to the back side of the left wall. Put a 2x1 ver on it.

Step 5

Put a corner piece to the front and to the right of it, Braille F.

Step 6

Put a 6x1 ver to the front.

Step 7

Put a 1x1 to the right, next to the 4th button of the PP.

Step 8

Put an 8x1 ver to the front of the 6x1 piece.

Step 9

Put a 2x1 ver to the front.

Step 10

Skipping four (window) buttons to the right, put a 1x1 on the front wall.

Step 11

Put a 6x1 hor to the right.

Step 12

Put a corner piece to the back and to the right, braille F.

Step 13

Put a 1x1 to the back.

Do that symmetrically on the right side: 1x1, then D, then 6x1 to the left, then 1x1.

Bag 23 (number 27)

Step 1

Go to the left side of the front partition wall. Put a 2x1 hor on it.

Step 2

Skipping two buttons to the right, put a 1x1 on it.

Step 3

Skipping eight buttons to the right, put a 1x1 on it.

Step 4

Skipping two buttons to the right, put a 4x1 hor on it.

Step 5

Skipping two buttons to the right, put a 2x1 hor on it.

Bag 24 (number 29)

Step 1

Go to the back side of the left wall. Put a flat 6x1 ver on it.

Step 2

Put a flat 2x1 hor to the front and to the right.

Step 3

Put a flat 10x1 ver to the front, on the left wall.

Step 4

Put a 3x1 ver to the front.

Step 5

Skipping four (window) buttons to the right, put a flat 6x1 hor to the right.

Step 6

Put a flat 3x1 ver to the right and to the back.

Step 7

Put a flat 3x1 ver parallel on the right.

Step 8

Put a flat 6x1 hor to the right and to the front.

Step 9

Skipping four (window) buttons to the right, put a flat 10x1 ver to the right and to the back, starting on the first button of the right wall.

Step 10

Put a flat 2x1 hor to the left of the last button of the PP.

Step 11

Put a flat 10x1 to the back of the 10x1 piece.

Step 12

Put a flat 6x1 hor to the left of the last button of the PP.

Step 13

Put a flat 10x1 hor to the left.

Step 14

Put a flat 10x1 hor to the left.

Step 15

Put a flat 3x1 hor to the left.

Step 16

Put a flat 4x1 ver on the back side of the left partition wall.

Step 17

Put a flat 1x1 to the front.

Step 18

Put a flat 2x1 to the front and to the left.

Step 19

Put a flat 4x1 to the front.

Step 20

Put a flat 1x1 to the right.

Step 21

Skipping two buttons to the right, put a flat 1x1.

Step 22

Skipping eight buttons to the right, put a flat 1x1 on.

Step 23

Skipping two buttons to the right, put a flat 4x1 hor to the right.

Step 24

Skipping two buttons to the right, put a flat 2x1 hor to the right. Put aside.

Bag 25 (number 30).

Step 1

Make a strange part (maybe a conditioner?). Put a flat 4x4 on the table.

Step 2

Put a 1x1 piece with the side hole on the leftmost front button, hole to the front.

Step 3

Put a 3x1 ver to the back of it.

Step 4

Put a 4x1 piece with the side buttons ver on the right side, buttons to the right.

Step 5

Put a flat 4x4 on top.

Step 6

Put a flat 2x1 ver on the left side, and another ver to the back of it on the left side.

Step 7

Put two corniced 2x1 pieces upright, on its longer sides, cornices up, side by short side, on the right side, on the side buttons.

Step 8

Put a 1x1 piece with the side hole on the leftmost front button, hole to the front.

Step 9

Put a 3x1 ver to the back.

Step 10

Put two grates on the side buttons of the corniced pieces, upright.

Step 11

Put two grates ver, side by short side, on the leftmost column.

Step 12

Insert two connectors into the two holes. Put aside.

Bag 26 (cont. number 30)

Step 13

Take a one-hole oblong piece, put it hor on the table so that the hole is up and down and to the left. Insert a connector into the hole. Insert a ribbed stick into the cross-hole.

Step 14

Take a small ribbed tube with the perpendicular hole at the end and turn it hor so that the hole is up and down and at the right. Put this hole onto the connector.

Step 15

Take a three-hole oblong piece with the cross hole in the middle of one side and turn it upright, holes to the front and to the back, the cross-hole to the right, and put this cross-hole on the ribbed stick.

Step 16

Insert a head-connector from the left into the ribbed tube.

Step 17

Install this part, the way it is, from the left, on your previous part, putting the top and the bottom holes of the three-hole oblong piece onto the two connector of the first part.

Step 18

Install this part, turning it so that the two upright grate pieces are at the front and the head connector is at the left side of the back, onto your structure, in the left side of the back wall, sliding it all the way down, with the head connector in the opening of the back wall.

Number 31.

Step 1

Make a door with the doorknob and install it ver into the right side of the ver partition, so that it opens to the left and to the back.

Step 2

Put a 1x1 to the front of it.

Step 3

Put a 1x1 with the handle to the front of it, handle to the front.

Step 4

Put a 1x1 to the back of the ver door.

Step 5

Put an 8x1 arch hor to the back and to the left.

Step 6

Put a 1x1 to the front of the leftmost button of the PP.

Step 7

Skipping four buttons to the front, put a 1x1.

Step 8

Put a 1x1 with the handle to the front, handle to the front.

Step 9

Put one flat 1x1 on top of the other and put it on the left side, to the right of the 7th button from the back on the left wall.

Step 10

Skipping four buttons to the right, put another such part (flat 1x1 on top of the other) on top of the other tall 1x1 pier.

Bag 27 (number 32)

Step 1

Make a door and install it hor in the left hor partition wall, so that it opens to the left and to the front.

Step 2

Go to the left side of the back wall. Put a 4x1 hor on it.

Step 3

Put a corner piece to the right and to the front, braille D.

Step 4

Put a 2x1 hor to the right, on the back wall.

Step 5

Skipping four (window) buttons, put a 3x1 hor to the right.

Step 6

Skipping four (window) buttons, put a 3x1 hor to the right.

Step 7

Skipping four (window) buttons, put a 2x1 hor to the right.

Step 8

Put a corner piece to the right and to the front, braille D.

Step 9

Put a 6x1 ver to the front.

Step 10

Put a 1x1 to the front.

Step 11

Put a corner piece to the front and to the left, braille J.

Step 12

Put a 4x1 arch hor to the left.

Step 13

Put a 2x1 hor to the left.

Step 14

Put a 4x1 arch hor to the left.

Step 15

Skipping eight (arch) buttons to the left, put a 4x1 arch hor to the left.

Step 16

Put a 3x1 ver to the left and to the back.

Step 17

Put a 6x1 ver to the back.

Number 33.

Step 1

Put a flat 6x1 hor to the left of the PP, over the hor door.

Step 2

Go to the back of the left wall. Put a 2x1 ver on it.

Step 3

Put an 8x1 ver to the front.

Step 4

Put an 8x1 ver to the front.

Step 5

Put a 2x1 ver to the front.

Step 6

Skipping four (window) buttons to the right, put a 1x1.

Step 7

Put a 6x1 hor to the right.

Step 8

Put a 2x1 ver to the back of its rightmost button.

Step 9

Put a flat 8x1 ver to the right and to the back.

Step 10

Put a flat 8x1 ver to the right, skipping six buttons, over the ver door, so that it is parallel to the first flat 8x1.

Step 11

Put a 2x1 ver to the right and to the front.

Step 12

Put a 6x1 hor to the front and to the right.

Step 13

Put a 1x1 to the right.

Step 14

Skipping four (window) buttons, put a 1x1 on the first button of the right wall.

Step 15

Put an 8x1 ver to the back.

Bag 28 (number 34).

Step 1

Install windows in the frames and put a pair on top the left front window, and two on top of the right.

Step 2

Go to the right side of the hor partition wall (to the back of the double chest of drawers). Put a flat smooth 6x1 piece hor on it, skipping the rightmost button on the right ver wall.

Step 3

Put a flat smooth 6x1 piece hor to the left.

Step 4

Put a flat smooth 6x1 ver to the front, on top of the ver door (the first button on top of the door remains free).

Step 5

Put a flat smooth 6x1 hor to the left of the 6x1 piece from step 3, on top of the arch.

Step 6

Put a flat smooth 6x1 piece hor to the left.

Step 7

Put a 1x1 flat smooth piece to the back of the leftmost end of the PP.

Step 8

Put a flat smooth 2x1 ver to the back.

Step 9

Put a flat smooth 6x1 ver parallel to the 6x1 on top of the ver door, so that it goes on top of the door frame on the left, and the first button on top remains free.

Number 35.

Step 1

Go to the front side of the left wall. Put an 8x1 ver on it.

Step 2

Put a 4x1 ver to the back.

Step 3

Put a corner piece to the back and to the right, braille F.

Step 4

Put a 1x1 to the right of the 4-dot of the F.

Step 5

Put a 1x1 with the side hole to the right, hole to the front.

Step 6

Repeat.

Step 7

Put a 1x1 to the right.

Step 8

Put a corner piece to the right and to the back, braille J.

Step 9

Put a 4x1 ver to the back of the 4-dot of the J.

Step 10

Put a 6x1 ver at the back side of the left wall.

Step 11

Skipping one button to the right, put an 8x1 hor on the back wall.

Step 12

Skipping four (window) buttons to the right, put a 1x1 to the right.

Step 13

Insert a clasp stick into a holed 1x1 piece and put it to the right of the PP, clasp to the front, parallel to the table.

Step 14

Put a 1x1 to the right.

Step 15

Repeat steps 12-14 skipping four (window) buttons to the right.

Step 16

Skipping four (door) buttons to the right, put a 4x1 hor to the right.

Step 17

Put a 3x1 ver to the front, on the right wall.

Step 18

Put an 8x1 ver to the right.

Step 19

Repeat. Put aside.

Bag 29 (number 36)

Step 1

Make two over-the-window arches. Put a flat 4x2 hor on the table. Put a flat 2x1 with one button hor on the middle two buttons of the first row. Put a flat 1x1 to the right, and one to the left. Put one 1x1 slide piece to the back of the left 1x1, top to the right, and one to the back of the right 1x1, top to the left. Put a 1x1 flat smooth button on top of the one button of the 2x1 one-button piece. Put a 2x2 arch piece on top of the part, in the middle, arch to the front. Put a flat 2x1 hor on its first row. Put two 1x1 slide pieces on its second row, tops facing each other. Put a 2x1 flat corniced piece hor on the 2x1, cornice to the front.

Step 2

Repeat to make the second such part.

Step 3

Install these parts over the two front windows.

Step 4

Put a 6x1 hor on the front wall, to the right of the left window.

Step 5

Put a 2x1 ver to the right and to the back.

Step 6

Put a 2x1 hor to the back and to the right.

Step 7

Repeat steps 4-6 symmetrically on the right side. Put aside.

Bag 30 (number 37)

Step 1

Make a right wing of the central entrance. Put a flat 3x1 hor on the table. Put a 1x1 on the rightmost button.

Step 2

Put a 1x1 with the clasp on top, clasp to the right.

Step 3

Put a 2x1 frame hor on the two free buttons on the left, window to the front.

Step 4

Put a flat 3x1 hor on top.

Step 5

Put a 2x1 frame hor on top, on the right two buttons.

Step 6

Put a 1x1 with the handle to the left, handle to the front.

Step 7

Put a flat 3x1 hor on top.

Step 8

Put a 2x1 frame hor on top, of the left two buttons.

Step 9

Put a 1x1 with the clasp to the right, clasp to the right.

Step 10

Put a 1x1 on top.

Step 11

Put a flat smooth 3x1 hor on top.

Step 12

Install onto your structure, as a right wing of the central entrance.

Bag 31 (number 38)

Step 1

Make the left wing. Put a 1x1 on the leftmost button of a flat 3x1.

Step 2

Put a 1x1 with the clasp on top, clasp to the left.

Step 3

Put a frame to the right.

Step 4

Put a flat 3x1 on top.

Step 5

Put a frame on the left two buttons.

Step 6

Put a 1x1 handle piece to the right, handle to the front.

Step 7

Put a 1x1 on top.

Step 8

Put a 3x1 on top.

Step 9

Put a frame on the two right buttons on top.

Step 10

Put a 1x1 clasp to the left, clasp to the left.

Step 11

Put a 1x1 on top.

Step 12

Put a flat smooth 3x1 on top.

Step 13

Install.

Bag 32 (number 39)

Step 1

Install the windows into the six window frames and install the three pairs of windows into the back wall
- two over the existing windows and one over the door.

Step 2

Go to the front side of the left wall. Skipping two buttons to the back, put an 8x1 ver on it.

Step 3

Put an 8x1 ver to the back.

Step 4

Put a 2x1 ver to the back.

Step 5

Skipping one button to the right, put an 8x1 hor on the back wall.

Step 6

Skipping four (window) buttons, put a 3x1 hor to the right.

Step 7

Skipping four (window) buttons, put a 3x1 hor to the right.

Step 8

Skipping four (window) buttons, put a 2x1 hor to the right.

Step 9

Put a corner piece to the right and to the front, braille F.

Step 10

Put an 8x1 ver to the front.

Step 11

Put an 8x1 ver to the front.

Step 12

Put a 6x1 hor on the back left partition wall, over the back left door, to the right and next to the 7th button from the back of the left wall.

Step 13

Put a 6x1 ver to the right and to the back. Put aside.

Bag 33 (number 40)

Step 1

Make four rather strange-looking pillars for the front. Put a 1x1 with the side buttons - from a separate bag - on top of a 1x1 cylinder.

Step 2

Put a 1x1 button on top.

Step 3

Put a 1x1 button on top.

Step 4

Put a 1x1 with the side buttons on top, so that its buttons are on the other two sides than the buttons of the first one.

Step 5

Put two more buttons on top.

Step 6

Put a 1x1 piece with the side buttons from a separate bag on top, turned like the first one.

Step 7

Now close your part with the four upright 8x1 flat corniced pieces, each cornice turned so that each side of your part has one.

Step 8

Close this with four flat smooth 8x1 upright pieces.

Step 9

Make three more.

Step 10

Install them - diamond-like - in front of the building, on the four pedestals. Put aside.

Bag 34 (number 41)

Step 1

Make a capital for the right pillar on the left side. Put a flat pizza piece on the table, cut-off corner to the right and to the back. Put a flat 2x2 on the back left corner.

Step 2

Put a flat 1x1 with the roll on the front left button, roll to the front.

Step 3

Put a flat 1x1 to the right.

Step 4

Put a flat 1x1 with the roll to the front, as before.

Step 5

Put a flat 3x1 ver on the left side.

Step 6

Put a 1x1 on the back right button.

Step 7

Install this part as it is on the right pillar on the left side.

Step 8

Make a capital for the left pillar on the right side. Put a pizza piece on the table, curved end to the left and to the back. Put a flat 2x2 on the back two buttons on the right side

Step 9

Put two roll pieces and a flat 1x1 as in the other capital.

Step 10

Put a flat 3x1 ver on the right side.

Step 11

Put a flat 1x1 on the front of the left side.

Step 12

Put a 1x1 to the back.

Step 13

Install on the left pillar on the right side.

Number 42

Step 1

Put a corner piece at the front of the left wall, braille H.

Step 2

Skipping two buttons to the right, put a 2x1 hor on the front wall.

Step 3

Skipping three buttons to the right, put a 2x1 hor to the right.

Step 4

Do the same symmetrically on the right side - corner J, then two 2x1 pieces.

Step 5

Connect the left capital to the structure by putting a flat 6x1 ver on the three muttons in the middle of it and three buttons to the back of it.

Step 6

Put a flat 1x1 to the right of the last button of the PP.

Step 7

Repeat symmetrically on the right capital.

Step 8

Put a grate upright hor on the two upright buttons over the left back wall.

Bag 35 (number 43)

Step 1

Make two capitals for the other two pillars.

Step 2

Put a flat 3x1 hor on the table. Put a flat 3x1 hor to the back of it.

Step 3

Connect by putting a flat 3x2 hor on top.

Step 4

Put two roll pieces and a flat 1x1 as before.

Step 5

Put a flat 3x1 on top of another flat 3x1 and put them hor on the first row of your part.

Step 6

Put 3x2 ver on the right side to the back of the PP (protruding to the back).

Step 7

Put a 3x1 ver to the left.

Step 8

Make another such part.

Step 9

Install.

Step 10

Put a flat 10x1 hor to connect the two middle pillars, leaving one button free on each capital.

Step 11

Put two flat 1x1 on these free buttons.

Step 12

Put one flat 2x2 to the back of each of the PP.

Step 13

Put one flat 1x1 to the back of each of the PP.

Step 14

Put a flat 10x2 hor to the back, between the two PPs.

Bag 36 (number 44)

Step 1

Put a flat 10x2 hor on top of the PP, skipping the back row.

Step 2

Put a flat 10x2 hor to the front.

Step 3

Go to the front side of the right wall. Put a flat 6x1 ver on it.

Step 4

Repeat.

Step 5

Repeat.

Step 6

Put a flat 10x1 hor to the back and to the left.

Step 7

Put a flat 4x1 hor to the left.

Step 8

Put a flat 10x1 hor to the left.

Step 9

Put a flat 6x1 ver to left and to the front.

Step 10

Put a flat 6x1 hor to the front and to the left.

Step 11

Put a flat 2x1 hor to the left.

Step 12

Put a flat 6x1 ver to the back.

Step 13

Skipping one button to the right, put a flat 2x1 hor to the right.

Step 14

Put a flat 3x1 hor to the right.

Step 15

Put a flat 2x1 ver on the left wall, to the front of the hor flat 2x1.

Step 16

Put a flat 10x1 ver to the front.

Bag 37 (number 45)

Step 1

Put a flat 2x1 ver in the middle, on the right capital on the left side, on the leftmost column, skipping the front button.

Step 2

Do it symmetrically on the right.

Step 3

Put a flat 8x1 with the cornice hor to connect two left-side capitals, aligning on the left, cornice to the front.

Step 4

Put a flat corniced 2x1 to the right the same way.

Step 5

Repeat.

Step 6

Put a flat corniced 8x1 to the right.

Step 7

Skipping two rows to the back, put a flat smooth 1x1 on the rightmost column (to the back of the rightmost button of the PP).

Step 8

Put a flat 6x1 hor to the back and to the left of the PP.

Step 9

Put a corniced flat 2x1 hor to the right.

Step 10

Skipping two buttons to the right (the existing cornice), put a flat corniced piece hor to the right.

Step 11

Repeat steps 7-10 symmetrically on the left.

Step 12

Put a 1x1 tall piece on the back left side, to the right of the left wall, on some button inside.

Step 13

Make two lanterns. Insert a smaller end of a candlestick piece into the bottom of a 1x1 piece. Put a wider end of a cone on top. Insert a wider end of another cone into the smaller (bottom) end of the candlestick. Repeat to make two such parts. Install the way they are into the two clasps on the back wall.

Bag 38 (number 46)

Step 1

Go to the front side of the right wall. Put an 8x1 ver on it.

Step 2

Put an 8x1 ver to the back.

Step 3

Put a 3x1 ver to the back.

Step 4

Put a 3x1 hor to the right.

Step 5

Skipping four (window) buttons put a 3x1 hor to the left.

Step 6

Repeat.

Step 7

Skipping four (window) buttons, put an 8x1 hor to the left.

Step 8

Skipping one button to the left, put an 8x1 ver on the left wall.

Step 9

Put an 8x1 ver to the front.

Step 10

Put a 3x1 ver to the front.

Step 11

Put a 6x1 hor on the left back (elevator) partition wall.

Step 12

Put a 6x1 ver to the right and to the back.

Step 13

Now go to the portico over the pillars, to the middle. Put a flat smooth 2x1 hor in the middle of the first row, on the 10th -11th buttons from the left (and from the right).

Step 14

Put a flat 2x1 hor to back.

Step 15

Put one flat 2x1 with one button ver to the right, and one to the back of the two PPs.

Step 16

Put four flat 2x1 pieces with one button ver side by long side to the back of the four PPs.

Step 17

Put one flat smooth 2x1 hor to the right, and one to the left, of the back button of the four PPs.
Number 47.

Step 1

Go to the front side of the right wall. Put a 3x1 ver on it.

Step 2

Put an 8x1 ver to the back.

Step 3

Put a 6x1 ver to the back.

Step 4

Put a corner piece to the back and to the left, braille F.

Step 5

Put a 2x1 hor to the left.

Step 6

Put two frames with the windows to the left.

Step 7

Put a 3x1 hor to the left.

Step 8

Put two frames with the windows to the left.

Step 9

Put a 3x1 hor to the left.

Step 10

Put two frames with the windows to the left.

Step 11

Put a 2x1 hor to the left.

Step 12

Put a 6x1 ver to the left and to the front.

Step 13

Put a 2x1 hor to the left, on the back wall.

Step 14

Put a 3x1 hor to the left.

Bag 39 (number 48)

Step 1

Go to the front side of the left wall. Put a 6x1 ver on it.

Step 2

Put a 6x1 ver to the back.

Step 3

Put an 8x1 hor to the back and to the right.

Step 4

Put a 3x1 ver to the back of its leftmost button, on the back wall.

Step 5

Put a 1x1 button to the back.

Step 6

Put a flat 2x1 on top of another flat 2x1 and put them hor on top the button and to the right.

Step 7

Put a 2x1 ver to the back of the button, on the back wall.

Step 8

Go to the portico. Put a 2x1 tall shelf piece, open side to the back, hor, on the 12th and 13th buttons from the left of the front wall.

Step 9

Put a 2x1 button/loop piece in front of it, hor, button to the right.

Step 10

Repeat steps 9 and 10 symmetrically on the right.

Step 11

Put two 2x1 pieces hor side by short side in the middle between the shelf pieces, on the four buttons of the flat 2x1 pieces with one button.

Step 12

Put two 1x1 pieces with the side buttons to the front and to the sides of the two PPs, buttons to the front.

Bag 40 (number 49)

Step 1

Put a flat 8x1 hor on the left side of the front wall.

Step 2

Put a 1x1 cylinder to the right.

Step 3

Put a 1x1 to the right.

Step 4

Repeat steps 1-3 symmetrically on the right.

Step 5

Put a flat 3x1 ver on the top of the portico, in the middle, on the 1x1 piece with the side button and on the left button of the 2x1 at the back.

Step 6

Put a flat 2x1 hor to the right of the back button of the PP.

Step 7

Put a flat 3x1 nver to the right and to the front.

Step 8

Insert a connector into a 1x1 piece with the side hole.

Step 9

Insert the other end of the connector into the back left hole of a 2x1 piece with the side holes. Put this part hor on the left button/loop piece, on the loop, at an angle.

Step 10

Make another such part, except that the connector goes into the right side of a 2x1 piece, and put it symmetrically on the right.

Bag 41 (number 50)

Step 1

Make a center-of-the-portico part. Put a flat 2x1 with one button on top of a flat 2x1. Put a 1x1 with the side buttons on top. Put three flat smooth 1x1 pieces upright on the three of the side buttons, leaving the front one free. Put a flat 2x1 from a separate bag hor on top. Install in the middle of the portico, in the space inside the three small walls.

Step 2

Put a flat 1x1 on the front button of the left small wall on the portico.

Step 3

Put a flat 2x1 with one button from a separate bag ver to the back.

Step 4

Put a shelf piece hor to the left, in the back row, shelf to the front (to the right from the diagonal piece).

Step 5

Repeat steps 2-4 symm on the right.

Step 6

Put a flat smooth 2x1 hor in the middle of the back portico wall, between the two 2x1 flat pieces with one hole.

Bag 42 (number 51)

Step 1

Go to the left side of the front wall. Put a cylinder on the leftmost button.

Step 2

Put a ribbed 2x1 hor to the right.

Step 3

Repeat.

Step 4

Put a cylinder to the right.

Step 5

Put a ribbed 2x1 hor to the right.

Step 6

Put a flat 2x1 hor to the right, on top of the cylinder and the 1x1.

Step 7

Repeat steps 1-6 symm on the left.

Step 8

Put a flat 10x1 hor in the middle of the portico, on its back wall, to the back of the hor 2x1 in the middle.

Bag 43 (number 52)

Step 1

Make two portico wall-ends. Put a 1x1 on the right button of a 2x1 piece.

Step 2

Put another 2x1 hor to the left of the 2x1.

Step 3

Connect them by a 1x1 long slide, hor, button to the right.

Step 4

Put another long slide hor underneath, on the left, button to the right.

Step 5

Put a flat smooth on top of the rightmost button of your part.

Step 6

Repeat steps 1-5 to make another such part.

Step 7

Install them on the second row of the portico, next to the two 1x1 pieces with the upright button in front.

Bag 44 (number 53)

Step 1

Put two croissants on the two 1x1 pieces with the upright button in front.

Step 2

Put a 1x1 button on top of a 1x1 flat piece and put a 1x1 upward clasp piece on top. Repeat.
Install these pieces on the first row of the portico, to the left and to the right of the croissants, skipping one button on each side, the "toes" side of the clasp piece to the front.

Step 3

Skip one button to each side of the PPs and put a clasp piece on each side, toes to the front.

Step 4

Skip one button to each side and put a 1x1 flat smooth piece on each side.

Step 5

Repeat. The last two pieces should be at the ends of the first row of the portico.

Step 6

Go to the left end of the front wall. Put a flat 2x1 hor on it.

Step 7

Put a flat 8x1 hor to the right.

Step 8

Repeat steps 6-7 symm on the right side.

Bag 45 (number 54)

Step 1

Put a shield on the upright button in the middle of the portico.

Step 2

Put a flat 2x1 one-button piece on top of a flat 2x1 piece and put them on top of the second row of a flat 2x1 piece. Put this part, the way it is, to the back of the shield, in the middle of the portico, on the second and third rows.

Step 3

Skip two buttons to the right of the PP and put a flat 2x1 - which should be in a separate bag! - on

the third row of the portico and on the front wall. Repeat same on the right.

Step 4

Put a flat 10x1 hor on the left end of the front wall, and symm on the right, starting from the corners. Put aside.

Number 55 Make a right-side slanted roof for the portico

Step 5

Put a flat 10x1 hor on the table. Put a flat 2x1 with the cornice hor to the front of it, on the left side, cornice to the front.

Step 6

Put a flat 8x1 corniced piece hor to the right.

Step 7

Connect with the flat smooth 4x2, hor on the left.

Step 8

Put a flat smooth 2x1 ver to the right.

Step 9

Put a flat smooth 3x1 ver to the right.

Step 10

Repeat four times.

Step 11

Flip upside down so that the thinner side is still on the left. Put a flat 1x1, upside down, on the rightmost front corner.

Step 12

Put a flat 4x1, upside down, hor, to the left.

Step 13

Put a flat 1x1, upside down, on the last row, skipping one button to the left from the right side.

Step 14

Skipping one button to the left, put a flat 1x1, upside down.

Step 15

Repeat two times.

Step 16

Flip smooth side up and install on the right side of the portico, thinner side to the left, slanted.

Bag 46 (number 56) Make the left side of the portico roof.

Step 1

Put a flat 10x1 hor on the table. Put a corniced flat 2x1 hor to the front, on the right.

Step 2

Put a flat 8x1 hor to the left.

Step 3

Continue symm.

Step 4

Install symm on the left side.

Bag 47 (number 57) all pieces in this bag are flat.

Step 1

Go to the back end of the left wall. Put a 10x1 ver on it.

Step 2

Put a 6x1 ver to the front.

Step 3

Put a 3x1 ver to the front.

Step 4

Put a corniced 2x1 hor to the front and to the right, on the front wall, cornice to the front.

Step 5

Put a corniced 8x1 to the right as before.

Step 6

Put a 2x1 with one button ver to the right and to the back.

Step 7

Do the right side of the front wall symm.

Step 8

Put a 6x1 ver, on the right wall, to the back of the 2x1 corniced piece on the right corner of the front wall.

Step 9

Put a 6x1 ver to the back.

Step 10

Repeat.

Step 11

Put a 3x1 hor on the back wall, to the left of the PP.

Step 12

Put a 6x1 hor to the left.

Step 13

Put a 10x1 hor to the left.

Step 14

Repeat.

Step 15

Put a 1x1 to the left.

Step 16

Put a 1x1 to the right of the third button from the back of the left wall.

Step 17

Put a 6x1 hor on the partition, to the right of the 8th button from the back of the left wall.

Step 18

Put a 6x1 ver to the right and to the back.

Bag 48 (number 58)

Step 1

Go to the back end of the left wall. Put a 2x1 ver on it.

Step 2

Put a 2x1 hor to the front and to the right.

Step 3

Put a 3x1 ver to the front, on the left wall.

Step 4

Put an 8x1 hor to the front and to the right.

Step 5

Put a 6x1 ver to the right and to the back, on the ver wall of the partition.

Step 6

Return to the left wall. Put a 2x1 ver to the front of the 8x1 hor piece.

Step 7

Put an 8x1 ver to the front.

Step 8

Put a 3x1 ver to the front.

Step 9

Now you are on the front wall. Put a 6x1 hor to the right of the PP.

Step 10

Repeat.

Step 11

Put a 3x1 hor to the front, so that its two left buttons are at the front of the two rightmost buttons of the PP.

Step 12

Put a 1x1 to the right.

Step 13

Do the right side of the front wall symm.

Step 14

Put a 6x1 ver, on the right wall, to the right and to the back of the 6x1 hor piece on the right side of the front wall.

Step 15

Put an 8x1 ver to the back.

Step 16

Put a 6x1 ver to the back.

Step 17

You are on the back wall. Put a 3x1 hor to the left of the PP.

Step 18

Put a 6x1 hor to the left.

Step 19

Repeat.

Step 20

Put an 8x1 hor to the left.

Step 21

Skipping one button to the left (partition), put a 2x1 hor to the left.

Step 22

Put a 3x1 hor to the left. It should end the back wall.

Bag 49 (number 59) (all flat pieces)

Step 1

Go to the back end of the left wall. Put a 4x1 with two buttons ver on it.

Step 2

Put a 1x1 to the right of its third (non-existing) button from the back.

Step 3

Put a smooth 6x1 ver to the front of the two-button piece.

Step 4

Put a 6x1 hor to the right of its third (non-existing) button from the back, on the partition.

Step 5

Put a smooth 6x1 ver to the right and to the back, on the ver wall of the partition.

Step 6

Go to the left end of the back wall. Put a smooth 2x1 hor on it.

Step 7

Put a smooth 2x1 hor to the right.

Step 8

Put a smooth 6x1 hor to the right.

Step 9

Repeat three times.

Step 10

Put a smooth 2x1 hor to the right. It should end the back wall.

Step 11

Put a smooth 2x1 ver to the front.

Step 12

Put a smooth 6x1 ver to the front.

Bag 50 (number 60) (all flat pieces)

Step 1

Continue the right wall. Put a smooth 6x1 ver to the front of the PP.

Step 2

Put a 4x1 two-button piece ver to the front.

Step 3

Put a smooth 6x1 hor to the front and to the left - on the front wall.

Step 4

Put a smooth 6x1 hor to the left.

Step 5

Put a smooth 2x1 ver to the left and to the front.

Step 6

Put a smooth 1x1 to the left, in the corner made by the two PPs.

Step 7

Put a smooth 6x1 hor to the left of the vertical 2x1, on the front row.

Step 8

Put a 2x1, a 1x1, and two 6x1 pieces symm on the left side of the front wall.

Step 9

Put a smooth 1x1 to the back of the leftmost 6x1, on the left wall.

Step 10

Put a smooth 2x1 ver to the back.

Step 11

Put a smooth 6x1 ver to the back. It should touch the 6x1 that is already there, to the back.

Bag 51 (number 61) Make a lamppost and the flowerpots.

Step 1

Put a lamp (cylinder) on the lamppost, put an inverted saucer on an install at the right front corner of the base.

Step 2

Put four smooth flat 1x1 pieces at all the sides of a 1x1 piece with the side buttons. Put the flower stalk in the middle. Put the flowers on it. Repeat. Put at the sides of the portico, in the base.

Bag 52 (number 62) Make an old-fashioned camera with a flash.

Step 1

Put an inverted saucer on top of a button from a separate bag.

Step 2

Insert a "gun" handle into the saucer center.

Step 3

Insert the gun muzzle into the "robot hand" hole, the clasp going downwards.

Step 4

Put another gun's muzzle into the clasp, the handle parallel to the table and turned toward the saucer.

Step 5

Insert the handle of the second gun into the opening of the small camera piece, camera turned parallel to the table.

Step 6

Put two buttons on top of each other, then pue a button from the separate bag ot top and put this part on the camera front. Then turn your part saucer side up and give to the lady photographer.

The end of the first book.

Town Hall book 2

Bag 1. (bags 1-4 are all flat)

Step 1.1.1

Put a 16x2 ver on the table.

Step 1.2

Put a 24x6 hor on the first six buttons of the right column of the PP.

Step 2.2.1

Put a 24x6 hor to the back of the PP, on the 7th -12th buttons of the right column of the 16x2 piece.

Step 2.2

Put an 8x6 hor on the first six buttons of the left column of the 16x2 piece.

Step 2.3

Put an 8x6 hor to the back, on the 7th -12th buttons of the left column of the 16x2 piece.

Step 3.3.1

Flip over, so that the 16x2 piece overhangs to the front on the left side.

Step 3.2

Go to the front right corner. Skip one button to the back on the right edge. Put a 1x1 on it.

Step 3.3

Put a 10x1 ver to the back.

Step 3.4

Put a 10x1 hor to the left of the last button of the PP, on the back edge.

Step 3.5

Put a 12x2 ver to the left and to the front, so that it overhangs to the back with one button.

Step 3.6

Put a 6x2 hor to the left, on the back edge, overhanging as before.

Step 3.7

Put a 12x2 ver to the left and to the front, overhanging as before.

Step 3.8

Put a 2x1 hor to the left, on the back edge, not overhanging. It should touch and align at the back with the 16x2 vertical piece on the left.

Step 4.4.1

Put a 6x1 hor to the left of the 16x2 piece, not overhanging, on the back edge.

Step 4.2

Put a 10x1 ver to the left and to the front, on the left edge.

Step 4.3

Put a 10x1 ver to the front.

Step 4.4

Go to the right front corner. Put a 16x2 hor on it, on the front edge, overhanging to the front.

Step 4.5

Put a 6x2 hor to the left, overhanging as before.

Bag 2.

Step 5.5.1

Flip over, horizontally, three long pieces protruding to the back. Put momentarily aside.

Step 5.2

Put a 6x1 hor on the table. Put a 3x2 hor on it, skipping the rightmost button.

Step 5.3

Put a 4x1 hor to the left of the PP.

Step 5.4

Put a 1x1 underneath the 4x1, to the left of the 6x1. Turn vertically, overhanging to the front. Put ver on the last button of the right edge.

Step 5.5

Put a 3x1 hor to the left, on the back edge.

Step 5.6

Put a 10x1 hor to the left.

Step 5.7

Repeat.

Step 5.8

Put a 3x2 ver on the table, put a smooth 6x1 on its right column, aligned at the back, and put this part to the back of the leftmost button of the PP, on the protruding three buttons of the 16x2, so that the 3x2 piece goes to the back of it and is aligned with it at the left. Put the two 10x1 pieces aside. Put the structure momentarily aside.

Bag 3.

Step 6.6.1

Put the 10x1 piece from the previous bag hor on the table. Put a 2x1 underneath the 5th and 6th buttons of it.

Step 6.2

Put a 6x1 hor to the right.

Step 6.3

Put a 10x1 hor to the left of the 2x1.

Step 6.4

Put a 4x1 hor to the right of the top 10x1 piece, overhanging to the right.

Step 6.5

Put a 10x1 from the previous bag hor to the left of the top 10x1, overhanging to the left.

Step 6.6

Put a 10x1 hor to the left of the bottom 10x1.

Step 6.7

Put a 1x1 on the bottom, on the right, to the right of the bottom 6x1.

Step 6.8

Put this part, the way it is, on the back right side of your structure, on one back right-side button.

It should touch the smooth 6x1 from the back.

Bag 4.

Step 7.7.1

Put a 6x1 ver to the left and one button to the back of the smooth piece.

Step 7.2

Put a 2x1 hor to the left.

Step 7.3

Put a 3x1 hor to the left.

Step 7.4

Skip one button to the left and put a 2x1 ver on the left edge.

Step 7.5

Put a 2x1 hor to the front and to the right.

Step 7.6

Put a 1x1 underneath.

Step 7.7

Put a 3x1 ver to the front, on the left edge.

Step 7.8

Put an 8x2 hor to the front and to the right.

Step 7.9

Put a 10x1 hor in the front, in the middle, on the protruding buttons.

From now on the pieces are no longer flat.

Step 8.8.1

Start building the right wall. Go the front right corner. Put a 1x1 on it.

Step 8.2

Put an 8x1 ver to the back.

Step 8.3

Repeat.

Step 8.4

Put a 2x1 ver to the back.

Step 8.5

Put an 8x1 hor to the back and to the left, on the back wall.

Step 8.6

Put an 8x1 hor to the left.

Step 8.7

Repeat.

Step 8.8

Put a 6x1 ver to the left and to the front, to start the vertical partition wall.

Step 8.9

Put a 2x1 hor to the front and to the left, to start the horizontal partition wall.

Step 8.10

Put a 3x1 hor to the left of the vertical 6x1 piece, on the back wall.

Step 8.11

Insert a head connector into the hole of a 2x1 piece and put it hor to the left of the PP, head to

the back.

Step 8.12

Put three flat 8x2 pieces hor side by short side along the front edge of the long rectangular gap, starting from the right wall.

Bag 5

Number 9.

1 Go to the front corner of the right wall. Put a 1x1 on it.

Step 2

put an 8x1 ver to the back.

Step 3

repeat.

Step 4

Put a 2x1 ver to the back.

Step 5

put an 8x1 hor to the back and to the left.

Step 6

Put an 8x1 hor to the left.

Step 7

repeat.

Step 8

put a 6x1 ver to the left and to the front, on the partition.

Step 9

Put a 2x1 hor to the front and to the left, on the horizontal partition line.

Step 10

skip four buttons to the left and put a 2x1 hor on the horizontal partition line and on the left wall.

Step 11

Put a 3x1 ver to the back, on the left wall.

Step 12

Put a 2x1 hor to the back and to the right.

Step 13

Put a 2x1 ver to the back, on the left wall.

Step 14

Go to the front corner of the left wall. Put a 1x1 on it.

Step 16

put a 6x1 ver to the back.

Step 17

go to the right-end front edge of the gap. Put a flat 10x1 hor on the first (front) row of the right-end 8x2 piece and partly on the middle 8x2 piece.

Step 18

put a flat 2x1 hor to the left.

Step 19

put a flat one-button 2x1 hor to the left.

Step 20

put a flat 1x1 to the left.

Step 21

repeat the last two steps pattern two more times.

Step 22

put a flat one-button 2x1 hor to the left.

Step 23

put a flat 2x1 ver to the left and to the back.

Number 10

Step 1

put a flat 10x1 hor on top of the other flat 10x1 on the front edge of the gap.

Step 2

put a flat 1x1 to the left.

Step 3

put a 2x1 ver to the front.

Step 4

go to the left-side edge of the front side. Put a flat 4x2 hor on it, to the right of the left wall, on the first two rows.

Step 5

put a 2x1 hor to the right, on the first row.

Step 6

put a 2x1 hor to the back of the PP.

Step 7

put a flat 4x2 hor to the right of the two PPs.

Step 8

Put a flat 3x1 hor to the right, on the first row.

Step 9

put a 3x1 hor to the back.

Step 10

skipping four buttons to the right, put a 3x1 hor to the right (on the second row).

Step 11

put a 3x1 ver to the back of the rightmost button of the PP.

Step 12

put a flat 3x1 hor to the front of the horizontal 3x1, on the first row.

Step 13

put a flat 4x2 hor to the right, on the first two rows.

Step 14

put two 2x1 hor to the right, symm to the left side.

Step 15

put a flat 4x2 hor to the right.

Step 16

skop two rows to the back and put a flat 2x2 (with the holes inside), skipping one row to the left from the right wall.

Bag 6.

Number 11.

Step 1

put a flat 2x2 disk on top of the PP.

Step 2

put four 4x1 pieces hor to the back of the four flat hor 4x1 pieces at the front wall.

Step 3

go to the left end of the right side of the front wall. Skip a button to the right and put a flat 2x1 hor on top of the flat 3x1 piece.

Step 4

do it symm on the right end of the left side of the front wall.

Step 5

put 9 cones hor on the left front edge of the gap, and one to the back of the leftmost cone.

Step 6

make a pattern in the middle of the floor. Find the vertical 2x1 piece to the right and to the front of the rightmost cone. Skip two buttons to the left and two to the front of it. Put a flat smooth 1x1 on.

Step 7

put a flat smooth 2x1 ver to the front.

Step 8

put a flat smooth 1x1 to the front.

Step 9

put a flat smooth 2x1 hor to the left.

Step 10

Put a flat smooth 2x2 to the back.

Step 11

put a flat smooth 2x1 hor to the back.

Step 12

put a flat smooth 2x1 to the left and to the front.

Step 13

put a flat smooth 2x1 to the front.

Step 14

put a flat smooth 2x1 hor to the left, aligned at the front.

Step 15

put a flat smooth 2x1 to the back.

Step 16

Put a flat smooth 2x1 hor to the back.

Step 17

put a flat smooth 1x1 to the left.

Step 18

put a flat smooth 2x1 ver to the front.

Step 19

put a flat smooth 1x1 to the front.

Bag 7.

Number 12.

Step 1

go to the front end of the right wall. Put a 3x1 ver on it.

Step 2

put an 8x1 ver to the back.

Step 3

put a 6x1 hor to the back and to the left.

Step 4

put a 6x1 hor to the left.

Step 5

put a 2x1 ver to the front of the leftmost button of the PP.

Step 6

put a flat smooth 6x1 hor to the left of the last 6x1 piece, on top of the cones.

Step 7

put a flat smooth 6x1 hor to the left of the PP.

Step 8

put a flat smooth 2x1 ver to the left and to the back.

Step 9

Put a 6x1 ver to the back.

Step 10

put a 1x1 to the left of the foremost button of the PP.

Step 11

go back to the middle of the right wall to continue building its second level.

Step 12

put an 8x1 ver on it to finish the second level.

Step 13

put a 6x1 hor to the left, on the back wall.

Step 14

put a 6x1 hor to the left.

Step 15

repeat.

Step 16

put an 8x1 hor to the left.

Step 17

put a 3x1 hor to the left.

Number 13.

Step 1

Fill the four four-button gaps in the front wall in the following manner: a 1x1 piece with the side button (to the front) - 2x1 hor - a 1x1 piece with the side button.

Step 2

Take a small "smoking pipe" piece and put it on the table ver, wide mouth on the table, clasp toward you. Put another one on top on the same manner.

Step 3

Repeat to make another such part.

Step 4

Put these two parts, the way they are, on the front side, on top of the flat 1x1 buttons to the left and to the right of the center opening gap.

Number 14.

Step 1

Put a flat 3x1 hor on top of the left PP and the two buttons to the left, and another flat 3x1 symm on the right.

Step 2

put a 3x1 hor to the back of the left PP.

Step 3

skip four buttons to the right and put a 2x1 hor to the back of the other flat 3x1 piece.

Step 4

put a 3x1 ver to the right and to the back of the PP.

Step 5

put a 1x1 to the back.

Step 5

go back to the front wall. Skip four buttons to the right from the right-side flat 3x1 piece and put a flat 2x2 on the first and second rows of the front wall (in between two 1x1 pieces with the side buttons).

Step 3

Put another flat 2x2 symm on the left.

Step 4

go to the front end of the left wall. Put a 6x1 ver on it.

Step 5

put a 6x1 ver to the back.

Step 6

put an 8x1 ver to the back.

Bag 8.

Number 15.

Step 1

Put the 1x1 buttons (they are different colors and are supposed to be flowers) and 1x1 leaflets on the front row, but not on the 2x2 pieces. The leaflets go underneath some of the "flowers".

Step 2

make a seat. Put a flat smooth 2x1 and flat 2x1 on a flat 2x2. Put a 1x1 button underneath the part, in the middle. Rotate the whole structure 180 degrees. Install the seat next to the back (now!) wall, skipping one column to the left from the vertical partition on the left side of the back wall. Two buttons of the seat should be vertical and on the right.

Bag 9.

Number 15.

Step 1

Make a chair. Put a flat 2x1 with the handle on a flat 2x2. Put a flat 2x1 with the clasps onto the handles, upright. Put a flat smooth 2x1 on the PP. Put another flat smooth 2x1 on the two free buttons of the 2x2. Put a 1x1 button underneath the part, in the middle. Install in the right back corner, skipping one column to the left, the back of the chair to the back, next to the back wall.

Bag 10.

Number 16.

Step 1

Make a small table. Put a flat 3x2 hor on the table. Put a flat one-button 2x1 piece ver on the right two buttons of it. Put another flat one-button 3x1 hor to the left, on the front row. Put two flat smooth 1x1 pieces to the back. put four 1x1 buttons on the smaller ends of the four cones and put these cones underneath the table, to make legs. Put this table in front of the chair in the right back corner, hor. Put a flat smooth 2x1 letter (in the separate bag) on this table, on one of the buttons, at an angle.

Step 2

Make a desk. Put a flat 6x1 hor on the table (your table!). Put a flat smooth 2x1 (from a sep. bag) ver on the left end. Put a flat one-button 2x1 (from a sep. bag) ver to the right. Put a flat smooth 2x1 (from a sep. bag) hor to the right, at the back. Put a flat smooth 2x1 hor to the front. Put a flat smooth 2x1 (from a sep. bag) hor to the right. Put a flat one-button 2x1 (from a sep. bag) hor to the back. Put two 2x1 with the ribbed sides ver underneath, on the right and on the left ends. Put two flat 2x1 underneath the PPs. Install ver to the left of the seat, skipping one row from the back wall.

Bag 11.

Number 17.

Step 1

Make an armchair. Put a flat 2x1 with the handle on a flat 2x2. Put a flat 2x1 with the clasp onto it. Put two flat 1x1 clasps on the two free buttons, clasps outward. Put two gun pieces into these clasps, handles in, muzzles to the back, to make the armrests. Put a flat 2x2 with the semicircle (the "washer board" piece) upright on the back. install to the left of the desk, next to the left wall, facing right.

Step 2

Make a lamp. Put a 1x1 button on a cup. Put an inverted saucer on the button. Install on the desk. Put a frog piece on the desk.

Step 3

Make a flower vase. Put a leaflet piece on a cylinder. Put a 1x1 button from the next bag on the leaflet. Install on the small table.

Bag 12.

Number 18.

Step 1

Rotate the structure 180 degrees. Go to the front end of the right wall. Put a 1x1 on it.

Step 2

Put an 8x1 ver to the back.

Step 3

Repeat.

Step 4

Put a 2x1 hor to the left of its third button, on the partition.

Step 5

Put a 2x1 hor to the back and to the left of the 8x1 piece, on the back wall.

Step 6

Put a 2x1 hor to the right.

Step 7

Skip four buttons to the left and put a 3x1 hor on the back wall.

Step 8

Repeat.

Step 9

Skip four buttons to the left and put 2x1 hor.

Step 10

Put a 6x1 ver to the left and to the front.

Step 11

Put a 1x1 to the front.

Step 12

Put a 3x1 hor to the left of the 6x1, on the back wall.

Step 13

Put a 2x1 hor to the left.

Step 14

Make three ledges. Put a flat smooth 4x1 on a flat 4x2. Put two flat 2x1 with the cornices on the free buttons. Repeat to make three such parts. Install in the back wall, hor, in the three gaps, cornices to the front and ledges protruding to the back.

Number 19

Step 1

Go to the front wall. Put a 2x1 hor on the right end of the left side of the front wall, skipping one button to the left from the middle. It should be on the flat horizontal 3x1 piece, but not on its rightmost button.

Step 2

Put a 2x1 hor to its back.

Step 3

Repeat 1-2 symm on the right side.

Step 4

Put a 3x1 ver to the back, on the right side, to make the next level of desk-and-armchair partition.

Step 5

Skip four buttons to the back and put a 3x1 ver on the continuation of the partition.

Step 6

Put a 2x1 hor to the right and to the back.

Step 7

Put a flat smooth 2x1 hor to the right.

Step 8

Repeat.

Step 9

Repeat.

Step 10

Go to the front end of the left wall. Put a 1x1 on it.

Step 11

Put a 6x1 ver to the back.

Step 12

Repeat.

Step 13

Put a 2x1 hor to the back and to the right.

Step 14

Put a 6x1 ver to the back, on the back wall.

Number 20.

Step 1

Put a 3x1 hor to the right.

Step 2

Put an 8x1 ver to the front, on the right wall.

Step 3

Put a 3x1 ver to the front.

Step 4

Go to the front end of the left wall. Put a 6x1 ver on it.

Step 5

Put a 6x1 ver to the back.

Step 6

Put an 8x1 ver to the back.

Step 7

Put a 1x1 to the right of the its 7th button from the back.

Step 8

Put an 8x1 hor on the left end of the back wall.

Step 9

Put a 6x1 ver to the front of its 6th button from the left, to make the next level of the elevator partition.

Step 10

Put three 3x1 hor on the back wall, in between the window gaps.

Step 11

Put an 8x1 ver to the right and to the front of the last 3x1 piece, on the back of the right wall.

Bag 13.

Number 21.

Step 1

Insert a five-column curved balustrade piece into the four clasps in the middle of the front wall, curving toward you and buttons on top.

Step 2

Put a flat 2x1 into a "phone receiver" piece. Repeat to make four such parts. Install hor, upright, on the front wall, mounting on the side buttons on the face of the front wall.

Step 3

Go to the right end of the left side of the front wall. Put two 2x1 ver, side by long side, on the two 2x1 pieces.

Step 4

Put a 2x1 shelf piece ver to the right, indent facing right.

Step 5

Put another shelf piece symm on the right side.

Step 6

Put a 2x1 ver to the right.

Step 7

Put a 3x1 ver to the right.

Step 8

Put a 2x1 ver to the back.

Number 22

Step 1

Put one 1x1 with the side button on top of another. Put two flat smooth 1x1 buttons on the side buttons. Install to the rightmost button of the front edge in front of the elevator gap, on top of the 1x1, side buttons to the front.

Step 2

Put a 2x1 hor to the left of the curved balustrade, on the second row.

Step 3

Put a 2x1 hor to the back.

Step 4

Repeat 2-3 symm on the right.

Step 5

Put a 3x1 ver to the back of the last piece, on the partition.

Bag 14

Number 22

Stack up four curved 2x1 pieces. Repeat to make four such parts. Put hor on the front row, between the "phone receivers".

Bag 15.

Number 23

Step 1

Insert two window halves into each window frame and install in the back wall.

Step 2

Put a tall tube in the elevator shaft, as in the first book.

Step 3

Go to the front end of the right wall. Put a 1x1 on it.

Step 4

Put an 8x1 ver to the back.

Step 5

Repeat.

Step 6

Put a 1x1 to the left of the third button (from the front!) of the PP.

Step 7

Put an 8x1 arch piece hor to the left.

Step 8

Put a 1x1 to the left.

Step 9

Put a 3x1 ver to the left and to the front.

Step 10

Cont. the right wall. Put a 2x1 ver to the back of the 8x1 piece on it.

Step 11

Put a 2x1 hor to the back and to the left.

Step 12

Put 2x1 hor to the left.

Step 13

Put a 3x1 hor skipping the window to the left.

Step 14

Repeat.

Step 15

Put a 2x1 hor skipping the window to the left.

Step 16

Put a 6x1 ver to the left and to the front.

Step 17

Put a 2x1 hor to the front and to the left.

Step 18

Cont. the back wall to the left, putting a 3x1 hor and then a 2x1 hor.

Step 19

Go the back end of the left wall. Put a 6x1 ver on it.

Step 20

Put a 2x1 hor to the front and to the right.

Step 21

Put a 6x1 ver to the left and to the front, to cont. the left wall.

Step 22

Put a 6x1 ver to the front.

Step 23

Put a 1x1 to the front.

Bag 16

Number 24.

Insert the windows into the frames, make eight two-piece stacks and install them by pairs in the front wall.

Bag 17.

Number 25.

Step 1

Put the button into the door, the door into the frame and install hor on the front partition of the elevator shaft so that it opens to the front and to the left.

Step 2

Put a 1x1 to the right of the door.

Step 3

Put a 6x1 ver to the front and to the back.

Step 4

Put a 6x1 ver on the front end of the left wall.

Step 5

Put a 6x1 ver to the back.

Step 6

Put an 8x1 ver to the back.

Step 7

Put an 8x1 hor on the left end of the back wall.

Step 8

Put three 3x1 hor to the right, in between the windows.

Step 9

Put an 8x1 ver on the back end of the right wall.

Step 10

Put a 2x1 hor to the front and to the left.

Step 11

Put a 3x1 ver to the front, on the right wall.

Step 12

Put a 1x1 with the side button to the front, side button to the left.

Step 13

Repeat.

Step 14

Put a 6x1 ver to the front.

Bag 18.

Number 26

Step 1

Put a button in the door, the door into the frame and install ver in the vertical partition of the right side, to the left of the desk, so that it opens to the left and to the back.

Step 2

Put a 6x1 ver to the front of this door.

Step 3

Put a 2x1 ver to the left of this piece, next to its second and third buttons.

Step 4

Put a shelf piece ver to the left, on top of the other shelf piece, shelf to the left.

Step 5

Put a 2x1 ver to the back of this door.

Step 6

Put a 2x1 hor to the back and to the front of the PP.

Step 7

Hang a picture (2x2 flat smooth piece) of a Viking ship on the night sea on the right wall, on the two side buttons from the previous bag.

Step 8

Go to the front wall. Put a flat 4x2 hor on top of the left window.

Step 9

Put a flat 2x2 to the right.

Step 10

Put a flat 4x2 hor to the right.

Step 11

Repeat steps 8-10 symm on the right.

Bag 19.

Number 27.

Step 1

Put a button onto the glass pane, insert into the door frame and install hor in the middle of the front wall so that it opens to the back and to the right.

Step 2

Go to the left side of the front wall. Put a flat 2x1 ver on it.

Step 3

Skip two buttons to the right and put a flat 4x2 hor.

Step 4

Skip two buttons to the right and put a 2x1 ver.

Step 5

Repeat steps 2-4 symm on the right.

Number 28

Step 1

Put a flat smooth button on top of a 2x1 one-button piece. repeat to make four such parts. Put them hor. on the front wall, on its first row, in the gaps between the flat pieces.

Step 2

Go to the leftmost such part. Go to the second row, behind it. Leaving the two-button gap there free, put two 1x1 wedge pieces to the sides of it, taller sides facing each other. Repeat three times, behind each smooth-button part.

Step 3

Put a flat smooth 6x1 horon the front wall, in the middle, over the door, on the second row.

Bag 20

Number 29

Step 1

Go to the front end of the left wall. Skipping the first button, put a 6x1 ver on it.

Step 2

Put a 6x1 ver to the back.

Step 3

Put a 3x1 hor to the back and to the right.

Step 4

Put a 1x1 button with the side button to the right, the side button facing front.

Step 5

Repeat.

Step 6

Put a 3x1 hor to the right.

Step 7

Put a 6x1 ver to the back of its rightmost button.

Step 8

Put a 3x1 hor to the left.

Step 9

Put a 2x1 hor to the left.

Step 10

Cont. the left wall. Put a 3x1 ver to the back of the horizontal 3x1.

Step 11

Put a 2x1 hor to the back and to the right.

Step 12

Put a 2x1 ver to the back.

Step 13

Cont. the back wall. Put an 8x1 hor to the right of the vertical 6x1.

Step 14

Put a 6x1 hor to the right.

Step 15

Put an 8x1 hor to the right,

Step 16

Put a 2x1 hor to the right.

Step 17

Put a 2x1 ver to the front.

Step 18

Put an 8x1 ver to the front.

Step 19

Repeat.

Step 20

Put a 2x1 hor to the front and to the left.

Step 21

Skipping the smooth-button part, put a 2x1 hor to the left.

Step 22

Put a 2x1 hor to the left.

Step 23

Skipping the smooth-button part, put a 2x1 hor to the left.

Step 24

Put a 1x1 to the front of its leftmost button.

Step 25

Put a 4x1 hor to the left of the horizontal 2x1 piece.

Step 26

Repeat.

Step 27

Put a 2x1 hor to the left.

Step 28

Put a 1x1 to the front, symm. to the previous 1x1 piece.

Step 29

Skipping the smooth-button part, put a 2x1 hor to the left.

Step 30

Put a 2x1 hor to the left.

Step 31

Skipping the smooth-button part, put a 2x1 hor to the left.

Bag 21

Number 31

Step 1

Put an 8x1 arch piece hor in the middle of the front wall, in the first row.

Step 2

Make four window arches. Put a 2x1 flat piece hor on the first row of the bumper piece, bumper facing front. Put two wedge pieces on the back row, taller ends facing each other. Repeat to make four. Install over the front-wall windows.

Number 32

Step 1

Put a flat 6x1 hor over the elevator shaft wall.

The rest of the pieces are all flat and smooth.

Step 2

Go to the left end of the back wall. Put a 1x1 on.

Step 3

Put a 2x1 hor to the right.

Step 4

Put four 6x1 hor to the right.

Step 5

Put a 2x1 hor to the right.

Step 6

Put a 2x1 ver to the right and to the front.

Step 7

Put a 6x1 ver to the front, on the right wall.

Step 8

Put a 6x1 hor to the front and to the left, on the partition.

Step 9

Put a 6x1 hor to the left.

Step 10

Put a 2x1 ver to the front, on the vertical partition.

Step 11

Put a 6x1 ver to the front.

Step 12

Put a 2x1 ver to the front.

Bag 22

Number 33

Step 1

Go to the back end of the left wall. Put a two-button 4x1 ver on it.

Step 2

Put a 1x1 to the right, on the jutting formation inside the shaft.

Step 3

Cont. the left wall. Put a 2x1 ver to the front of the two-button piece.

Step 4

Put a 2x1 ver to the front.

Step 5

Put a 6x1 ver to the front.

Step 6

Repeat.

Step 7

Put a 6x1 hor to the right, on the front wall.

Step 8

Repeat four times.

Step 9

Put a two-button 4x1 ver to the right and to the back, on the right wall.

Step 10

Put a 6x1 ver to the back.

Step 11

Go to the middle of the front wall. Put a 2x1 hor, then a 6x1 hor, then a 2x1 hor on the first row, over the balcony.

Step 12

Put on top of the first floor.

The end of the second book.

Town Hall book 3

Bag 1.

Number 1

Step 1

Put a flat 16x2 ver on the table.

Step 2

Put a flat 24x6 hor on the front, to the right, so that the leftmost column of it is on top of the six right-side buttons of the PP.

Number 2

Step 1

Put a flat 24x6 hor to the back.

Step 2

Put a flat 8x6 hor to the left.

Step 3

Put a flat 8x6 hor to the front.

Number 3.

Step 1

Flip the structure upside down so that the long piece protrudes to the front at the left. Put a flat 2x1 hor to the left of the long piece, at the back.

Step 2

Put a flat 12x2 ver to the right, so that it protrudes one button-long to the back.

Step 3

Put a flat 6x2 hor to the right, aligned at the back.

Step 4

Put a flat 12x2 ver to the right, symm with the first 12x2 piece.

Step 5

Put a flat 10x1 hor to the right, aligned with the 2x1 piece.

Step 6

Put a flat 10x1 ver to the right and to the front.

Step 7

Put a flat 1x1 to the front.

Number 4.

Step 1

Put a flat 16x2 hor to the front and to the left.

Step 2

Put a flat 6x1 hor to the left.

Step 3

Put a flat 2x1 ver to the left.

Step 4

Skip over the long protruding piece to the left, go to the back edge and put a flat 6x1 hor to the left, aligned with the 2x1 piece on its right (skipping the protruding piece).

Step 5

Put a flat 10x1 ver to the left and to the front.

Step 6

Put a flat 10x1 ver to the front.

Bag 2.

Number 5.

Step 1

Flip over so that the long protruding pieces are to the back and the protruding "step" is in the middle of the front edge. Put momentarily aside. Put a flat 6x1 piece hor on the table. Put a flat 3x1 on top, skipping the rightmost button. Put a flat 4x1 to the left. Put a flat 1x1 underneath, to the left of the bottom piece. Turn this part ver, so that the overhanging end faces to the front. Put it on the structure, at the back of the right edge.

Step 2

Put a flat 3x1 hor to the left, at the edge of what is now the back edge (but is in fact the front edge of the large gap).

Step 3

Put a flat 10x1 hor to the left.

Step 4

Repeat.

Step 5

Put a flat 3x2 ver on the table. Put a flat smooth 6x1 ver on the right column of it so that the three button-space of it protrudes forward. Put to the back of the leftmost button of the PP. Put the remaining pieces separately.

Bag 3.

Number 6.

Step 1

Put a flat 10x1 from the previous bag on top of a flat 2x1, so that four buttons overhang from either side.

Step 2

Put a flat 6x1 hor to the right of the 2x1, so that two buttons of it protrude to the right.

Step 3

Put a flat 10x1 hor to the left of the 2x1, so that six buttons of it protrude to the left.

Step 4

Put a flat 4x1 hor to the left of the top 10x1, so that two buttons of it overhang to the right.

Step 5

Put a flat 10x1 from the previous bag hor to the left of the top 10x1, so that four buttons of it overhang to the left.

Step 6

Put a flat 10x1 hor underneath, so that six buttons of it protrude to the left.

Step 7

Put a flat 1x1 underneath the right side, so that one button still overhangs to the right.

Step 8

Put this part hor on the structure, so that it forms its back wall, closing the large gap perimeter.

Bag 4

Number 7

Step 1

Go to the back end of the left wall. Put a flat 2x1 ver on it.

Step 2

Put a flat 2x1 hor on the table, put a flat 1x1 underneath its right button, and put as is to the front and to the right of the PP.

Step 3

Put a flat 3x1 ver to the front, on the back wall.

Step 4

Put a flat 8x2 hor to the front and to the right.

Step 5

Put a flat 6x1 ver to the back of its rightmost column.

Step 6

Put a flat 2x1 hor to the left of its last button.

Step 7

Put a flat 3x1 hor to the left.

Step 8

Put a flat 10x1 hor on the protruding step in the middle of the front edge.
Number 8.

Step 1

Insert a head connector into the hole of a 2x1 piece. Put this part hor, head to the back, on the leftmost end of the back wall.

Step 2

Put a 3x1 hor to the right.

Step 3

Put an 8x1 hor to the right.

Step 4

Repeat.

Step 5

Repeat.

Step 6

Put a 3x1 ver to the right and to the front.

Step 7

Put an 8x1 ver to the front.

Step 8

Repeat. It should leave the front button of the base free.

Step 9

Go to the vertical bridge between the elevator shaft and the large gap. Starting from the back wall, put a 3x3 ver on it. Put a 3x1 ver to the front.

Step 10

Put a 1x1 to the left of the front button of the PP.

Step 11

Put a flat 8x2 hor to the right and to the front of the PP, starting at the front of the vertical 3x1. Put a flat 8x2 hor to the right. Repeat. It should touch the right wall.
Number 9.

Step 1

Go to the front button of the right wall. Put an 8x1 hor to the left of it, on the second row of the

base.

Step 2

Put a 3x1 hor to the left.

Step 3

Put an 8x1 hor to the front and to the left, touching corners with the PP, on the first row of the base, but not on the protruding step.

Step 4

Put a 3x1 hor to the back and to the left, touching corners with the PP.

Step 5

Put an 8x1 hor to the left.

Step 6

Go to the back end of the left wall. Count seven buttons to the front and put a 1x1 to the right of the 7th button, leaving a four-button gap on the front edge of the elevator shaft.

Bag 5.

Number 10.

Step 1

Go to the leftmost button of the front edge. Put a 1x1 lip piece on it, lip forward (as will be all the rest of the lip pieces).

Step 2

Put a cone to the right.

Step 3

Put a 2x1 lip to the right.

Step 4

Put a cone to the right.

Step 5

Put a 2x1 lip to the right.

Step 6

Put a cone to the right.

Step 7

Put a 2x1 lip to the right.

Step 8

Put a cone to the right.

Step 9

Put another cone to the right.

Step 10

Repeat steps 1-9 symm on the right.

Step 11

Go to the right end of the protruding step in the middle of the front edge. Put a 3x1 hor on it.

Step 12

Put a 1x1 with the side button to the left, button to the front.

Step 13

Put a 2x1 hor to the left.

Step 14

Put a 1x1 with the side button to the left, as before.

Step 15

Put a 3x1 hor to the left.

Number 11 (all flat)

Step 1

Go to the back end of the left wall. Put a 6x1 ver on it.

Step 2

Put a 2x1 hor to the front and to the right.

Step 3

Put a 3x1 ver to the front, on the left wall.

Step 4

Put a 2x1 ver to the front.

Step 5

Put a 6x1 ver to the front.

Step 6

Put an 8x2 hor to the front and to the right, leaving the lip buttons on the front wall free.

Step 7

Put a 4x2 hor to the right.

Step 8

Put a 4x1 hor to the right, aligned to the PP at the front.

Step 9

Put a 4x1 hor to the right.

Step 10

Put a 4x2 hor to the right, as before.

Step 11

Put an 8x2 hor to the right.

Step 12

Put a 6x1 ver to the back of the rightmost column of the PP.

Step 13

Put a 6x1 ver to the back.

Step 14

Put a 2x1 ver to the back.

Step 15

Put a 3x1 ver to the back.

Step 16

Put a 10x1 hor to the back and to the left.

Step 17

Put a 10x1 to the left.

Step 18

Repeat.

Step 19

Put a 2x1 ver to the front of the 6th button from the left of the PP.

Step 20

Put a 3x1 ver to the front.

Step 21

Put a 2x1 hor to the front and to the left. Put aside.

Bag 6.

Number 12 (all flat)

Step 1

Put a 12x2 hor on the table. Put two 6x1 hor to the back, side by short side.

Step 2

Take four 3x1 smooth pieces from a separate bag. Connect the part by putting two smooth pieces ver, side by long side, on its leftmost two columns, and two on the right.

Step 3

Put two smooth 3x1 pieces hor on the front edge, one on the right and one the left, so that there is a two-button space in between. Put a smooth 2x1 hor there.

Repeat step 3 on the back edge.

Put a smooth 2x1 hor, smooth 4x1 hor, smooth 2x1 hor sequence in the middle row.

Step 4

Flip over. Put 2x1 ver on the third column from the right, and the other one on the left. Insert the four cones small end first into the ends of the two PPs. Install this part hor in the middle of the structure, skipping two rows to the front from the front gap edge and nine columns to the right from the left wall. Put momentarily aside.

Bag 7.

Number 13

Step 1

Make a seat. Put a flat 2x1 and a flat smooth 2x1 on top of a flat 2x2 and put a button underneath, in the middle. Repeat to make six such seats. Install three in front of the table, smooth sides hor and to the back, with the one-button space between the seats, and three at the back of the table, smooth sides hor and to the front.

Step 2

Put a flat 2x1 between two stapler pieces to connect them. Install this part upright, hor, in the middle of the front wall, hanging on the two side buttons.

Step 3

Put sixteen cones on the front edge of the large gap.

Bag 8

Number 14

Step 1

Put a flat smooth 3x1 hor on the leftmost end of the front wall, on the first row - on top of the lips.

Step 2

Put a flat smooth 8x1 hor to the right.

Step 3

Put a flat 2x1 hor to the right.

Step 4

Put six buttons to the right, two of them on the leaflets.

Step 5

Put a flat 2x1 hor to the right.

Step 6

Put a flat smooth 8x1 hor to the right.

Step 7

Put a flat smooth 3x1 hor to the right.

Step 8

Put two buttons and a leaf piece on a 2x2 cylinder. Repeat. Put one at the left front corner, inside the

walls, and one at the right.

Bag 9

Number 15.

Step 1

Make three window ledges. Put a flat 4x2 hor on the table. Put a flat smooth 4x1 on the second row. Put two flat 2x1 cornice pieces hor on the front row. Repeat to make three.

Step 2

Put a 3x1 hor on the left of the back wall.

Step 3

Put a 2x1 hor to the right.

Step 4

Put a 6x1 ver to the right and to the front.

Step 5

Put a 2x1 hor to the front and to the left of the PP.

Step 6

Put a 2x1 hor to the right of the 6x1 on the back wall.

Step 7

Put the ledge hor to the right, smooth part to the back.

Step 8

Put a 3x1 hor to the right.

Step 9

Put the ledge.

Step 10

Put a 3x1

Step 11

Put the ledge.

Step 12

Put a 2x1 hor.

Step 13

Put a 2x1 hor.

Step 14

Put an 8x1 ver to the front.

Step 15

Repeat.

Step 16

Put a 2x1 ver to the front.

Number 16

Step 17

Cover the cones on the front edge of the gap with four flat smooth pieces.

Step 18

Put a 6x1 ver on the back of the left wall.

Step 19

Put a 2x1 hor to the front and to the right.

Step 20

Put a 6x1 ver to the front.

Step 21

Repeat.

Step 22

Put a 2x1 hor to the front and to the right.

Bag 10, number 17.

Step 1

Make a globe. Put a cone on the flat 2x2 with one button, narrow end up. Put a crossbar stick into the cone, ver. Put a saucer on the stick, edges up. Put a cylinder on the stick. Put two halves of the globe on. install the globe in the right back corner, skipping one column from the right wall, to the front of the flat row of the buttons to the front of the edge-gap colonnade.

Step 2

Put a 2x1 wedge hor on the left edge of the front wall, to the right of the 2x1, thin edge to the front.

Step 3

Skip four buttons to the right and repeat.

Step 4

Put a 3x1 hor to the right.

Step 5

Put a 1x1 to the back of the second button of the PP.

Step 6

Put a 1x1 to the right of the 3x1 piece.

Step 7

Skip four buttons to the right and put a 1x1 on.

Step 8

Put a 3x1 hor to the right.

Step 9

Put a 1x1 to the back of the second button of the PP.

Step 10

Put a wedge hor to the right.

Step 11

Skip four buttons to the right and repeat.

Bag 11 number 18

Step 1

Make a chair. Turn a flat 3x2 upside down, put four buttons into four corners, flip over, put a 2x1 on one short edge, put the other 2x1 on top, put a prism piece on top, the slide side facing the seat, put a 2x2 with the wings on the seat to make the seat with the handles. Install at the right side of the long table in the middle, facing left.

Step 2

Put an 8x1 ver at the back of the left wall.

Step 3

Put a 1x1 to the right, at the elevator partition.

Step 4

Put a 6x1 ver to the front.

Step 5

Repeat.

Step 6

Put a 1x1 to the left, on the front wall.

Step 7

Skip eight buttons to the right (including the wedges) and put a 1x1 on. Open bag 12.

Step 8

Put a 2x1 ver to the right.

Step 9

Put a 2x1 hor to the right.

Step 10

Skip four buttons to the right and put a 2x1 hor.

Step 11

Put a 2x1 ver to the right.

Step 12

Put a 1x1 to the right.

Step 13

Skip eight buttons to the right (including the wedges) and put a 1x1 on.

Step 14

Put a 2x1 ver to the right.

Step 15

Put an 8x1 ver to the back.

Step 16

Repeat.

Step 17

A 2x1 ver to the back.

Step 18

Put a 3x1 hor to the left.

Step 19

Skip the ledge and repeat.

Step 20

Repeat.

Step 21

Skip the ledge and put an 8x1 hor.

Step 22

Put an 8x1 ver on the elevator partition.

Step 23

Make the elevator buttons and install them as before.

Number 20

Step 24

Install the frames into the three windows and put them into the back wall, on the ledges.

Step 25

Put a 3x1 hor on the left end of the back wall.

Step 26

Put a 2x1 hor to the right.

Step 27

Put a 6x1 ver to the right, on the partition.

Step 28

Put a 1x1 to the front.

Step 29

Put a 2x1 hor to the right of the 6x1, on the back wall.

Step 30

Put a 3x1 hor between the windows.

Step 31

Repeat.

Step 32

Put a 2x1 hor to the right of the right window.

Step 33

Put a 2x1 hor to the right.

Step 34

Put an 8x1 ver to the front.

Step 35

Repeat.

Step 36

Put a 2x1 ver to the front.

Step 37

Put a 2x1 hor to the front and to the left.

Step 38

Skip eight buttons to the left and put a 3x1 hor on.

Step 39

Put a 1x1 to the back as before.

Step 40

Put a 1x1 to the left of the 3x1.

Step 41

Skip four buttons to the left and put a 1x1 on.

Step 42

Put a 3x1 hor to the left.

Step 43

Put a 1x1 to the back as before.

Step 44

Put a 2x1 hor on the left end of the front wall.

Step 45

Put a 6x1 ver to the back.

Step 46

Repeat.

Step 47

Put a 2x1 hor to the back and to the right.

Step 48

Put a 6x1 to the back, on the left wall.

Bag 13, number 22

Step 1

Make ten two-storied windows, with panes. Put two such sets in the middle of the front wall, in between the walls, on the first row. Put one set in the left corner of the front wall, on the second row. Skip two buttons to the right and put another set in. Do the same on the right side.

Step 2

Put a 2x1 hor on the front wall, to the left of the middle window.

Step 3

Repeat on the right.

Step 4

Put a 2x1 ver to the right of the PP.

Step 5

Repeat on the left.

Bag 15. Number 23

Step 1

Stack up four 2x1 curved pieces. Repeat to make six such parts. Put one hor on the front wall, on the two buttons to the right of the flowers in front of the middle window. Repeat on the left.

Step 2

Put two parts hor, side by long side (one in the first row and one in the second), in between the two windows on the left side, in the front wall.

Step 3

Repeat on the right.

Bag 14. Number 23

Step 1

Put an 8x1 hor on the left side of the back wall.

Step 2

Put a 6x1 ver on the partition.

Step 3

Put a 1x1 to the left.

Step 4

Put three 3x1 pieces hor on the back wall, between the windows.

Step 5

Put a 2x1 ver at the back of the right wall.

Step 6

Put two 8x1 ver to the front.

Step 7

Put a 2x1 ver to the front.

Number 24.

Step 1

Put an 8x1 ver at the back of the left wall.

Step 2

Put a 1x1 to the left, on the partition.

Step 3

Put two 6x1 to the front, on the left wall.

Step 4

Make four stacks of three 1x1 pieces each. Put two such pieces at the sides of the leftmost curved stack, and two at the sides of the rightmost curved stack.

Step 5

Put a flat 1x1 on top of the back elevator partition, next to the left wall. Not on the front partition!

Bag 16 number 25

Step 1

Put a 3x2 hor on the left end of the back wall.

Step 2

Put a 2x1 hor to the right.

Step 3

Put a 2x1 ver to the right and to the front, on the partition wall.

Step 4

Make a ladder. Put one flat 2x1 on top of another. Put a flat 2x1 with the handle on top. Attach the ladder. Put ver, ladder to the left, to the front of the PP.

Step 5

Put a 2x1 ver to the front.

Step 6

Put an 8x1 hor on the back wall.

Step 7

Put a 6x1 hor to the right.

Step 8

Put an 8x1 hor to the right.

Step 9

Put a 2x1 hor to the right.

Step 10

Put three 6x1 pieces ver to the front, on the right wall. The front button of the wall should remain free.

Number 26

Step 1

Make the elevator door and install as before.

Step 2

Put one flat 2x1 on top of the other and put them hor to the right of the elevator door.

Step 3

Repeat on the left.

Step 4

Put a 3x1 ver to the back.

Step 5

Put a 2x1 hor to the back and to the right.

Step 6

Put a 2x1 ver to the back.

Step 7

Put four 3x1 arches hor in the front wall, two on the left and two on the right.

Number 27.

Step 1

Put a flat 4x1 hor on top of the front middle window.

Step 2

Put a flat 1x1 sandwiched between two flat 1x1 with the roll and put this part to the left of the PP.

Step 3

Repeat on the right.

Step 4

Put two flat 4x1 pieces hor, side by short side, on top of the elevator door.

Step 5

Put a 6x1 ver to the front, on the left wall.

Step 6

Put a 6x1 ver to the front.

Step 7

Put a 3x1 hor to the right, on the front wall (on the second row).

Step 8

Put an 8x1 hor to the right (one button remains free to the right, before the rolls).

Step 9

Put an 8x1 hor and a 3x1 hor symm on the right side.

Bag 17

Number 28

Step 1

Put a 1x1 with the side button on the leftmost button of the front wall, on the first row, button to the front.

Step 2

Put a 2x1 with the groove hor to the right, groove to the front.

Step 3

Repeat.

Step 4

Insert a connector into a 2x1 with the hole, long side first, and put this part hor to the right, connector to the front.

Step 5

Put a 2x1 grooved piece to the right, as before.

Step 6

Repeat.

Step 7

Put a 2x1 ver to the right, on the first and second row.

Step 8

Repeat.

Step 9

Repeat steps 1-8 symm on the right.

Bag 18.

Number 29

Step 1

Put a flat 2x1 with the wings on the table, wings to the front and to the back, the cut-off corners of the wings to the left. Put the other winged piece symm to the right. Connect by putting a flat 4x1 hor on the back row. Put a flat smooth 1x1 on the first row on the rightmost button, and the other on the leftmost. Put a flat 2x1 hor in between. Install this part hor, the way it is, on top of the front middle window, overhanging to the front.

Step 2

Put four flat smooth buttons upright on the front-side buttons (and connectors) on the front wall.

Number 30

Step 1

Put a flat 6x1 hor on top of the elevator-door wall.

Step 2

The rest of the pieces in this bag are all flat smooth. Put a 6x1 ver to the right and to the back, on the elevator partition.

Step 3

Put a 2x1 hor on the left side of the back wall.

Step 4

Put a 6x1 hor to the right.

Step 5

Put a 3x1 hor to the right.

Step 6

Put a 6x1 hor to the right.

Step 7

Repeat.

Step 8

Repeat.

Step 9

Put a 2x1 ver to the right and to the front.

Step 10

Put a 6x1 ver to the front.

Step 11

Repeat.

Step 12

Put a 4x1 with two buttons ver to the front.

Number 31

Step 13

Put a 4x2 hor to the front and to the left.

Step 14

Put a 4x2 hor to the left.

Step 15

Repeat.

Step 16

Put an 8x1 hor to the left, on the second row (so that the two buttons of the first row, in the middle, remain free).

Step 17

Put the three 4x2 pieces symm on the left.

Step 18

Put a 2x1 hor on the left curved column in the front wall, to the front of the 4x2 and 8x1 piece.

Step 19

Repeat on the right.

Step 20

Put a 2x1 ver on the front end of the left wall.

Step 21

Put a 6x1 ver to the back.

Step 22

Repeat.

Step 23

Put a 4x1 with two buttons ver to the back.

Step 24

Put a 1x1 to the right, on the elevator partition.

Step 25

Put a 6x1 hor on the elevator-door wall. Put the structure aside.

Bag 19 - all flat.

Number 1.

Step 1

Begin the roof. Put a 24x6 hor on the table. Put a 16x2 ver on the left, the six first buttons of the right column under the leftmost column of the big piece.

Number 2.

Step 2

Put another big piece hor to the back of the first, the same way, on top of the long piece.

Step 3

Put an 8x6 piece hor to the left of the PP.

Step 4

Put another 8x6 piece hor to the front of the PP.

Number 3.

Step 5

Flip over, so that the long piece is to the front. Put a 10x2 hor to the right of the long piece, on the front edge.

Step 6

Put another 10x2 hor to the right.

Step 7

Put another 10x2 ver to the right and to the front, eight rows overhanging in the front.

Step 8

Put a 2x1 hor to the right of the long piece, at the back edge.

Step 9

Put a 10x2 hor to the right, one row overhanging in the back.

Step 10

Put another 10x2 ver to the right and to the front, shifting one row to the front, so that it is aligned with the back edge and touches the horizontal 10x2 in the front.

Number 4

Step 1

Put an 8x1 hor to the right of the PP, on the back edge.

Step 2

Put a 2x1 ver to the right and to the front, on the right edge.

Step 3

Put an 8x1 ver to the front.

Step 4

Repeat.

Step 5

Put a 4x1 hor to the left of the long piece, on the back edge.

Step 6

Put a 2x1 hor to the left.

Step 7

Put a 2x1 ver to the left and to the front.

Step 8

Put an 8x1 ver to the front.

Step 9

Repeat.

Number 5.

Step 1

Flip over, so that the protruding pieces are to the back. put an 8x2 hor on the left side of the back edge.

Step 2

Put a trapdoor hor to the back, the hinges on the left.

Step 3

Put an 8x2 ver to the right and to the front.

Step 4

Put an 8x4 ver on the right side of the back edge.

Bag 20.

Number 6 - all flat.

Step 1

Flip over so that the trapdoor is on the left in front. Put a 2x1 ver on the front end of the left edge.

Step 2

Put an 8x1 hor to the right.

Step 3

Put a 3x2 ver to the back of the rightmost two buttons of the PP. Put momentarily aside.

Step 4

Put a 10x2 hor on the table. Put another 10x2 hor to the right. Connect them by putting an 8x2 hor on top, so that only the rightmost column of the left 10x2 piece is under the 8x1 piece's leftmost column. Put another 8x2 piece hor to the left of the first one. Put a 2x2 piece to the right of the first 8x2 piece. Flip this part over, so that the 2x2 piece is still on the right, and put hor in the front, to the right of the two PPs, connecting the two long pieces and forming the front edge.

Step 5

Skip two buttons to the right and put a 2x1 ver on the front end of the right edge.

Number 7.

Step 1

Flip the structure the right side up, so that the trapdoor is once again in the left back corner.

Step 2

Put a flat 10x1 ver on the front end of the left edge.

Step 3

Put a flat 10x1 ver to the back.

Step 4

Repeat steps 2-3 on the right edge.

Step 5

Put three flat 10x1 pieces hor on the back edge.

Step 6

Put a flat 10x2 hor on the front, on the left side, skipping one row from the front edge to the back, to the right of the 10x1 vertical piece on the left edge.

Step 7

Repeat symm on the right.

Step 8

Put an 8x1 slide piece ver to the left of the PP, slide to the right, aligning with the front edge.

Step 9

Repeat symm on the left.

Number 8

Step 1

Rotate the structure 180 degrees, so that the trapdoor is in the right front corner. Put a trapdoor cover on the table hor, sticks to the right. Put a flat 2x1 piece with the upright stick ver on the middle two buttons of the leftmost column, upright stick to the left. Install the cover on the trapdoor, the way it is.

Step 2

Put four flat three-button corner-pieces in the four corners of the long gap.

Step 3

Put two flat 4x1 pieces ver on the left and on the right edges, between the cornerpieces.

Step 4

Put four flat 6x2 pieces hor on the back and on the front edge, next to the corner-pieces.

Step 5

Put the four remaining corner-pieces in the middle of the back and the front edge, so that they overhang over the gap. The pattern should be: the J and H in the front, left to right, and the D and F in the back.

Bag 21.

Number 9.

Step 1

Put four flat smooth 8x1 pieces hor on the front edge.

Step 2

Put two flat smooth 8x1 ver to the back of the right piece, on the right edge, and two symm on the left.

Number 10.

Step 1

Put a grooved 2x1 ver on the front end of the left edge of the gap, groove to the right.

Step 2

Put a bench piece ver to the back, seat to the right.

Step 3

Put a grooved piece ver to the back, groove to the right.

Step 4

Put a flat 4x1 to the right, on the back edge.

Step 5

Repeat.

Step 6

Put a grooved piece ver to the right and to the front, groove to the left.

Step 7

Put a groover piece ver to the right, groove to the right.

Step 8

Put a flat 4x1 hor to the right.

Step 9

Repeat.

Step 10

Continue symm around the gap.

Bag 22. Number 11

Step 1

Put four flat smooth 8x1 pieces hor at the edges of the gap.

Step 2

Put two arches ver in the middle of the gap, across it, side by side.

Step 3

Put two flat smooth 2x1 pieces hor to the front and to the back of the arches.

Step 4

Put aside two sliding-door pieces with the handle (they are black).

Bag 23. Number 12

Step 1

Connect nine sliding-door pieces. Put the black piece last. Repeat. Install the hor in the back edge of the gap, handle last.

Step 2

Put a flat smooth button on the left back corner of the gap edge, and one on the right.

Bag 24. Number 13

Step 1

Curve the sliding doors and close them in the front.

Step 2

Put two smooth flat buttons at the front corners of the gap. Put momentarily aside.

Step 3

Put one flat 2x1 on top of another and lay hor on the table. Put two hammer pieces on top, buttons facing each other. Put a flat 2x1 hor on top. Put an arch on top. Repeat to make another such part. Install them ver at the sides of the gap, between the flat smooth buttons.

Number 15.

Step 1

Rotate 180 degrees. Put one flat button on top of another, put a hammer piece on top, repeat to make another such part and install them, button to the front, at the front corners of the structure, skipping the first-row button.

Step 2

Put a button on top of a flat 2x1 piece. repeat. Put these parts ver, button to the front, on the front ends of the 8x1 slide pieces.

Step 3

Put a flat 6x1 hor in the middle of the front edge, on the threshold.

Step 4

Go to the right slide piece. put a cone to the left of its back button.

Step 5

Skip two buttons to the front and put another cone.

Number 16.

Step 1

Skipping the leftmost button on the front wall, put a 2x1 arch piec hor on the first row, arch to the front.

Step 2

Put a flat 2x1 hor to the right.

Step 3

Put an arch.

Step 4

Put a flat 2x1.

Step 5

Put an arch.

Step 6

Repeat steps 1-5 symm on the right.

Step 7

Put a tall 2x1 hor on the left side of the threshold.

Step 8

Put a flat 2x1 on its left side.

Step 9

Repeat steps 7-8 symm on the right.

Step 10

Put a flat smooth 6x1 hor in between.

Bag 25. Number 17

Step 1

Put a flat 2x2 washing-board piece on the table, hole to the right. Turn a hammer piece upside down and insert its button into the hole. Put a two-button frog piece ver to the left, nose to the left.

Repeat to make six such pieces.

Step 2

Turn one such piece nose to the back and insert the hammer into the rightmost arch, from behind, swinging down.

Step 3

Repeat on each arch.

Number 18.

Step 1

Flip six flat 2x1 one-button pieces upside down and put hor on the hammers in the front row (one is missing).

Step 2

One flat 2x2 on top of another and put them on top of a 2x2 lip piece. repeat to make four such parts.

Install in between the hammer parts on the first and second rows, lips overhanging to the front.

Put momentarily aside.

Bag 26. Number 19. Start making the front piece with the number 1891 on it.

Step 1

Hold a 2x1/2x2 piece upright, ver, 2x2 wall upright and to the left. Put a button on the upper back button of the 2x2 wall. Put another button on it. Put momentarily aside.

Step 2

Put a flat grey (sorry) 2x1 piece on top of a white flat 2x1. Put a flat smooth 2x1 on top. Put this part upright ver (like a tall building), smooth side to the left and put it on the front two buttons of the upright wall of the part in step 1. Put momentarily aside.

Step 3

Make another part like the one in step 2. Put it on the back two buttons of another upright piece. put a cylinder on the front upper button of it.

Step 4

Insert a stick into the cylinder. This part on the left, connect the stick to the two-button stack on the first

part. Install this part, the way it is, in the middle of the front edge.
Bag 27. Number 20.

Step 1

Put a flat 1x1 on the table. Put a flat 1x1 with a hor clasp (in a separate bag) to the right, clasp to the back. put a flat 2x1 hor on top. Put a flat smooth 2x1 hor on top. Install this part ver, upright, in the middle of the front edge, clasp to the back, smooth side to the left.

Step 2

Put a flat 1x1 piece sandwiched in between two flat 1x1 pieces from a separate bag. Put a flat 1x1 with the ver clasp on top, clasp to the back. put a flat smooth 1x1 on top. Repeat to make another such part. Install them in the middle of the first row, at the sides of the PP.

Number 21.

Step 1

Put a flat 2x1 on top of another and on top of a 2x1 lip piece. repeat. Put them ver on the leftmost and rightmost buttons of the front row, lips overhanging to the front.

Step 2

Put a 2x1 grooved piece hor to the back and to the right of the left PP.

Step 3

Put a 4x1 arch hor to the right.

Step 4

Repeat.

Step 5

Put a 3x1 hor to the right.

Step 6

Put a 6x1 ver to the back, on top of a slide piece.

Step 7

Repeat steps 3-6 symm on the right.

Step 8

Put a flat 4x1 ver across to the cones next to the right slide piece.

Bag 28. Number 22.

Put four 8x1 cornice pieces hor on the front wall, cornices to the front.

Number 23

Step 1

Put a flat 8x1 hor on the table. Put two flat 2x1 pieces hor to the front of it, side by short side, in the middle. Connect by putting a flat 4x2 piece hor on top. Put two flat 2x1 pieces hor at the sides, on the 8x1 piece. Install this part, the way it is, in the middle of the front wall, on first and second rows.

Step 2

Put two 6x1 ver at the sides, on the slide pieces.

Number 24

Step 1

Put a flat 4x1 with two buttons hor in the middle of the first row of the front wall, on the first row of the flat 4x2 piece.

Step 2

Put a flat 1x1 with the upright clasp to the back of the PP, on the third button from the left, counting from the vertical 6x1 piece (but not counting it!), clasp to the back.

Step 3

Put a 1x1 button to the right.

Step 4

Put a 2x1 hor to the left of the flat 4x1 with the two buttons.

Step 5

Put a flat 6x1 ver to the back.

Step 6

Put a flat 1x1 to the back.

Step 7

Repeat steps 4-6 on the right.

Number 25.

Step 1

Put a ribbed 2x1 hor to the left of the clasped 1x1 piece, and another to the right of the 1x1 button.

Step 2

Go to the left end of the front wall. Put a flat 2x1 with one button ver on it.

Step 3

Put another such piece ver to the right.

Step 4

Put a flat smooth 2x2 to the right.

Step 5

Repeat.

Step 6

Put another flat 2x1 with one button ver to the right.

Step 7

Repeat.

Step 8

Put a flat smooth 2x2 to the right.

Step 9

Put two more 2x1 with one button to the right as before.

Step 10

Repeat steps 2- 9 symm on the right.

Bag 29. Number 26

Step 1

Put a flat smooth 1x1 on top of a 1x1 button and put them on the button of a 1x1 shoe piece. put this part, toe to the right. On the left end of the front wall.

Step 2

Repeat on the right.

Step 3

Put a 3x1 ver on the left vertical wall of the middle tower, in the front.

Step 4

Put a flat smooth 2x1 ver to the back.

Step 5

Put a 3x1 ver to the back.

Step 6

Repeat steps 3-5 on the right tower wall.

Step 7

Put two flat smooth 2x1 pieces hor on the front tower wall, on the buttons of the 4x1 piece with the two

buttons. there is a 2x1 gap between the two pieces.

Step 8

Put two ribbed 2x1 hor to the back of the two PPs. They should be taller than the middle ribbed piece between them.

Number 27.

Step 1

Put two more ribbed pieces hor on the tops of the two PPs.

Step 2

Make a part. Put a 2x1 on top of a flat 2x1. Put a flat 2x1 on top. Put another flat 2x1 on top. Insert a connector in the hole, long end first. Install this part hor in the middle of the front tower wall, between the ribbed pieces.

Step 3

Go to the front end of the left tower wall. Put a 1x1 with the side button on it, button to the right.

Step 4

Put a 2x1 ver to the back.

Step 5

Skip two buttons to the back (the flat smooth piece), put a 3x1 ver to the back.

Step 6

Repeat steps 2-5 symm on the right.

Number 29

Step 1

Make a part. Put a flat 4x1 hor on the table. Put a 1x1 on its right end. Put a flat 2x1 hor to the left. Put a flat 2x1 on top of the PP. put a stapler piece hor on top, sliding to the left. Put another stapler piece to the left, the same way.

Step 2

Repeat to make another such part.

Step 3

Install these parts hor on the front wall, to the left and to the right of the front tower wall, tall ends facing each other.

Step 4

Put a 3x1 ver on the front end of the left tower wall.

Step 5

Skip two buttons to the back and put a 2x1 ver to the back.

Step 6

Repeat steps 4-5 on the right.

Step 7

Put three ribbed 2x1 pieces hor on the front tower wall, side by short side.

Number 29.

Step 1

Make a stepladder part. Put a flat 10x1 hor on the table. Put a flat smooth 1x1 on its left end. Put a four-column piece hor to the right. Put another four-column piece to the right. Put a flat smooth 1x1 to the right. Put a flat 10x1 on top. Put a flat smooth 1x1 on its left end. Put a flat smooth 8x1 hor to the right. Put a flat smooth 1x1 to the right. Install this piece upright, hor, to the back of the front tower wall, in the middle.

Bag 30. Number 30

Step 1

Put a 2x1 ver on the front end of the left tower wall.

Step 2

Put a flat 2x2 to the right.

Step 3

Put a 4x1 arch ver to the back of the 2x1, on the left tower wall.

Step 4

Put a 1x1 to the back.

Step 5

Repeat steps 1-4 symm on the right.

Step 6

Put an 8x1 arch hor on the back tower wall.

Step 7

Put a smooth flat 4x1 upright on the inside of the left tower wall, under the flat 2x1 piece, on the flat smooth 2x1, hanging on the side button.

Step 8

Repeat symm on the right.

Number 31.

Step 1

Put one flat 4x2 on top of another and put them on top of the other such piece that should be in a separate bag. Put this part hor in the middle of the front tower wall.

Step 2

Put a 10x1 ver to the left and to the back.

Step 3

Put a 10x1 ver to the left.

Step 4

Repeat steps 2-3 on the right.

Step 5

Put two 2x1 pieces hor on the back tower wall, side by short side.

Bag 31. Number 32.

Step 1

Put twelve flat 2x2 pieces with one button on the tower walls to form a square.

Step 2

Hang a clock upright in the middle of the front wall.

Number 33.

Step 1

Put four one-button roof pieces in the corners of the tower, slide sides facing outwards.

Step 2

Put a 3x1 piece and a 2x1 roof piece on each side of the tower, slide sides facing outwards.

Number 34.

Step 1

Put a flat 2x2 piece with one button in each corner of the tower.

Step 2

Put a flat smooth 3x1 piece in between each two PPs. Put aside.

Bag 32.

Make the tower top part.

Step 1

Put a flat 5x6 piece on the table. Put a cone in the middle (between the buttons).

Step 2

Put a flat smooth 1x1 piece in each corner of the 6x6 piece. put a flat 4x1 piece with two buttons between each two PPs.

Step 3

Make a part. Put a flat 2x2 disk on top of a one-button inverted saucer piece. put a one-button hemisphere on top. Put a cylinder on top. Install this part on the cone in the middle of the 6x6 piece.

Step 4

Make a part. Put a 4x1 arch piece hor on the table. Put two flat 2x1 corniced pieces hor on top, side by short side. Put one cylinder on top of another and put them under the left side of this part. Put one cylinder on top of another and put them under the right side of this part.

Step 5

Repeat step 4 to make four such parts. Install them on the four sides of the tower top, on the buttons of the two-button 4x1 pieces, cornices facing outwards. Put a flat 6x6 on top.

Step 6

Put four one-button roof pieces in four corners, as before. Put four 2x1 roof pieces in between, as before.

Step 7

Put two flat 4x2 pieces hor on top, side to long side.

Step 8

Put four tall one-button roof pieces on top, as before.

Step 9

Put a one-button pyramid on top.

Number 35

Install this part on top of the tower.

Number 36

Install the roof onto the third floor. Install the third floor onto the building.

Enjoy!

Thank you so much for building this set!

Visit bricksfortheblind.org for more accessible instructions!

Abbreviation definitions:

F = flat (Plate.)

FS = flat smooth (tile)

Slide = slope.

Lip = inverted slope.

Ribbed stick = Technic axle.

Connector = Technic pin.

Stubby or Short connector = Technic pin with stud.

Long connector = elongated Technic pin.

Nail = technic axle with end stop.

Fat nut = Technic joiner.

Thin nut = Technic stop.

Elbow = technic joiner 90 dg.

1x1, 2x1, 3x1... means a 1x1, 2x1, 1x3... brick.

Ver = vertically.

Hor = horizontally.

Symm = symmetrically.

LMA = Lay Momentarily Aside.
PP = previous piece.
Sep bag = separate bag.
Braille letters (for placing corner pieces):
D = open corner to the front left.
F = open corner to the front right.
J = open corner to the back left.
H = open corner to the back right.

We hope you enjoyed building your LEGO set! Bricks for the Blind is able to create these text-based building instructions thanks to generous donations from our builders. If you enjoy the instructions we create, please consider making a \$5 donation at: <https://www.gofundme.com/f/bricks-for-the-blind-gofundme>.