76966 Dinosaur Missions: Allosaurus Transport Truck

Adapted by John Le and tested by Jolene Nemeth.

New and unexpected animal adventures are in store for fans aged 8+ with this Dinosaur Missions: Allosaurus Transport Truck (76966) model loaded with role-play possibilities. This LEGO® Jurassic World dinosaur toy set makes a fun kids' party gift. It lets kids tell unlimited action stories using the molded Allosaurus toy figure with movable legs, head and opening mouth, plus Darius, Kenji, Yaz and guard minifigures. There's a semi-truck with an opening roof and hood, a 3-minifigure cab with a bed, a cage trailer with front supports and an opening back ramp, a cage that opens with a lever push, a quad bike and drone, plus plenty of story starter elements.

Allosaurus toy set – Treat dinosaur fans aged 8+ with this detailed Dinosaur Missions: Allosaurus Transport Truck set, made to meet kids' passions for adventure, animals and exciting hero stories.

Movable Allosaurus figure – Features a molded dinosaur toy set with movable arms, legs, head and opening jaw, plus Darius, Kenji, Yaz and guard/driver minifigures to kick-start role play and stories.

Adventure playset – Vehicle-loving kids will enjoy this Jurassic World adventure toy, with a semi-truck that has a LEGO® dinosaur cage trailer with lowering ramp and walls, a quad bike and more.

Easy set for playdates – Extra storytelling elements include a drone, tranquilizer darts and gun, making this Jurassic World dinosaur toy set ready to play out high-action escape and recovery tales.

Dimensions – This 588-piece set includes a truck with a trailer and an Allosaurus figure that measures over 6 in. (16 cm) high, 17 in. (43 cm) long and 3 in. (8 cm) wide.

The front of the box shows a semi truck transporting an allosaurus through the jungle but the cage broke and the allosaurus is free! In the front, there is a 4 wheeler with 2 people controlling a drone to tranquilize the dinosaur!

The back of the box shows the transport truck parked in the forest! Kenji is luring the dinosaur into the cage with a chicken leg while Darius is controlling a drone to tranquilize the dinosaur just in case! There is also a guard on top of the cage holding a tranquilizer gun!

The top of the box shows a real size image of Yaz.

The build is 588 pieces in total and is for ages 8+.

Bag 1 includes the pieces for Darius, the allosaurus, the 4 wheeler, and the drone

Bag 2 includes the pieces for a guard and the transport truck.

Bag 3 includes the pieces for the transport truck.

Bag 4 includes the pieces for the cage.

Bag 5 includes the pieces for Kenji and the cage.

Bag 6 includes the pieces for the cage.

Welcome to text-based instructions from Bricks for the Blind. Before you start building, here are some terms we'll be using:

- In Front of/Front: towards you.
- Behind/Back: away from you.
- Up: towards the ceiling.
- Down: towards the floor.
- Stud: the bump on a LEGO brick. Example: A 2x1 brick has two studs on it.
- Vertically: with the longest side going from front to back
- Horizontally: with the longest side going from left to right.
- Upright: pointing up towards the ceiling.
- Standing upright: The piece is perpendicular to the ground, like a wall.
- Lying flat: The piece is parallel to the ground, like a piece of toast which fell off the table.
- That one/ppp: previously placed piece.
- Plate: piece with studs.
- Tile: smooth piece without studs (unless otherwise specified)
- A jumper plate is a 1x2 plate with a single stud on top, or a 1x3 plate with only two studs on top.

- "Anti-stud" is a term for the portion of a LEGO piece which accepts studs, like the bottom of a plate or brick.

- Symmetrically: a mirror image. Example: If you place a 2x1 brick with technic connector on the front wall at the right, connector to the front, and then place another such piece symmetrically on the back wall, at the right, the technic connector of the second piece should point to the back, since it will be placed symmetrically.

- Centered-vertically: even amount of space in front of and behind piece
- Centered-horizontally: even amount of space left and right of piece.
- Row: studs lined up horizontally (left to right/side to side).
- Column: studs lined up upright or vertically (top to bottom/back to front).

A note on LEGO Technic[™] part names. These parts are somewhat different from regular LEGO bricks. Here are some definitions in case the builder or helper is not familiar with LEGO Technic[™].

Axles - An axle is a connector which has an X shaped cross-section. Because their cross section is not round, anything connected to an axle using an axle-hole will rotate with that axle. Axles are longer than they are wide, and the length of an axle corresponds with how many bricks long it is. Aka a 3L axle is three bricks long. Axles come in a variety of lengths, with a 2L axle being the shortest available. They may be combined with pins, or have circular stops on them. A stop prevents the axle from sliding through an axle-hole at a specific point on the axle.

Pins - A pin is a connector which has a circular cross section and a flanged notch out of one or both ends. This flanged notch allows them to click into bricks with a pin-hole. Pins come with and without friction ridges, which are small bumps on the pin which prevent them from rotating freely. For standard pins, black is a high friction pin, and gray is a low friction pin. A standard length pin is two brick lengths long, with a stop in the middle. This prevents a brick from being pushed from one side of the pin to the other. A 1L pin is one brick long and still retains the stop, however it also includes a hollow stud at the other end. A 3L pin is three bricks long, and only contains a stop at one side, allowing two bricks to be pushed onto the other side of the pin. Pins may also have one side which is an axle.

Technic brick - a brick which contains one or more holes which accept technic pins.

Lift-arms - A lift-arm is a basic structural element, similar to a brick or a plate, but usually without any studs. It is a beam with rounded ends and with holes in it, with the same spacing as the studs on a LEGO brick. lift-arms come in a variety of lengths, including a 1x1 lift-arm which looks like a cylinder. Thick lift-arms are as wide as a LEGO brick, and thin lift-arms are half as wide as a LEGO brick, but not the same thickness as a LEGO plate! The holes in a lift-arm arm may accept axles or pins. They also come in a variety of shapes, including tees, ells and triangles.

Gears - A gear is a functional element. They are typically discs with teeth on the outside, there are also worm gears which look like a spiraling cylinder! Gears connected by axles transmit or even transform rotational motion!

Axle and Pin Connectors - These elements are typically smaller than lift-arms and are used to connect some combination of pins or axles. They might have pins or axles, as well as axle or pin-holes. They have a lot of different angle combinations! The simplest just connects two axles or pins together in a straight line.

Bushes/Bushings - LEGO Technic[™] uses bushes largely as spacers, but they also can reduce friction between rotating parts, or can form useful elements such as handles. Bushes are typically light gray, generally cylindrical, and have an axle-hole running through the middle. They have a flange at the front and back to make them easier to pull on and off.

For builders with low vision, or a sighted building partner may want to follow along with the printed visual instructions that come with each kit, or PDF versions are always online at LEGO.com for each set: (<u>https://www.lego.com/en-us/service/buildinginstructions/76966</u>) As low vision users may benefit from viewing the instructions on a personal device where they can zoom in on content and use assistive technologies to enhance the visuals.

Sorting the pieces:

To begin a successful build, it helps to sort the pieces into groups, bags, or small containers. Have a friend or family member do this in advance following the instructions below. You will see that the pieces should be sorted according to the building steps in the kit. Doing this in advance makes locating the pieces for each step easier. See below on how to sort the pieces to correspond to the steps in this set. Number the containers using letters A-Z, numbers, or meaningful names. The parts will be sorted into one or a small number of steps in the instructions. Example: Steps 1-3 means collect all the parts used in steps 1,2 and 3, and put them in one container.

This LEGO set comes with 6 bags labeled 1 to 6, 2 sets of instructions, and some loose pieces. Sort the pieces into groups or piles as described below. Note that where there are multiple colors of the same brick in a step, the colors will be split into 2 groups to make telling the difference easier for the builder! LEGO includes a few spare parts in case you lose something. Set these into their own group away from the rest, in case you need them later.

Bag 1 - Darius, Allosaurus, 4 Wheeler, and Drone Group 1 - Page 5. Group 2 - Steps 1-4. Group 3 - Steps 1-10. Group 4 - Steps 1-5. Bag 2 - Guard and Transport Truck Group 5 - Page 15. Group 6 - Steps 1-15. Group 7 - Steps 16-22 and 2 transparent 1x2 sloped curved tiles from Step 23. Group 8 - Rest of Step 23 and Steps 24-26. Group 9 - Steps 27-32. Bag 3 - Yas and Transport Truck Group 10 - Page 34. Group 11 - Steps 33-43. Group 12 - Steps 44-54. Group 13 - Steps 55-63. Bag 4 - Cage Group 14 - Steps 1-15. Group 15 - Steps 16-19. Group 16 - Steps 20-23. Bag 5 - Kenji and Cage Group 17 - Page 18. Group 18 - Steps 24-33 and 1 black 1x1 round plate from Step 34. Group 19 - Rest of Step 34 and Steps 35-42. Group 20 - Steps 43-50. Group 21 - Steps 51-53. Group 22 - Steps 54-56. Bag 6 - Cage Group 23 - Steps 57-64. Group 24 - Steps 65-69. Group 25 - Steps 70-77 and 2 transparent yellow 1x1 round tiles from Step 78. Group 26 - Rest of Step 78 and Steps 79-84. Let's get to building! Building Instructions (Bag 1, Book 1):

Group 1 - Darius

Sub-build 1. Locate 1 dark grey pair of legs, 1 torso printed with a dark blue shirt and a light orange jacket, 1 brown head printed with eyes and lips, and 1 black hair. Assemble your minifigure then put him in front of you.

Sub-build 1.2. Let's make a part! Attach a mint blue needle to the clip of a dark grey gun with a clip so the tip of the needle faces the same way as the barrel. This is a tranquilizer gun! Now attach your gun to the minifigure's hand, then put everything away while we make a dinosaur!

Group 2 - Allosaurus

1. Horizontally place a large dark blue and dark tan dinosaur torso with spikes in front of you so the smaller front-facing pin holes are on the left and face the front and back. Make sure the spikes face up! Now attach a dark blue and dark tan dinosaur tail to the right-facing pinhole so the spikes face up.

2. Attach a dark tan dinosaur leg with blue stripes to the larger right front-facing pinhole so the toes face the left. Then repeat symmetrically to the back.

3. Attach a dark tan dinosaur arm to the front-facing pinhole that is on the left so the claws face the left. Then repeat symmetrically to the back.

4. Let's make a part! Horizontally place a dark blue dinosaur head printed with dark tan spots and orange eyes in front of you so the nose faces the left and the spikes face the top right. Now attach a dark blue lower jaw to the bottom left of the head so it attaches to ridges! Make sure the teeth of the jaw face up. Now attach the pin of your part to the left-facing pinhole so the spikes are on top! Now put away your allosaurus while we make the next part!

Group 3 - Four Wheeler

1. Horizontally place a sand green 2x6 plate in front of you. Then horizontally place a tan 2x3 plate on the 3 rightmost columns.

2. Vertically place a white $1x^2$ plate with 2 clips on the long side on the leftmost column so the clips face the left. Then place a tan $2x^2$ tile with 2 studs to the right so the studs are on the left.

3. Place a light grey 2x2 plate with 2 small pins underneath the 2 leftmost columns so the pins face the front and back. Then repeat symmetrically to the right.

4. Vertically place a sand green 2x2 plate with 1x3 sloped curved sides on the 2 leftmost columns so it slopes to the left. Then repeat symmetrically to the right.

5. Place 2 white 1x1 plates with a clip, 1 in front of the other, on the rightmost column so the clips face the right. Now vertically place a tan 1x2 rounded plate to the left of the 2 ppp.

6. Place a tan 2x2 tile with 2 studs on the 2 rightmost columns so the studs are on the right.

7. Place 2 white 1x1 tiles with a clip, 1 in front of the other, on the leftmost column so the clip hands face left and right. Now vertically place a white 1x2 jumper plate to the right of the 2 ppp.

8. Vertically attach a silver wrench to the 2 leftmost top-facing clips so it is flat and the wrench jaw faces the front right. Then place a white 1x1 tile with a clip to the right so the clip hands face the left and right.

9. Vertically attach black handlebars to the ppp so the handles are on top and curve to the right. Now horizontally attach the short side of a black bar grill with 2 rounded parts to the left-facing clips so it curves up and to the right, and the rounded parts are on top.

10. Let's make 4 identical parts! Insert a light grey wheel into a black tire. Now you should have 4 identical parts! Attach them to the front-facing and back-facing pins so the hollow sides face outwards. Now put away your 4 wheeler while we make a drone!

Group 4 - Drone

1. Horizontally place a dark grey 1x2 rounded plate in front of you. Then horizontally place a light grey 1x2 brick with an anti-stud and side studs on 3 sides on top so the anti-stud faces the right.

2. Place a light grey 1x1 round tile with a top-facing bar upright on the left-facing side stud. Now place a transparent 1x1 round plate upright on the left-facing bar so the anti-stud faces the left.

3. Horizontally place a light grey 1x2 plate with bars on the short sides upright on the front-facing side studs. Then horizontally place a sand green 1x2 tile upright on the front-facing side studs. Now repeat both parts symmetrically to the back.

4. Vertically place a black 1x3 plate with a stud and 2 upright clips on the left column so it is centered vertically. Now horizontally place a sand green 1x2 sloped curved tile on top so it slopes to the right. Now attach a mint blue needle to the front clip so the tip faces the left. Then repeat symmetrically to the back.

5.1. Let's make 4 identical parts! Place a light grey 1x1 round plate with a bar in front of you so the bar faces the right. Now attach a dark grey bar holder with a clip to the right-facing bar so the clip faces the right and the clip hands face the front and back.

5.2. Place a light grey 1x1 round tile with a top-facing bar on top. Now horizontally place a black propeller on top of the bar of the ppp.

5.3. Now you should have 4 identical parts! Attach the clip of 1 part to the front left facing bar so the propeller faces up and the front. Then repeat symmetrically to the right. Now repeat both parts symmetrically to the back. Now put away your drone while we make the next part!

Building Instructions (Bag 2, Book 1):

Group 5 - Guard

Sub-build 2. Locate 1 black pair of legs, 1 blue torso printed with dark grey straps, 1 nougat head printed with eyes, lips, and a light blue earpiece, and 1 dark blue hat. Assemble your minifigure then put him away while we make the transport truck!

Group 6 - Transport Truck

1. Horizontally place a light grey 1x12 brick with pinholes in front of you. Then insert a black 2L pin into the leftmost and rightmost front-facing pinholes.

2. Horizontally attach a light grey 1x12 brick with pinholes to the front-facing pins so it is centered horizontally.

3. Insert a tan 3L pin into the 2nd front-facing pinhole from the right so the 2L pin faces the front. Then repeat symmetrically to the back.

4. Insert a black 2L pin into the front-facing pinhole to the left of the 2L pin. Then repeat symmetrically to the back. Now insert 2 more pins into the 2nd and 3rd front-facing pinholes from the left. Then repeat symmetrically to the back.

5. Horizontally attach the 2 leftmost pinholes of a black 1x8 brick with pinholes to the 2 rightmost frontfacing pins. Then repeat symmetrically to the back.

6. Horizontally place a dark tan 4x8 plate on the 8 rightmost columns. Then horizontally place a light blue 2x4 plate to the left so it is centered vertically.

7. Horizontally attach the 2 rightmost pinholes of a black 1x8 brick with pinholes to the 2 leftmost frontfacing pins. Then repeat symmetrically to the back.

8. Horizontally place a dark tan 4x8 plate on the 7 leftmost columns so 1 column overhangs to the left. Then vertically place a light blue 1x4 plate to the right.

9. Vertically place a light grey 1x2 grill tile on the rightmost column so it is centered vertically. Then horizontally place a 2x4 plate with 2x2 studs and a curved ridge to the left of the ppp so it is centered vertically, the studs are on the left, and the ridge faces the right.

10. Place a light grey 2x2 tile with a stud on the 2nd and 3rd columns from the left so it is centered vertically. Then vertically place a light grey 1x2 grill tile to the right so it is centered vertically. Now horizontally place a black 2x12 plate to the right of the ppp.

11. Horizontally place a light grey 2x4 tile on the 4th - 7th columns from the right so it is centered vertically. It should sit to the left of the rounded ridge.

12. Horizontally place a light grey 1x2 brick on the front row of the 7th and 8th columns from the right. Then place a light grey 1x1 slope tile on the right column of the ppp so it slopes to the back. Then repeat both parts symmetrically to the back.

13.1. Let's make a part! Vertically stack 2 black 1x2 plates in front of you. Now vertically place a light grey 1x2 plate with an upright bar on the long side on top so the bar faces the right. Now vertically place a light grey 1x4 sloped curved tile on top so it is centered vertically.

13.2. Vertically place your part on the 8th column from the right so it is centered vertically and the bar faces the right.

14. Vertically place 2 sand green 2x3 stair plates, 1 to the right of the other, on the front row on the 6th, 7th, 8th, and 9th columns from the left so the short side overhangs 2 rows to the front. Then repeat symmetrically to the back.

15. Vertically place a light blue 1x4 plate on the 6th column from the left so it is centered vertically. Now vertically place 2 tan 1x2 jumper plates, 1 in front of the other, to the right of the ppp so they are centered vertically. Then vertically place 2 tan 1x2 jumper plates, 1 in front of the other, to the right of the 2 ppp so they are centered vertically. Now horizontally place a white 1x2 panel in front of 4 jumper plates so the wall faces the front. Then repeat symmetrically to the back.

16.1. Vertically place a light grey 1x2 steering wheel on the 3rd and 4th rows from the front of the 6th column from the left so the wheel faces the right. Then vertically place a sand green 1x2 plate behind the ppp. Now vertically place a light brown 1x2 slope tile with a sticker on top of the ppp so it slopes to the right.

16.2. Skip this step if you have already placed your sticker! Ask a helper to place sticker 6 on the light brown 1x2 slope tile. This sticker has 2 speedometers on it. Make sure the sticker is placed on correctly and is oriented on the build correctly, ask a sighted person to check.

17. Place a black 1x1 round plate on the 2x2 tile with a stud that is on the 2nd and 3rd columns from the left. Then place a light grey 2x2 dish on top. Now place a light grey 1x1 round tile on top of the ppp.

18.1. Let's make a part! Horizontally place a light grey 1x2 brick with 2 side studs in front of you so the side studs face the front. Now place a light grey 1x1 round tile upright on the right front-facing side stud. Then attach the shorter bar of a light grey L-shaped bar to the front-facing side stud so the longer bar faces the right.

18.2. Vertically place your part on the 5th column from the left so it is centered vertically and the upright parts face the left.

19. Vertically place a sand green 1x6 plate on the leftmost column so it is centered vertically. Now horizontally place 2 dark grey 1x2 log bricks, 1 to the right of the other, on the front row to the right of the ppp. Then repeat symmetrically to the back.

20. Let's make a part! Vertically place a sand green 1x6 plate in front of you. Then place a sand green 1x1 plate on the front row. Then repeat symmetrically to the back. Now vertically place your part underneath the leftmost column so it is centered vertically.

21. Vertically place a black 1x4 plate on the leftmost column so it is centered vertically. Now horizontally place the leftmost column of a sand green 1x6 stair plate with an arch and a lip in front of the ppp so the lip faces the front. Then repeat symmetrically to the back.

22. Vertically place 3 sand green 1x2 plates with 2x2 side studs hanging down, 1 in front of the other, on the leftmost column so the side studs face the left.

You will have 2 extra transparent 1x2 sloped curved tiles. Save them for later!

Group 8 - Transport Truck

23.1. Let's make a part! Horizontally place a sand green 2x4 plate in front of you. Then horizontally place a black 1x2 plate on the back row so it is centered horizontally. Now horizontally place a transparent 1x2 sloped curved tile from group 7 on the back left corner so it slopes and overhangs to the left. Then repeat symmetrically to the right.

23.2. Horizontally place a transparent yellow 1x2 sloped curved tile on the front left corner so it slopes and overhangs to the left. Then repeat symmetrically to the right.

23.3. Horizontally place your part upright on the left-facing side studs so the 1x2 plate is on top.

24. Place a sand green 1x1 brick on the 2nd row from the front of the 6 column from the left. Then repeat symmetrically to the back.

25. Horizontally place a light grey 1x4 tile with 2 studs on the 2nd row from the front of the 2nd, 3rd, 4th, and 5th columns from the left. Then place a sand green 1x1 plate in front of the rightmost column of the ppp. Then repeat both parts symmetrically to the back.

26. Vertically place a light grey 1x2 grill tile on the leftmost column so it is centered vertically. Then place the right column of a white 2x2 corner tile with a cutoff corner in front of the ppp so the cutoff corner faces the front left. The left column of it will sit on the edges of the upright parts on the left. Then repeat symmetrically to the back.

Group 9 - Transport Truck

27. Vertically place a light grey 1x4 tile with 2 studs to the left of the steering wheel that is on the 6th column from the left so it is centered vertically. Now horizontally place the right column of a sand green 1x2 plate in front of the ppp. Then repeat symmetrically to the back.

28. Vertically place a sand green 1x6 plate on top of the 3 ppp so it is centered vertically. Then place a sand green 1x1 plate with a side stud sticking up to the right of the front row of the ppp so the side stud faces the front. Then repeat symmetrically to the back.

29. Horizontally place a sand green 1x4 sloped curved brick on the front left corner so it slopes to the left. Then repeat symmetrically to the back.

30. Place a sand green 1x1 slope tile upright on the front-facing side stud so it slopes to the left. Then repeat symmetrically to the back.

31. Vertically place the right column of a transparent black 2x6x2 windshield in between the 2 ppp so it is centered vertically and slopes to the left. Now place a white 4x4 car hood to the left of the ppp so it is centered vertically and the studs are on the right. Then vertically place a white 1x2 ingot tile on top of the ppp.

32.1. Let's make a part! Place a white 2x2 inverted sloped curved tile in front of you so the higher side is in the back. Now horizontally place a light grey 1x2 plate with 1x4 side studs on the front row so the side studs face the front. Then horizontally place a white 1x4 tile with a sticker upright on the front-facing side studs.

32.2. Skip this step if you have already placed your sticker! Ask a helper to place sticker 2 on the white 1x4 tile. This sticker is a license plate that says OCM 1877 and is covered in dirt. Make sure the sticker is placed on correctly and is oriented on the build correctly, ask a sighted person to check.

32.3. Rotate your main build 180 degrees so the windshield is on the right. Now vertically place your part underneath the leftmost column so the 1x4 tile faces the left.

Building Instructions (Bag 3, Book 1):

Group 10 - Yas

Sub-build 3.1. Locate 1 tan pair of legs, 1 torso printed with a purple and white stripe shirt with a light brown jacket, 1 tan head printed with eyes, red lips, and eyelashes, and 1 black hair. Assemble your minifigure then put her in front of you.

Sub-build 3.2. Let's make a part! Place a light grey 1x2 tile printed with a yellow joystick and buttons on top of a light grey 1x2 plate with a bar on the long side so there is no overhang. This is a drone controller! Now attach it to your minifigure's hand! Now put everything away while we continue the build!

Group 11 - Transport Truck

33.1. Let's make a part! Horizontally place a light grey 2x4 half cylinder brick with a sticker in front of you.

33.2. Skip this step if you have already placed your sticker! Ask a helper to place sticker 1 on the light grey 2x4 half cylinder brick. This sticker has dark grey bars on it and is covered in dirt. Make sure the sticker is placed on correctly and is oriented on the build correctly, ask a sighted person to check.

33.3. Place 2 light grey 2x2 round bricks, 1 to the right of the other, underneath the ppp.

33.4. Insert a blue 2L pin axle into each of the bottom-facing holes of the 2 ppp so the pins face down.

33.5. Horizontally attach the pins of your part to the front-facing pinholes that are to the right of the 1x4 sloped curved tile that is on the 8th column from the left.

34.1. Let's make a part! Horizontally place a light grey 2x4 half cylinder brick with a sticker in front of you.

34.2. Skip this step if you have already placed your sticker! Ask a helper to place sticker 4 on the light grey 2x4 half cylinder brick. This sticker has dark grey bars on it and is covered in dirt. Make sure the sticker is placed on correctly and is oriented on the build correctly, ask a sighted person to check.

34.3. Place 2 light grey 2x2 round bricks, 1 to the right of the other, underneath the ppp.

34.4. Insert a blue 2L pin axle into each of the bottom-facing holes of the 2 ppp so the pins face down.

34.5. Horizontally attach the pins of your part to the back-facing pinholes that are to the right of the 1x4 sloped curved tile that is on the 8th column from the left.

35. Let's make a part! Horizontally place a black 1x6 plate in front of you. Then horizontally place a white 2x4 brick on top so it is centered horizontally and overhangs 1 row to the front.

36. Place a white 1x1 brick with an axle hole on the leftmost column so the axle hole faces the left. Then repeat symmetrically to the right.

37. Vertically place a light blue 2x4 plate underneath the front row so it is centered horizontally and 3 rows are exposed to the front.

38. Horizontally place a light blue 2x4 plate on the 2nd and 3rd rows from the front so it is centered horizontally.

39. Place a white 2x2 plate with 2 side studs underneath the leftmost column of the 2nd and 3rd rows from the back so 1 column is exposed to the left and the side studs face the left. Then place another 1 underneath the 2x4 plate, in front of the ppp so 1 row of the right column is exposed to the front, and the side studs face the left. Now repeat both parts symmetrically to the right.

40. Place a tan 2x2 corner plate on the front left corner so it looks like the braille letter f. Then place another 1 behind it so it looks like the braille letter h. Now repeat both parts symmetrically to the right. Then place a white 2x2 plate on the 2nd and 3rd rows from the front so it is centered horizontally.

41. Vertically place a light brown 1x4 tile with 2 studs on the front left corner. Then repeat symmetrically to the right. Now place 2 light blue 2x2 tiles with 2 studs, 1 to the right of the other, on the 2nd and 3rd rows from the front so they are centered horizontally, and the studs are on the left.

42. Horizontally place 2 tan 1x2 tiles with an overhead bar, 1 to the right of the other, on the front row so they are centered horizontally and slope to the front. Now vertically place an orange 1x2 ingot tile on the 2nd column from the left, behind the ppp.

43. Vertically place your part to the right of the 1x4 sloped curved tile that is on the 8th column from the left so it is centered vertically and the 1x2 tiles with an overhead bar are on the right.

Group 12 - Transport Truck

44. Let's make a part! Horizontally place a white 1x4x4 panel with a sticker in front of you so the wall faces the front.

45. Skip this step if you have already placed your sticker! Ask a helper to place sticker 5 on the white 1x4x4 panel. This sticker has a calendar and a map on it. Make sure the sticker is placed on correctly and is oriented on the build correctly, ask a sighted person to check.

46. Horizontally place a white 2x6 plate underneath the ppp so it is centered horizontally and 1 row is exposed to the front.

47. Stack 2 white 1x1x2 bricks with 2 side studs on the back left corner so the side studs face the left. Then repeat symmetrically to the right.

48. Horizontally place a white 1x2x2 panel on the front row so it is centered horizontally and the wall faces the back.

49. Horizontally place 2 white 1x3 inverted slope bricks, 1 to the right of the other, on the front row so they are centered horizontally and slope outwards to the left and right.

50. Place a white 2x2 tile with a stud on top so it is centered horizontally.

51. Place a light grey 2x2 corner plate on the 2 leftmost columns so it looks like the braille letter j. Then repeat symmetrically to the right.

52.1. Let's make a part! Vertically place a white 2x3 plate in front of you. Then vertically place a white 1x3 plate on the left column. Now place a white 2x2 sloped curved tile on the front 2 rows so it slopes to the right. Then horizontally place a white 1x2 sloped curved tile behind the ppp so it slopes to the right. Now

vertically place your part on the 2 rightmost columns of your previous part so 1 row overhangs to the back and it slopes to the right.

52.2. Let's make a part! Vertically place a white 2x3 plate in front of you. Then vertically place a white 1x3 plate on the right column. Now place a white 2x2 sloped curved tile on the front 2 rows so it slopes to the left. Then horizontally place a white 1x2 sloped curved tile behind the ppp so it slopes to the left. Now vertically place your part on the 2 leftmost columns of your previous part so 1 row overhangs to the back and it slopes to the left.

53. Vertically place your part to the right of the 1x4 sloped curved tile that is on the 8th column from the left so it is centered vertically and the overhang is on the right.

54.1. Let's make a part! Horizontally place a white 2x3 plate in front of you. Then place a white 2x2 plate on the 2 leftmost columns.

54.2. Vertically place a white 1x2 plate with a rail on the leftmost column so the rail faces the left. Then horizontally place a white 2x4 sloped curved tile on top so it slopes and overhangs 1 column to the right.

54.3. Flip your part upside down so it is horizontal and the rail faces the left. Now vertically place a white 5x6x2 car hood on the rightmost column so it is centered vertically and slopes and overhangs 4 columns to the right. Now horizontally place a light grey 2x4 plate on top so it is centered vertically and there is no overhang.

54.4. Flip your part over so it is right-side up, horizontal, and slopes to the right. Now horizontally place the 2 leftmost columns of your part on the 2x2 tile with a stud that is on the 9th and 10th columns from the left so it is centered vertically and slopes to the right.

Group 13 - Transport Truck

55.1. Let's make 2 identical parts! Place a light grey pin connector with an axle in front of you so the pin hole faces up and the axle faces the front. Then insert a blue 2L pin axle into the pinhole so the axle faces up.

55.2. Place a light grey 3L ridged axle connector on top of the top-facing axle. Then insert a red 2L axle into the top-facing axle hole.

55.3. Place a light grey 3L ridged axle connector on top of the top-facing axle. Then place the bar of a light grey 1x1 round tile with a top-facing bar on top of the ppp so the anti-stud faces up. This is a truck exhaust!

55.4. Now you should have 2 identical parts! Attach the axle of 1 part to the front-facing axle hole that is on the 9th column from the left so the anti-stud faces up. Then repeat symmetrically to the back.

56. Insert a light grey 2L pin into the 2nd front-facing pinhole from the left. Then repeat symmetrically to the right.

57.1. Let's make a part! Horizontally place a light grey 1x4 plate in front of you. Then horizontally place the front row of a white 4x6 car hood with a sticker on top so it is centered horizontally and slopes to the back.

57.2. Skip this step if you have already placed your sticker! Ask a helper to place sticker 3 on the white 4x6 car hood. This sticker has a tan shield on it with a dinosaur and says prehistoric wildlife. Make sure the sticker is placed on correctly and is oriented on the build correctly, ask a sighted person to check.

57.3. Vertically place your part on the front-facing side studs that are to the right of the car exhaust so it sits on all the side studs and slopes to the right.

58.1. Let's make a part! Horizontally place a light grey 1x4 plate in front of you. Then horizontally place the front row of a white 4x6 carhood with a sticker on top so it is centered horizontally and slopes to the back.

58.2. Skip this step if you have already placed your sticker! Ask a helper to place sticker 7 on the white 4x6 car hood. This sticker has a tan shield on it with a dinosaur and says prehistoric wildlife. Make sure the sticker is placed on correctly and is oriented on the build correctly, ask a sighted person to check.

58.3. Rotate your main build 180 degrees, then vertically place your part on the front-facing side studs that are to the left of the car exhaust so it sits on all the side studs and slopes to the left.

59.1. Let's make a part! Horizontally place a black 1x6 plate in front of you. Then horizontally place a black 1x2 brick underneath the 2 leftmost columns. Then repeat symmetrically to the right.

59.2. Place a black 2x2 corner plate on the 2nd and 3rd columns from the left so it overhangs to the front and looks like the braille letter d. Then repeat symmetrically to the right.

59.3. Place 2 black 1x1 tiles with a clip, 1 to the right of the other, on the back row so they are centered horizontally and the clip hands face left and right. Now horizontally place a black 1x2 sloped curved tile on the 2 leftmost columns so it slopes to the left. Then repeat symmetrically to the right.

59.4. Horizontally place your part upright on the left-facing side studs so it is centered horizontally and the clips are on the bottom. Only 2 studs will attach to the side studs!

60. Vertically place 2 silver 1x2 grill tiles, 1 to the right of the other, upright on the left-facing side studs.

61. Horizontally attach the bottom of the 2 middle bars of a black ladder with 4 rungs to the 2 left-facing clips.

62. Insert a light grey 2L pin into the 2nd front-facing pinhole from the left. Then repeat symmetrically to the right.

63. Let's make 6 identical parts! Insert 6 light grey wheels into 6 black tires. Now attach them to the frontfacing and back-facing pins so the hollow sides face outwards. Now put away your truck while we make the next part!

Building Instructions (Bag 4, Book 2):

Group 14 - Cage

1. Horizontally place a black 8x16 plate in front of you. Then place a yellow 2x2 plate on the back right corner. Then repeat symmetrically to the front.

2. Vertically place a light grey 1x2 plate with 2 side studs hanging down on the back right corner so the side studs face the right. Then repeat symmetrically to the front.

3. Horizontally place 2 dark grey 1x2 grill tiles, 1 to the right of the other, on the front row on the 3rd, 4th, 5th, and 6th columns from the right. Then horizontally place a dark grey 1x4 tile with 2 studs to the left. Now repeat both parts symmetrically to the back.

4. Vertically place 2 dark grey 1x3 plates, 1 in front of the other, on the 7th column from the left so they are centered vertically.

5. Vertically place 2 dark grey 1x4 tiles with 2 studs, 1 in front of the other, on the 2nd column from the left. Now horizontally place 2 dark grey 1x2 grill tiles, 1 to the right of the other, on the front row to the right of the ppp. Then repeat symmetrically to the back.

6.1. Place a tan 2x2 tile with 2 studs on the 2nd and 3rd rows from the front on the 5th and 6th columns from the left so the studs are on the right. Then repeat symmetrically to the back.

6.2. Place a tan 2x2 tile with 2 studs on the 2nd and 3rd rows from the front on the 8th and 9th columns from the left so the studs are on the right. Then place another 1 to the right of the ppp so the studs are on the left. Now repeat both parts symmetrically to the back.

7. Vertically place 2 dark grey 1x2 grill tiles, 1 in front of the other, on the 5th column from the right so they are centered vertically.

8.1. Place a tan 1x1 quarter circle tile on the 2nd row from the front on the 4th column from the left so the curve faces the back left. Then repeat symmetrically to the back. Now place 1 on the 4th row from the front on the 6th column from the left so the curve faces the back left.

8.2. Place a tan 1x1 quarter circle tile on the 4th row from the back on the 8th column from the left so the curve faces the front right. Now place another 1 on the 4th row from the front on the 6th column from the right so the curve faces the back left.

9. Place a light grey 2x2 corner tile with a cutoff corner on the front 2 rows on the 6th and 7th columns from the left so the cutoff corner faces the back right. Then place another 1 behind the ppp so the cutoff corner faces the front right. Now repeat both parts symmetrically to the back.

10. Let's make a part! Horizontally place a dark grey 2x6 plate in front of you.

11. Vertically place a black 1x2 plate with 2 side studs sticking up on the leftmost column so the side studs face the left. Then vertically place a black 2x4 plate to the right so it is centered vertically.

12. Vertically place a dark grey 2x6 plate on the 2 leftmost columns so it is centered vertically. Then vertically place a black 1x4 plate to the right so it is centered vertically.

13. Place 2 light grey 2x2 corner plates, 1 in front of the other, on the 2nd and 3rd columns from the left so they are centered vertically, the front one looks like the braille letter d and the back one looks like the braille letter j.

14. Vertically place a light grey 1x2 plate with a pinhole on the front 2 rows of the 2nd column from the left so the pinhole is in the front. Then insert a light grey 2L pin into the left-facing pinhole of the ppp. Then repeat both parts symmetrically to the back.

15. Vertically place a light grey $1x^2$ rounded plate on the leftmost column so it is centered vertically. Then vertically place a light grey $1x^2$ plate with 2 clips on the long side in front of the ppp so the clips face the left. Then repeat symmetrically to the back.

Group 15 - Cage

16.1. Let's make a part! Horizontally place a dark grey 1x16 brick with pinholes in front of you. Then insert a black 2L pin into the 2nd front-facing hole from the left. Then repeat symmetrically to the right. Now horizontally attach a dark grey 1x16 brick with pinholes to the front-facing pins so it is centered horizontally.

16.2. Horizontally place your part on the 3 rightmost columns so it overhangs to the right.

17. Horizontally place the leftmost column of your main build on top of the leftmost column of your part so it is centered vertically, the side studs face the right, and 3 columns are exposed to the right.

18. Vertically place a light grey 1x2 plate with 2 side studs hanging down on the leftmost column so it is centered vertically and the side studs face the left.

19.1. Place a white 2x2 tile with a sticker upright on the left-facing side studs.

19.2. Skip this step if you have already placed your sticker! Ask a helper to place sticker 8 on the white 2x2 tile. This sticker says 08, has a T-Rex on it, and is covered in dirt. Make sure the sticker is placed on correctly and is oriented on the build correctly, ask a sighted person to check.

Group 16 - Cage

20.1. Let's make a part! Horizontally place a black 2x4 plate in front of you.

20.2. Place a light grey 2x2 corner plate on the rightmost column so 1 column overhangs to the right and it looks like the braille letter f. Then repeat symmetrically to the left.

20.3. Vertically place a dark grey 1x3 plate on the 2nd column from the left so 1 row overhangs to the back. Now place a yellow 1x1 round plate on the front and back rows of the ppp. Now repeat everything symmetrically to the right.

20.4. Place a black 1x1 plate with a side stud sticking up on the rightmost column so the side stud faces the front. Then repeat symmetrically to the left.

20.5. Horizontally place a light grey 1x2 plate with a pinhole on the 2 rightmost columns so the pinhole overhangs to the right and faces the front and back. Then repeat symmetrically to the left.

20.6. Insert a light grey 2L pin into the back-facing holes of each of the 2 ppp.

20.7. Rotate your main build 180 degrees. Now vertically place your part underneath the 3rd, 4th, and 5th columns from the left so it is centered vertically and the side studs face the left.

21.1. Let's make 2 identical parts! Place a black 2x2 plate with a cutoff corner in front of you so the cutoff faces the back left. Then place a dark grey 2x2 triangle tile on top so the right angle faces the front right.

21.2. Now you should have 2 identical parts! Place 1 upright on the front left-facing side studs so the cutoff corner is in the front and faces the bottom. Then repeat symmetrically to the back.

22.1. Let's make 2 identical parts! Horizontally place a black 1x2 plate with 2x2 side studs sticking up in front of you so the side studs face the back. Now horizontally place a black 1x2 brick with an axle hole on top. Then insert a blue 2L pin axle into the front-facing axle hole so the pin faces the front.

22.2. Now you should have 2 identical parts! Insert the pin of 1 part into the leftmost front-facing pinhole so the side studs face the front. Then repeat symmetrically to the back.

23. Vertically place a light grey 1x2 tile printed with a yellow joystick and buttons upright on the leftmost front-facing side studs. Then vertically place a light grey 1x2 ingot tile upright on the leftmost back-facing side studs.

Building Instructions (Bag 5, Book 2):

Group 17 - Kenji

Sub-build 4. Locate 1 dark blue pair of legs, 1 torso printed with a green shirt and blue jacket, 1 tan head printed with eyes, lip, 1 black hair, and 1 light brown chicken leg. Assemble your minifigure then attach the chicken leg to his hand! Now put him away while we continue the build!

Group 18 - Cage

24. Vertically place a black 2x4 plate with holes in front of you.

25. Horizontally place a black 1x10 plate underneath the front row so 8 columns are exposed to the right. Then repeat symmetrically to the back.

26. Place a dark grey 2x2 round tile with a hole on the 2 leftmost columns so it is centered vertically. Then place a black 1x1 round plate on the front row on the 3rd column from the left. Then repeat symmetrically to the back.

27. Horizontally place a light grey 1x2 rounded plate on the front row of the 4th and 5th columns from the right. Then horizontally place a black 1x2 plate with a hinge on the long side to the left of the ppp so the hinge faces the front. Now repeat both parts symmetrically to the back.

28.1. Let's make a part! Vertically place a light grey 1x2 rounded plate in front of you. Then place a black 2x2 corner plate on the front row so it overhangs 1 row to the front and looks like the braille letter h. Then

repeat symmetrically to the back. Now vertically place a light grey 1x2 rounded plate on top so it is centered vertically.

28.2. Vertically place your part on the 2nd and 3rd columns from the right so it is centered vertically and the 1x2 rounded plate is on the left.

29.1. Let's make a part! Horizontally place 2 yellow 2x3 plates, 1 in front of the other, in front of you. Now vertically place a light grey 1x2 tile on the leftmost column so it is centered vertically.

29.2. Place 2 green 1x1 bricks with a side stud and a bottom lip, 1 in front of the other, on the 2nd column from the right so they are centered vertically and the side studs face the left.

29.3. Vertically place your part underneath the 3rd, 4th, and 5th columns from the right so it is centered vertically and the side studs face the left.

30. Horizontally place a yellow 1x8 plate on the front left corner. Then vertically place a dark grey 1x3 plate to the right of the ppp so 2 rows overhang to the front. Then repeat both parts symmetrically to the back.

31. Place a yellow 2x2 plate on the 3rd and 4th columns from the right so it is centered vertically. Then horizontally place the 2 leftmost columns of a dark grey 1x3 plate in front of the ppp. Then repeat symmetrically to the back.

32. Vertically place a light grey 1x2 sloped curved tile on the 2nd column from the right on the 2nd and 3rd rows from the front so it slopes to the front. Then repeat symmetrically to the back. Now vertically place a dark grey 1x4 tile with 2 studs to the left of the 2 ppp so it is centered vertically.

33. Place a light grey 1x1 plate with 2 side studs hanging down on the front row of the 4th column from the right so the side studs face the front. Then repeat symmetrically to the back.

34.1. Place a black 1x1 round plate on the front row of the 4th column from the right.

Group 19 - Cage

34.2. Place a red 1x1 round plate on the back row of the 4th column from the right.

35. Horizontally place a dark grey 1x2 plate with a stud and a pinhole on the front left corner so the hole is on the left. Then horizontally place a dark grey 1x3 plate to the right of the ppp. Now repeat both parts symmetrically to the back.

36. Horizontally place a dark grey 1x4 tile with 2 studs on the front left corner. Then repeat symmetrically to the back.

37.1. Let's make a part! Horizontally place a black 1x4 thin lift arm in front of you so the pin and axle holes face the front and back. Now insert a red 1L pin with a ball into the right front-facing pinhole so the pin faces the back and the ball faces the front.

37.2. Horizontally attach a black 1x4 thin lift arm to the back-facing pin so it is aligned with the previous lift arm.

37.3. Insert a light grey 1L pin with a stud into the left front-facing pinhole so the stud faces the front.

37.4. Vertically place a dark grey double pin connector with 2 thin axle connectors on top of the leftmost column so the pinholes are on top and face the left, and the axle holes align with the axle hole of the thin lift arms. Now insert a red 2L axle into the leftmost front-facing axle connector so it goes all the way in and is centered vertically.

37.5. Insert 2 light grey 1L pins with a stud into the 2 left-facing pinholes so the studs face the left. Now horizontally place a red 1x2 slope tile upright on the left-facing side studs so it slopes down.

37.6. Horizontally place the rightmost column of your part in between the 2 leftmost pin connectors of the previous part, then insert a 4L dark grey axle with a stop into the leftmost back-facing pin hole so it attaches to the thin lift arms. Make sure the axle is not exposed to the front of the thin lift arms.

38. Let's make a part! Horizontally place a black 10L axle in front of you. Then insert a light grey 1L bushing into the right side of the axle so it goes a 4th of the way in.

39. Insert a red 1x1 brick with a pinhole into the left-facing side of the axle so it sits to the left of the axle connector. Now insert a thin yellow bushing into the left-facing side of the axle so it goes all the way in.

40. Vertically attach the middle axle hole of a 3L thin lift arm with 2 axle connectors and a pin to the left side of the axle so it goes all the way to the right and the pin is on the bottom and faces the left.

41. Attach a black and light grey 6L technic shock absorber with 2 pin holes to the left-facing pin so the side with the spring faces the back. Now insert a light grey 1L axle with a ball into the left-facing axle hole so the ball faces the left.

42. Attach a light grey 1L axle bushing to the left-facing axle so it goes all the way in.

43. Attach a black 1x1 brick with a pinhole to the left-facing axle so it goes all the way in. Then attach a light grey 1L axle bushing to the left-facing axle so it goes all the way in.

44. Vertically place your part on the previous part, on the 4th column from the right, to the right of the 1x4 tiles with 2 studs that are on the front and back row so it is centered vertically, the axles face the front and back, and the pinhole of the shock absorber is on the left and aligns with the front left pinhole.

45. Lift up the leftmost part with the 1x2 slope tile so it is upright and the slope tile is on top. Now attach a black 4L axle with 2 pinholes to the 2 front-facing balls that are on the leftmost column and 6th column from the left.

46. Push the leftmost back-facing axle with a stop to the front so it goes through the shock absorber and connects to the front left pinhole.

47. Horizontally place a dark grey 1x4 sloped curved tile on the front row of the 3rd, 4th, 5th, and 6th columns from the right. Then repeat symmetrically to the back.

48. Flip your part upside down so the taller side is on the left. Now insert a dark grey 1L pin with a bar and ball into the leftmost top-facing hole of the 2x4 plate with holes so it is centered vertically.

49. Flip your part over so it is right-side up, horizontal and the 1x2 slope tile is on the left. Now bring back your main build so it is horizontal and the clips face the right. Now horizontally place the 5 rightmost columns of your part on the 5 leftmost columns so it is centered vertically and the 1x2 slope tile is on the left.

50. Vertically place a light grey 1x4 tile upright on the front-facing side studs to the right of the front-facing axle.

Group 21 - Cage

51.1. Let's make 2 identical parts! Horizontally place a dark grey 1x4 inverted sloped brick in front of you so it slopes to the right. Now place a dark grey 1x1 plate on the 2nd column from the left.

51.2. Horizontally place a dark grey 1x2 plate with a hinge on the short side on the leftmost column so 1 column overhangs to the left and the hinge faces the left. Now place a yellow 1x1 tile on the leftmost column. Then horizontally place a yellow 1x4 tile with a sticker to the right of the ppp.

51.3. Skip this step if you have already placed your sticker! Ask a helper to place sticker 10 on the yellow 1x4 tile. This sticker has a silver handle on it. Make sure the sticker is placed on correctly and is oriented on the build correctly, ask a sighted person to check.

51.4. Now you should have 2 identical parts! Attach the hinge of 1 part to the front-facing hinge connector that is on the left side so your part is upright and the tile faces the back. Then repeat symmetrically to the back.

52. Rotate your build 180 degrees. Now horizontally place a yellow 1x1 tile with a 1x1 slope tile on the 2 rightmost columns of the front row so it slopes to the left. It should sit in front of a 1x2 sloped curved tile. Now place a yellow 2x2 sloped curved tile behind the left column of the ppp so it slopes to the left. Then repeat both parts symmetrically to the back.

53. Place a light grey 2x2 corner panel on the 2nd and 3rd rows from the back to the left of the 2x2 sloped curved tile from the previous step so the corner wall faces the back right. Then repeat symmetrically to the front.

54. Vertically place a light grey 1x4 tile upright on the front-facing side studs to the left of the front-facing axle.

55. Insert a red axle connector with a tooth into the front-facing axle so it goes all the way to the back and the sloped side of the tooth faces the front and the tooth faces the left. Then repeat symmetrically to the back.

56. Attach 2 yellow thin bushings to the front-facing axle. Then repeat symmetrically to the back.

Building Instructions (Bag 6, Book 2):

Group 23 - Cage

57. Let's make 2 identical parts! Horizontally place a sand green 4L L-shaped lift arm with a sticker in front of you so the axle hole is on the left and the short side is on the right and faces down.

58. Skip this step if you have already placed your sticker! Ask a helper to place sticker 11 on the sand green 4L L-shaped lift arm. This sticker has diagonal black and yellow stripes on it. Make sure the sticker is placed on correctly and is oriented on the build correctly, ask a sighted person to check.

59. Insert a black 2L pin into the 2nd front-facing pinhole from the left. Now insert a white 3L pin axle into the leftmost front-facing axle hole so the axle faces the back and the pin faces the front.

60. Attach the 3 rightmost pinholes of a sand green 9L lift arm to the front-facing pins.

61. Insert a black 2L pin into the leftmost back-facing pinhole. Then insert a blue 2L pin axle into the 3rd back-facing pinhole from the left so the axle faces the back. Now horizontally attach the 3 rightmost columns of the longer side of a yellow 11L bent liftarm to the 2 ppp so the short side is on the left and faces down.

62.1. Lay your part on its side so it is horizontal and the bent lift arm is on the left, and the short side of it faces the back. Now let's make a part! Horizontally place a yellow 1x6x5 rounded fence with an x in front of you. Then insert a light grey 3L axle into the leftmost and rightmost top-facing axle holes. Now insert a dark grey 3L pin axle into the leftmost bottom-facing axle hole so the 2L pin faces down.

62.2. Horizontally place the rightmost column of your part on the right top-facing axle so the pin on the leftmost column attaches to the pinhole below it.

63. Horizontally place a light grey 1x2 grill tile on top of the 1x6x5 fence with an x so it is centered horizontally on it. Now place a light grey 1L bushing on top of each of the top-facing axles so they go all the way down.

64. Let's make a part! Horizontally place a yellow 1x6x5 rounded fence with an x in front of you. Now horizontally place a light grey 1x2 grill tile on top so it is centered horizontally. Now horizontally place your part on top of the 2 top-facing axles so the grill tile faces down. Then place a dark grey 3L pin axle in the leftmost top-facing axle hole of the ppp so the 2L pin faces up.

Group 24 - Cage

65.1. Let's make a part! Horizontally place a sand green 4L L-shaped lift arm with a sticker in front of you so the axle hole is on the right and the short side is on the left and faces down.

65.2. Skip this step if you have already placed your sticker! Ask a helper to place sticker 11 on the sand green 4L L-shaped lift arm. This sticker has diagonal black and yellow stripes on it. Make sure the sticker is placed on correctly and is oriented on the build correctly, ask a sighted person to check.

65.3. Insert a white 3L pin axle into the rightmost front-facing axle hole so the 2L axle faces the back and the pin faces the front. Now insert a black 2L pin into the 2nd front-facing pinhole from the right.

65.4. Horizontally place the axle of your part on the rightmost top-facing axle hole of the 1x6x5 fence with a cross so it overhangs to the right.

66.1. Let's make 2 identical parts! Horizontally place a light grey 11L axle in front of you. Then attach a yellow 2L ridged axle connector to the left side of the axle. Then repeat symmetrically to the right.

66.2. Insert a blue 2L pin axle into the left-facing axle hole so the pin faces the left. Then repeat symmetrically to the right.

66.3. Now you should have 2 identical parts! Vertically place 1 on the front pinhole of the leftmost column. Then place another 1 on the pinhole to the left of the 1x6x5 fences so there are 3 pinholes in between them.

67.1. Horizontally attach the rightmost pinhole of the longer side of a yellow 11 bent lift arm to the 2L topfacing pin that is on the leftmost column of the 1x6x5 fence so it also attaches to the 2 pins that are to the left.

67.2. Place a black 2L pin to the left of the top-facing pin. Then place a blue 2L pin axle to the right of the 2 leftmost top-facing pins so the pin faces up.

68. Horizontally place a sand green 9L lift arm on top of the 5 top-facing pins.

69. Now you should have 2 identical parts! Bring back your main build so it is horizontal and the clips face the left. Now lay 1 part on its side so it is vertical and the 11L bent lift arms are in the front and stick up. Now attach the top pinholes in the back of your part to the 2 left-facing pins that are underneath the front row of the main build. Then repeat symmetrically to the back.

Group 25 - Cage

70.1. Let's make a part! Horizontally place a black axle connector with a pin connector in front of you so the axle connector faces the left and the pin connector faces up. Now insert a light grey 3L axle into the left-facing axle hole.

70.2. Vertically attach the front axle hole of a thin black 3L lift arm with a pin to the left-facing axle so it goes all the way in and the pin is in the back and faces the left.

70.3. Horizontally attach a black axle connector with a pin connector to the left-facing axle so the pinhole faces up. Now attach a red 1L pin connector to the left-facing pin.

70.4. Insert a blue 3L pin into the leftmost pin hole so the 2L pin faces up. Then insert a black 2L pin into the rightmost pin hole so the pin faces up.

70.5. Rotate your part so the pins face the back and the thin 3L lift arm sticks up.

70.6. Rotate your main build so it is horizontal and the clips face the back. Now attach the back-facing pins of your part to the front-facing pinholes of the 9L lift arm that is in the front left corner so the thin 3L lift arm sticks up.

71.1. Let's make a part! Horizontally place a black axle connector with a pin connector in front of you so the axle connector faces the right and the pin connector faces up. Now insert a light grey 3L axle into the right-facing axle hole.

71.2. Vertically attach the front axle hole of a thin black 3L lift arm with a pin to the right-facing axle so it goes all the way in and the pin is in the back and faces the right.

71.3. Horizontally attach a black axle connector with a pin connector to the right-facing axle so the pinhole faces up. Now attach a red 1L pin connector to the right-facing pin.

71.4. Insert a blue 3L pin into the rightmost pin hole so the 2L pin faces up. Then insert a black 2L pin into the leftmost pin hole so the pin faces up.

71.5. Rotate your part so the pins face the back and the thin 3L lift arm sticks up.

71.6. Attach the back-facing pins of your part to the front-facing pinholes of the 9L lift arm that is in the front right corner so the thin 3L lift arm sticks up.

72. Lift the left and right sides of your part up so they are upright.

73. Let's make a part! Horizontally place a yellow 2x8 plate in front of you. Then place a yellow 2x2 plate on top so it is centered horizontally.

74.1. Let's make 2 identical parts! Place a yellow 2x2 inverted sloped curved tile in front of you so the higher side is in the back. Now vertically place a yellow 2x4 plate on top so it overhangs 3 rows to the front. Now place a sand green 2x4 tile on the back 4 rows. Then place a yellow 2x2 plate underneath the 2nd and 3rd rows from the front.

74.2. Now you should have 2 identical parts! Vertically place 1 part on the back row of the 2nd and 3rd columns from the left so it slopes and overhangs 4 rows to the back. Then repeat symmetrically to the right.

75. Vertically place 2 light grey 1x2 plates with a bar on the short side, 1 to the right of the other, on the front row of the 2nd and 3rd columns from the left so they overhang 1 row to the front and the bars face the front. Then repeat symmetrically to the right.

76.1. Place a sand green 2x2 sloped curved tile on the 2 leftmost columns so it slopes to the left and there is no overhang. Then repeat symmetrically to the right. Now horizontally place a sand green 2x4 tile with a sticker in between the 2 ppp.

76.2. Skip this step if you have already placed your sticker! Ask a helper to place sticker 9 on the sand green 2x4 tile. This sticker has a dark grey shield with a dinosaur on it. Make sure the sticker is placed on correctly and is oriented on the build correctly, ask a sighted person to check.

77. Horizontally place a light grey 1x2 rounded plate underneath the 2 leftmost columns of the front row. Then repeat symmetrically to the right.

78.1. Place a transparent yellow 1x1 round tile on the front left corner. Then repeat symmetrically to the right.

Group 26 - Cage

78.2. Place 2 transparent red 1x1 round tiles on top, next to the 2 ppp.

79. Rotate your main build so it is vertical and the clips face the front. Now horizontally attach the bars of your part to the front-facing clip so the anti-studs face the back.

80.1. Flip your build upside down so it is horizontal and the upright tiles face the right. Let's make 2 identical parts! Place a light grey 3L T-shaped lift arm in front of you so the 2L part faces the back and the pinholes face up. Now insert a black 2L pin into the front left and front right top-facing pinholes.

80.2. Now you should have 2 identical parts! Attach the pins of 1 part to the 3 rightmost front-facing pinholes of the 1x16 brick that is on the top row so the lift arm sticks up. Then attach another 1 to the left so there are 4 free pinholes in between them.

81.1. Let's make 2 identical parts! Horizontally place a tan 3L pin in front of you so the 2L pin faces the left. Now attach a light grey 2L pin connector to the right-facing pin.

81.2. Now you should have 2 identical parts! Attach the pin of 1 part to the top back-facing pinhole of the right 3L T-shaped liftarm so the pin faces the front. Then repeat symmetrically to the left.

82.1. Let's make 2 identical parts! Place a light grey 3L T-shaped lift arm in front of you so the 2L part faces the back and the pinholes face up. Now insert a black 2L pin into the front left and front right top-facing pinholes.

82.2. Now you should have 2 identical parts! Attach the pins of 1 part to the 3 rightmost back-facing pinholes of the 1x16 brick that is on top so the lift arm sticks up. Then attach another 1 to the left so there are 4 free pinholes in between them. The upper pinholes of the 2 ppp should align with the 2L pin connectors!

83. Insert a tan 3L pin into each of the top back-facing pinholes of the 2 ppp so the 1L pins face the back.

84. Let's make 4 identical parts! Insert a light grey wheel into a black tire. Now you should have 4 identical parts! Attach them to the front-facing and back-facing pins so the hollow sides face outwards.

Now flip your build over so it is right side up and the upright tiles face the right. Now you can press down on the leftmost 1x2 slope tile that is centered vertically to open up the cage!

Bring back your truck and orient it in front of you so it is horizontal and the windshield faces the right. Now attach the leftmost down-facing ball of your current build to the rightmost socket of the truck!

Congratulations on finishing your build! Would you like to inspire other blind people to build LEGO sets? Let's feature your build on our <u>Builders page</u>. It's easy and we will do all the work! Just contact us at info@bricksfortheblind.org and together we will make it happen!

Please signup for our newsletter and follow us on <u>Facebook</u> and <u>Instagram</u> to be the first to know when new instructions are available!

Bricks for the Blind is a registered tax exempt 501(c)(3) corporation.

At the end of the instruction booklets are advertisements for the following 4 LEGO Jurassic Park Theme kits:

76964 Dinosaur Fossils: T. rex Skull

76960 Brachiosaurus Discovery

76962 Baby Bumpy: Ankylosaurus

76965 Dinosaur Missions: Stegosaurus Discovery