

## 43016 Cristiano Ronaldo – Soccer Legend

Adapted by Jordi Isus, Maria Goldoriole, and blind builder Laia Isus. Tested by Peter Durieux.

SIUUU! Score a creative goal with the LEGO® Editions Cristiano Ronaldo – Soccer Legend (43016) building set for boys, girls, and soccer fans ages 12 and up. Kids will be excited to create a highly detailed Cristiano Ronaldo display figure and discover 2 building options – the soccer legend in his signature victory “Siuuu” pose or performing his iconic bicycle kick. The set includes a large CR7 backdrop, a printed signature plaque and a new soccer ball element. The figure also features a new co-molded face, and, once complete, becomes a piece of collectible soccer decor that will bring sporting spirit to any bedroom or office. The kit makes a crowd-pleasing birthday or holiday gift for boys, girls, and sports lovers. Instructions are available digitally in the LEGO Builder app, where star players can track their progress and rotate their creations in 3D. The Set contains 854 pieces.

- **CRISTIANO RONALDO LEGO® Set** – Make the crowd go wild with the LEGO Editions Cristiano Ronaldo – Soccer Legend (43016) building set for boys, girls, and sports fans ages 12 and up.
- **2 POSE OPTIONS** – Kids can assemble the Cristiano Ronaldo figure in the soccer star’s signature celebration “Siuuu” pose or performing his iconic bicycle kick.
- **CRISTIANO RONALDO MERCH** – Packed with details, the LEGO® soccer set includes a large CR7 backdrop, a printed signature plaque and a number 7 jersey, plus a new co-molded face and soccer ball element.
- **SOCCER DECOR** – Display the assembled LEGO® Cristiano Ronaldo model in a bedroom or office as a unique piece of sports decor.
- **GIFT FOR SPORTS LOVERS** – The kit makes a great soccer gift for boys, girls and Cristiano Ronaldo fans on birthdays, holidays, and special occasions.
- **LEGO® EDITIONS COLLECTION** – Show your love for other legendary soccer stars with more sports merch sets, sold separately.
- **A HELPING HAND** – Budding soccer stars can access instructions digitally in the LEGO® Builder app, where they can track progress and rotate the set in 3D.
- **DIMENSIONS** – The 854-piece model soccer figure measures over 10 in. (25 cm) high, 9 in. (23 cm) wide and 5 in. (13 cm) deep in the victory pose.

The front of the box shows a large LEGO figure of Cristiano Ronaldo in the Standing Celebration Pose, proudly wearing the red and green kit of the Portugal national team with the number 7 on his chest. A white LEGO soccer ball rests between his feet on a green base. Behind him is a clean white background, with RONALDO written in green and the figure leaning against a giant number 7. On the left, inside a yellow-and-green shield shape, appear the green letters “CR.” The LEGO logo sits in the top-left corner. On the right, bold letters spell “CR7”, with “Cristiano Ronaldo” written underneath. In the bottom-left corner, the box displays 12+, the set number 43016, and the name Cristiano Ronaldo – Soccer Legend. In the bottom-right corner it lists 854 pieces and the word Editions in bold. The overall design is clean and dynamic, with Ronaldo as the absolute center of attention.

The back of the box features the full Cristiano Ronaldo model in the Bicycle Kick Pose, stretched out in mid-air on black support bases, capturing his iconic acrobatic shot. In the bottom-left corner there is a small image of the same Standing Celebration Pose shown on the front. The background is light and uncluttered, keeping all attention on the dramatic action pose.

This set is a 2 in one set, this means you get one set of pieces that can build two different official models. The set includes instructions for both builds, and each model uses all 854 pieces. To build the alternate model, you first take apart the main model and then rebuild it using the same bricks. This set is for ages 12+ and contains 8 labelled paper bags.

- Welcome to text-based instructions from Bricks for the Blind. Before you start building,
- here are some terms we'll be using:
  - - In Front of/Front: towards you.
  - - Behind/Back: away from you.
  - - Up: towards the ceiling.
  - - Down: towards the floor.
  - - Stud: the bump on a LEGO brick. Example: A 2x1 brick has two studs on it.
  - - Vertically: with the longest side going from front to back
  - - Horizontally: with the longest side going from left to right.
  - - Upright: pointing up towards the ceiling.
  - - Standing upright: The piece is perpendicular to the ground, like a wall.
  - - Lying flat: The piece is parallel to the ground, like a piece of toast which fell off the table.
  - - That one/ppp: previously placed piece.
  - - Plate: piece with studs.
  - - Tile: smooth piece without studs (unless otherwise specified)
  - - A jumper plate is a 1x2 plate with a single stud on top, or a 1x3 plate with only two studs on top.
  - - Anti-stud is a term for the portion of a LEGO piece which accepts studs, like the bottom of a plate or brick.
  - - Left/ right wedge parts: these are parts that when placed in front of you and are pointing to the back, their wedge is on the left/ right side of the part.
  - - Symmetrically: a mirror image. Example: If you place a 2x1 brick with technic connector on the front wall at the right, connector to the front, and then place another such piece symmetrically on the back wall, at the right, the technic connector of the second piece should point to the back, since it will be placed symmetrically.
  - - Centered-vertically: even amount of space in front of and behind piece
  - - Centered-horizontally: even amount of space left and right of piece.
  - - Row: studs lined up horizontally (left to right/side to side).
  - - Column: studs lined up upright or vertically (top to bottom/back to front).
- A note on LEGO Technic™ part names. These parts are different from regular LEGO bricks. Here are some definitions in case the builder or helper is not familiar with LEGO Technic™.
  - - Axles - An axle is a connector which has an X shaped cross-section. Because their cross section is not round, anything connected to an axle using an axle-hole will rotate with that axle. Axles are longer than they are wide, and the length of an axle corresponds with how many bricks long it is. Aka a 3L axle is three bricks long. Axles come in a variety of lengths, with a 2L axle being the shortest available. They may be combined with pins or have circular stops on them. A stop prevents the axle from sliding through an axle-hole at a specific point on the axle.
  - - Pins - A pin is a connector which has a circular cross section and a flanged notch out of one or both ends. This flanged notch allows them to click into bricks with a pinhole. Pins come with and without friction ridges, which are small bumps on the pin which prevent them from rotating freely. For standard pins, black is a high friction pin, and gray is a low friction pin. A standard-length pin is two brick lengths long, with a stop in the middle. This prevents a brick from being pushed from one side of the pin to the other. A 1L pin is one brick long and still retains the stop; however, it also includes a

hollow stud at the other end. A 3L pin is three bricks long, and only contains a stop at one side, allowing two bricks to be pushed onto the other side of the pin. Pins may also have one side which is an axle.

- - Technic brick - a brick which contains one or more holes which accept technic pins.
- - Lift-arms - A lift-arm is a basic structural element, like a brick or a plate, but usually without any studs. It is a beam with rounded ends and with holes in it, with the same spacing as the studs on a LEGO brick. lift-arms come in a variety of lengths, including a 1x1 lift-arm which looks like a cylinder. Thick lift- arms are as wide as a LEGO brick, and thin lift-arms are half as wide as a LEGO brick, but not the same thickness as a LEGO plate! The holes in a lift-arm arm may accept axles or pins. They also come in a variety of shapes, including tees, ells, and triangles.
- - Gears - A gear is a functional element. They are typically discs with teeth on the outside; there are also worm gears which look like a spiraling cylinder! Gears connected by axles transmit or even transform rotational motion!
- - Axle and Pin Connectors - These elements are typically smaller than lift-arms and are used to connect some combination of pins or axles. They might have pins or axles, as well as axle or pinholes. They have a lot of different angle combinations! The simplest just connects two axles or pins together in a straight line.
- - Bushes/Bushings - LEGO Technic™ uses bushes largely as spacers, but they also can reduce friction between rotating parts or can form useful elements such as bars. Bushes are typically light gray, cylindrical, and have an axle-hole running through the middle. They have a flange at the front and back to make it easier to pull on and off.
- For builders with low vision, or a sighted building partner who may want to follow along with the printed visual instructions that come with each kit, PDF versions are always online at LEGO.com: (<https://www.lego.com/en-us/service/building-instructions/43016>) As low vision users may benefit from viewing the instructions on a personal device where they can zoom in on content and use assistive technologies to enhance the visuals.

Sorting the pieces:

To begin a successful build, it helps to sort the pieces into groups, bags, or small containers. Have a sighted friend or family member do this in advance following the instructions below. You will see that the pieces should be sorted into groups according to the building steps in the set. Doing this in advance makes locating the pieces easier. See below on how to sort the pieces to correspond to the steps in this set. Number the containers using letters A-Z, Numbers, or meaningful names. The parts will be collected into a small Number from steps in the instructions. Example: Steps 1-3 means collecting all the parts used in steps 1, 2 and 3, and putting them in one container.

This set comes with 8 labelled paper bags, and 2 instruction sets one for each building option as it is a 2 in 1 set.

Sort the pieces into groups as described below. Note that where there are multiple colors of the same brick in a step, the colors will be split across two groups to make telling the difference easier for the builder!

LEGO includes a few spare parts in case you lose something. Set these into their own group away from the rest, in case you need them later.

Book 1, Build 1: Cristiano Ronaldo performing his iconic bicycle kick.

Bag 1

Group 1: contains the pieces for steps 1-3.

Group 2: contains the pieces for steps 4-10.

Group 3: contains the pieces for step 11.

Group 4: contains the pieces for steps 12-14.

Group 5: contains the pieces for steps 15-22.

Group 6: contains the pieces for steps 23-24.

Group 7: contains the pieces for steps 25-26.1.

Group 8: contains the pieces for steps 26.2 -32.

Bag 2

Group 9: contains the pieces for steps 33-36.1.

Group 10: contains the pieces for steps 36.2-40.1.

Group 11: contains the pieces for steps 40.2-43.

Group 12: contains the pieces for step 44.1.

Group 13: contains the pieces for steps 44.2-53.

Group 14: contains the pieces for step 54.1.

Group 15: contains the pieces for step 54.2.

Group 16: contains the pieces for steps 54.3-59.

Group 17: contains the pieces for steps 60-63.

Group 18: contains the pieces for steps 64-65.

Group 19: contains the pieces for steps 66-76.

Bag 3

Group 20: contains the pieces for steps 77-82.

Group 21: contains the pieces for steps 83-90.

Group 22: contains the pieces for steps 91-93.

Group 23: contains the pieces for steps 94-100.

Group 24: contains the pieces for step 101.1.

Group 25: contains the pieces for step 101.2.

Group 26: contains the pieces for steps 102-111.

Bag 4

Group 27: contains the pieces for steps 112-115.

Group 28: contains the pieces for steps 116-126.

Group 29: contains the pieces for step 127.1.

Group 30: contains the pieces for steps 127.2 -130.1.

Group 31: contains the pieces for steps 130.2-135.

Group 32: contains the pieces for steps 136-140.

Bag 5

Group 33: contains the pieces for steps 141-160.

Group 34: contains the pieces for steps 161-163.1.

Group 35: contains the pieces for steps 163.2-165.

Group 36: contains the pieces for steps 166-174.

Group 37: contains the pieces for steps 175-176.

Group 38: contains the pieces for steps 177-179.

Bag 6

Group 39: contains the pieces for steps 180-189.

Group 40: contains the pieces for steps 190-191.

Group 41: contains the pieces for steps 192-209.

Group 42: contains the pieces for steps 210-211.

Bag 7

Group 43: contains the pieces for steps 212-221.

Group 44: contains the pieces for steps 222-226.1.

Group 45: contains the pieces for steps 226.2-227.

Group 46: contains the pieces for steps 228-236.1.

Group 47: contains the pieces for steps 236.2-238.

Group 48: contains the pieces for steps 239-240.

Group 49: contains the pieces for step 241.

Group 50: contains the pieces for steps 242-250.

Group 51: contains the pieces for steps 251-252.

Group 52: contains the pieces for step 253.

Group 53: contains the pieces for step 254.

Group 54: contains the pieces for step 255.

Group 55: contains the pieces for step 256.

Group 56: contains the pieces for steps 257-258.

Group 57: contains the pieces for steps 259-261.

Group 58: contains the pieces for steps 262-264.

Group 59: contains the pieces for steps 265-274.

Bag 8

Group 60: contains the pieces for steps 275-281.1.

Group 61: contains the pieces for steps 281.2.-289.

Group 62: contains the pieces for steps 290-296.

Group 63: contains the pieces for steps 297-300.

Group 64: contains the pieces for steps 301-308.

Group 65: contains the pieces for steps 309-320.

Group 66: contains the pieces for steps 321-323.

#### Description of the main model:

The main model stands on a green base that represents the football pitch. On the back-right corner of the pitch rises a large upright number seven, built in metallic gold. Attached to the front of this number seven is a golden plaque with the letters CR set against a dark green background, giving it a premium display look.

On the pitch itself, there are two black support stands:

- one at the front center,
- and one at the back left.

These supports hold Cristiano Ronaldo in his iconic bicycle-kick pose.

Ronaldo is wearing the official Portugal national team kit, with a red shirt and green shorts. His arms, hands, and fingers are poseable, and his head can turn, allowing small adjustments to the action pose.

The back-left support holds Ronaldo's right leg, stretched high toward the sky as he prepares to strike. The front support holds his back, keeping the whole mid-air movement stable.

A FIFA Official Match Ball, in white, blue, and pink, is connected to the number seven by a bar, floating in the air as if caught in the perfect moment before impact. The tip of Ronaldo's raised shoe points directly toward the ball, capturing the instant just before the legendary kick.

At the front of the base, there is a black nameplate with Cristiano Ronaldo's signature in gold, completing the display with a premium finish.

#### General placement guidelines

##### 1. Rows and Columns Across the Whole Build:

Unless we say otherwise, rows are counted from front to back or back to front, and columns are counted from left to right or from right to left across the entire build.

Example: Vertically place a tan 1x2 plate on the 4th and 5<sup>th</sup> rows from the front on the 3rd column from the left. or place a white 2x2 tile with stud on the 2 back rows on the 3<sup>rd</sup> and 4<sup>th</sup> columns from the right.

This uses the full build's row and column Layout.

##### 2. Why We Sometimes Count Columns from a Specific Row:

Each row can have a different number of columns. This happens when the build becomes narrower or wider toward the sides, or when certain rows have cutouts, curves, or irregular shapes.

So, if a row is shorter or wider than the rows above or below it, counting columns across the whole build becomes misleading. To avoid confusion, we count columns within that specific row.

Example: Instead of: Place the 1x2 plate on the front row on the 2nd and 3rd columns from the right. We say: Place the 1x2 plate on the 2nd and 3rd columns from the right of the front row.

This makes it clear that the row itself is the reference, not the whole build.

### 3. Why We Sometimes Count Rows from a Specific Column:

Each column can have a different number of rows. This happens when one column extends further back than the next, another extends forward, some columns are tall, others short, or the shape is staggered or irregular. When columns vary in height or depth, counting rows across the entire build becomes confusing. To avoid this, we count rows within that specific column.

Example: Place a tan 1x1 round plate on the 3rd row from the back of the 2nd column from the right.

This avoids the problem of columns with different lengths.

### 4. Using Landmarks for Tactile Orientation:

When rows and columns alone aren't enough, we add landmarks—nearby pieces that help the builder feel where the new piece belongs.

Example: Vertically place a green 2x4 plate on the 2nd through 5th rows from the back on the 2nd and 3rd columns from the left, so the back row sits on the front row of the back left 2x2 corner plate, and the front row sits on the back row of the front left 2x2 corner plate.

These tactile cues confirm the correct placement.

## General technic guidelines

1. In this set, you will use Technic elements such as liftarms, pins, axles, and connectors. Liftarms may appear in different shapes (for example, straight, L-shaped, bent, or T-shaped), and they may include both pin holes (round) and axle holes (cross-shaped). Liftarms also come in two thicknesses, which affects how far pins and axles extend when inserted.

Liftarm Thickness: Thick vs. Thin:

- A thick liftarm is the standard type and is 1L thick.
- A thin liftarm is 0.5L thick (half the thickness of a regular liftarm).

When a step uses a thin liftarm, the instruction will always say so. If the instruction does not mention thickness, you should assume the liftarm is the standard 1L thick type.

This is important because they are half as thick, and a pin or axle inserted through a thin liftarm will extend 0.5L farther on 1 side compared to the same pin inserted through a thick liftarm.

Example

- In a 3L thick liftarm, inserting a 2L pin from front to back leaves 1L extending toward the front.

- In a 3L thin liftarm, inserting the same 2L pin from front to back leaves 1.5L extending toward the front.

## 2. Counting the Holes

- When a liftarm has both pin holes and axle holes, we count all holes in order, from one end of the liftarm to the other.

- Unless the instruction specifically says, in the axle hole or in the pin hole, you should assume the counting includes both types of holes together.

- The instruction will always tell you which direction to count from: from the right or from the left.

### Examples

- Insert a tan 2L pin into the 2nd back-facing hole from the right.

Count all holes (pin and axle) starting at the right end. Place the pin in the second hole.

- Insert a black 2L axle into the 3rd hole from the left.

Count all holes from the left end until the third one, regardless of type.

- Insert a blue pin into the axle hole in the 4th position from the right.

Here, the instruction specifies axle hole, so place the pin in the cross-shaped hole at that position.

## 3. Directional Guidance for Inserting or Attaching Pieces

To make Technic building smoother for blind builders, we always specify the exact direction a pin, axle, or connector moves when it is inserted or attached.

We use the following terms:

- front to back — the piece moves away from you

- back to front — the piece moves toward you

- top to bottom — the piece moves downward

- bottom to top — the piece moves upward

### Examples

- Insert a black 2L pin from front to back into the second front-facing hole from the right of your 5L liftarm.

- Insert a 3L pin from back to front into the 3<sup>rd</sup> back facing pin hole from the left, so 2L of the pin extends to the back. Attach the leftmost front facing hole of your 7L liftarm from back to front onto the 2L back extending pin.

## 4. Specifying How Far a Pin or Axle Extends

After inserting or attaching a piece, we always tell you how much of the pin or axle extends in each direction, using Technic length units (L).

This measurement automatically accounts for whether the liftarm is thick or thin.

### Examples

- Insert a black 2L pin from front to back into the second front-facing hole from the right of the 5L liftarm, so 1L of the pin extends toward the front.

- Attach the leftmost back-facing hole of a 7L liftarm from front to back onto the 1L pin extending at the front.

These technic guidelines help to make Technic-set building easier for blind builders.

Let's get to building!

Building Instructions (Bag 1, Book 1):

Group 1:

1. Place a black 4x4 corner plate in front of you, so the right angle faces the back right and it looks like a large braille letter D. Horizontally place the 4 right columns of a black 1x8 brick on the back row of the ppp, so 4 columns overhang to the left.
2. Vertically place a black 1x4 brick with 4 side studs on 1 long side in front of the rightmost column of the ppp, so the side studs face the right, and 1 row overhangs to the front.
3. Vertically place the back row of a black 2x4 plate with 3 holes underneath the 2 left columns of your build.

Group 2:

4. Vertically place the back right corner of a dark grey 2x4 plate underneath the front overhang.
5. Vertically place a black 1x2 log brick on the 2<sup>nd</sup> and 3<sup>rd</sup> rows from the front on the rightmost column of your build, so it sits in front of the vertical 1x4 brick with 4 right facing side studs. Vertically place a black 1x4 brick with 4 side studs on 1 long side in front of the ppp, so the side studs face the right, and 3 rows overhang to the front.
6. Let's make a part. Vertically place a dark grey 2x4 plate in front of you. Vertically place a white 1x10 brick with 9 pin holes on top of the ppp on the left column, so the pin holes face the right and the left and it is centered vertically. Bring back your main build and position it vertically in front of you so the overhang is on the front right. Vertically place the 3 back overhanging rows of your part on the 2<sup>nd</sup> through 4<sup>th</sup> rows from the back on the leftmost column of your main build.
7. Vertically place the back right corner of a black 4x4 corner plate underneath the front right overhang, so the right angle faces the front right and it looks like a large braille letter J. repeat symmetrically to the left.
8. Vertically place a dark grey 1x10 brick on top of your build on the 2<sup>nd</sup> column from the right, so it is centered vertically. Repeat symmetrically to the left.
9. Horizontally place a yellow 1x4 plate to the right of the front top of the ppp., so it sits between the 2 ppps.
10. Horizontally place 2 black 1x4 bricks with 4 side studs on 1 long side 1 to the right of the other on the front row, so the side studs face the front and there's no overhang.

Group 3:

- 11.1 Let's make 2 identical parts! Horizontally place a black 6x8 brick with pin holes and open center in front of you. insert a black 2L pin from right to left into the right frontmost facing pin hole, so 1L of the pin extends to the right. Insert the pin end of a blue 2L pin axle from right to left into the right backmost facing pin hole, so the 1L axle end extends to the right. repeat both parts symmetrically to the left. You should now have 2 identical parts! Tacke one of your parts

and rotate it 180 degrees, so the protruding axles face the left close to the front left corner and the right close to the front right corner. Insert a black 2L pin from front to back into the front leftmost facing pin hole, so 1L of the pin extends forward. Repeat symmetrically to the right. Horizontally attach the back leftmost and the back rightmost facing pin holes of the other part the one you haven't rotated from front to back onto the 2 black 1L front facing pins.

11.2 Bring back your main build and position it vertically in front of you so the 1x10 brick with 9 pin holes is vertically on the left with its pin holes facing the left and the right. Align the right side of your sub build with the left side of your main build so the corners are even. Insert the right protruding pins and axles from left to right into the left facing pin holes of your main build. Press firmly to secure.

Group 4:

12. Let's make a sub build! Place a black 4x4 corner plate in front of you, so the right angle faces the back left and it looks like a large braille letter F. Horizontally place the 4 left columns of a black 1x8 brick on the back row of the ppp, so 4 columns overhang to the right.

13. Vertically place a black 1x4 brick with 4 side studs on 1 long side in front of the leftmost column of the ppp, so the side studs face the left, and 1 row overhangs to the front.

14. Vertically place the back row of a black 2x4 plate with 3 holes underneath the 2 right columns of your build.

Group 5:

15. Vertically place the back left corner of a dark grey 2x4 plate underneath the front overhang.

16. Vertically place a black 1x2 log brick on the 2<sup>nd</sup> and 3<sup>rd</sup> rows from the front on the leftmost column of your build, so it sits in front of the vertical 1x4 brick with 4 left facing side studs. Vertically place a black 1x4 brick with 4 side studs on 1 long side in front of the ppp, so the side studs face the left, and 3 rows overhang to the front.

17. Let's make a part! Vertically place a dark grey 2x4 plate in front of you. Vertically place a white 1x10 brick with 9 pin holes on top of the ppp on the right column, so the pin holes face the right and the left and it is centered vertically. Bring back your main build and position it vertically in front of you so the overhang is on the front left. Vertically place the 3 back overhanging rows of your part on the 2<sup>nd</sup> through 4<sup>th</sup> rows from the back on the rightmost column of your main build.

18. Vertically place the back left corner of a black 4x4 corner plate underneath the front left overhang, so the right angle faces the front left, and it looks like a large braille letter H. Repeat symmetrically to the right.

19. Vertically place a dark grey 1x10 brick on top of your build on the 2<sup>nd</sup> column from the left, so it is centered vertically. Repeat symmetrically to the right.

20. Horizontally place a yellow 1x4 plate to the left of the front row of the ppp, so it sits between the 2 ppps.

21. Horizontally place 2 black 1x4 bricks with 4 side studs on 1 long side 1 to the right of the other on the front row, so the side studs face the front and there's no overhang.

22. Bring back your main build and position it horizontally in front of you so the 2 protruding 1L axles and 2 1L pins face the left. Align the right side of your sub build with the left side of your main build so the corners are even. Insert the left protruding pins and axles from right to left into the right facing pin holes of your main build. Press firmly to secure.

Group 6:

23. Let's make 2 identical parts! Horizontally place a green 1x4 plate in front of you. Horizontally place the 2 left columns of a green 1x6x1 slope tile with 1x2x1/3 cutout on the ppp, so it slopes to the right and 4 columns extend to the right. Repeat symmetrically to the left. You should now have 2 identical parts! Bring back your main build and place it vertically in front of you. Horizontally place one of your parts upright on the front facing side studs, so there's no overhang. Repeat symmetrically to the back.

24. Let's make 2 identical parts! Horizontally place a green 1x2 plate in front of you. Horizontally place the 2 left columns of a green 1x6x1 slope tile with 1x2x1/3 cutout on the ppp, so it slopes to the right. You should now have 2 identical parts! Bring back your main build and position it horizontally in front of you, so the side studs face the front. Take 1 of your parts and horizontally place it upright on the 6 right columns of front facing side studs, so it slopes to the right. Repeat symmetrically to the left.

Group 7:

25. Turn your build upside down, so the 2 parts you have just attached are facing the back. Vertically place a black 1x2 plate on the 2 front rows on the 9th column from the right of antistuds, so it sits to the left of the vertical right black 2x4 plate with 3 holes. Repeat symmetrically to the left. Then, repeat both placements symmetrically to the back.

26.1 Place a dark blue 2x2 inverted tile on top of your upside down build on the 9<sup>th</sup> and 10<sup>th</sup> columns from the right, so it is centered vertically. Repeat symmetrically to the left.

Group 8:

26.2 Place 2 yellow 2x2 inverted tiles one to the right of the other to the right of the ppp, between the 2 ppps.

27. Let's make a part! Place a black 4x4 plate in front of you. Horizontally place a black 2x4 brick with 3 top facing axle holes on top of the ppp, so it is centered vertically. place 2 dark grey 2x2 inverted slope bricks one to the right of the other behind the ppp, so they slope upward to the back. Bring back your upside down main build and position it horizontally in front of you so the side with no side studs faces the front. turn your part upside down so the slopes are on the back. Place the front row of your part on top of your main build on the front row of antistuds, so it is centered horizontally and fills the front gap.

28. Turn your build right side up so the side studs face the front. Horizontally place a dark grey 1x2 plate with 2x2 upright facing side studs underneath the 5<sup>th</sup> and 6<sup>th</sup> columns from the left of the back row of your main build, so the side studs face the back.

29. Horizontally place a green 1x4 plate on top of your main build on the back row on the 3<sup>rd</sup> through 6<sup>th</sup> columns from the left. Vertically place the back row of a green 2x6 tile to the left of the ppp. Vertically place another in front of the ppp. Now, repeat the 3 placements symmetrically to the right.

30. Vertically place a green 2x6 tile on the 6 front rows on the 5<sup>th</sup> and 6<sup>th</sup> columns from the right of visible studs. Horizontally place the 2 right columns of another behind the ppp. Place 2 more horizontally one behind the other behind the ppp. Repeat the 4 placements to the left.

31. Place a green 2x6 tile on the 6 front rows on the 9<sup>th</sup> and 10<sup>th</sup> columns counting the entire build, so it sits to the left of a vertical 2x6 tile. Vertically place a green 2x6 plate with 5 holes to the left of the ppp so it attaches to the main build by the front and the back rows.

32. Vertically place a green 1x6 tile to the left of the ppp. Vertically place a green 2x6 tile to the left of the ppp. Now, place a green 1x6 tile vertically to the left of the ppp.

“Fantastic start! In this bag you’ve built the strong base and begun shaping the big green field, even though it’s not fully finished yet. You’ve laid the ground where all the action will happen. When you’re ready, open Bag 2 and keep the fun rolling — the build is just getting exciting.

Building Instructions (Bag 2, Book 1):

Group 9:

33. Let’s make a sub build. Horizontally place a green 2x4 plate in front of you.

34. Horizontally place a green 1x2 brick with axle hole on the back right corner with the axle hole facing the front and the back. Horizontally place another to the left of the ppp. Repeat both placements symmetrically to the front.

35. Vertically place a green 1x2 brick with axle hole on top of your sub build on the rightmost column.

36.1 Horizontally place a green 1x3 brick to the left of the back row of the ppp. Place a white 1x1 brick in front of the rightmost column of the ppp. Place another on the front left corner of your sub build.

Group 10:

36.2 Place a black 1x1 brick to the right of the ppp.

37. Horizontally place a green 2x4 plate on top of your sub build, so there’s no overhang.

38. Vertically place a green 1x2 brick with axle hole on top of your sub build on the rightmost column with the axle hole facing the left and the right.

39. Horizontally place a green 1x3 brick to the left of the back row of the ppp.

40.1 Horizontally place a white 1x3 plate in front of the ppp. Place a gold 1x1 plate on top of the ppp on the leftmost column. Skip 1 column to the right and place another.

Group 11:

40.2 Place a dark blue 1x1 plate to the left of the ppp, so it sits between the 2 gold 1x1 plates. Horizontally place a white 1x3 plate on top of the 3 ppps.

41. Horizontally place a green 2x4 plate on top of your sub build, so there’s no overhang.

42. Place 2 green 1x1 bricks with pin hole one in front of the other on top of the ppp on the rightmost column, so the pin holes face the left and the right.

43. Horizontally place a green 1x3 brick on top of your sub build on the back row on the 3 left columns.

Group 12:

44.1 Horizontally place a black 1x3 plate in front of the ppp. Place a white 1x1 plate on top of the ppp on the leftmost column. Skip 1 column to the right and place another.

Group 13:

44.2 Place a red 1x1 plate to the left of the ppp, so it sits between the 2 white 1x1 plates. Then, horizontally place a red 1x3 plate on top of the 3 ppps.

45. Horizontally place a green 2x4 brick on top of your sub build, so there's no overhang. Place 2 green 2x2 tiles with upright 1x2 plate one to the right of the other on top of your sub build with the side studs facing the back. Horizontally place a tan 1x4 plate upright on the back facing side studs.

46. Rotate your sub build 90 degrees counterclockwise, so the side studs face the left. Then, flip it, so it sits on the right side with the studs of the ppp facing up on the right and the antistuds facing the left. Vertically attach the side studs of 2 green 1x2 bricks with 1x2 side studs on 1 long side one in front of the other to the left facing antistuds of your sub build. Now, vertically place a tan 1x4 plate underneath the 2 ppps.

47. Rotate your sub build 90 degrees clockwise, so the 3 ppps are on the back. Bring back your main build and position it horizontally in front of you, so the side with no green 1x6x1 slope tiles faces the back. Vertically place your sub build on the right gap so the front row attaches to a horizontal yellow 1x4 plate on the 2<sup>nd</sup> row from the front of visible studs.

48. Let's make a sub build! Stack 3 green 2x2 bricks.

49. Horizontally place 2 dark green 1x2 plates, one in front of the other on top of your stack.

50. Horizontally place the 2 right columns of a green 2x4 brick on top of your sub build, so 2 columns overhang to the left.

51. Horizontally place a dark green 1x2 plate underneath the 2 back left columns of the ppp. Next, place a black 1x2x3 brick horizontally underneath the ppp.

52. Stack 2 green 1x2x1 2/3 bricks with 2x2 side studs on a long side. Then, horizontally place your stack underneath the front left overhanging corner of your sub build, so the side studs face the front.

53. Place a green 1x1 brick with pin hole on top of your sub build on the back right corner with the pin hole facing the left and the right.

Group 14:

54.1 Horizontally place a white 1x3 plate to the left of the ppp.

Group 15:

54.2 Horizontally place a green 1x3 plate on top of the ppp.

Group 16:

54.3 Horizontally place white 1x3 plate on top of the ppp.

55. Horizontally place a green 1x3 brick in front of the ppp. Place a green 1x1 brick with pin hole to the right of the ppp, so the pin hole faces the right and the left.

56. Horizontally place a green 2x4 brick on top of your sub build, so there's no overhang. Place 2 green 2x2 tiles with upright 1x2 plate one to the right of the other on top of your sub build with the side studs facing the front. Horizontally place a tan 1x4 plate upright on the front facing side studs.

57. Rotate your sub build 90 degrees clockwise, so the side studs face the left. Then, flip it, so it sits on the right side with the studs of the ppp facing up on the right and the antistuds facing the left. Vertically attach the side studs of 2 green 1x2 bricks with 1x2 side studs on 1 long side one in front of the other to the left facing antistuds of your sub build. Now, vertically place a tan 1x4 plate underneath the 2 ppps.

58. Rotate your sub build 90 degrees clockwise, so the 3 ppps are on the back. Bring back your main build and position it horizontally in front of you, so the side without side green 1x6x1 slope tiles faces the back. Vertically place your sub build on the left gap, so the front row attaches to a horizontal yellow 1x4 plate on the 2<sup>nd</sup> row from the front of visible studs.

59. Horizontally place a green 2x4 tile on top of your main build on the 2 front rows on the 4 left columns of visible studs, so the back row sits on the tan 1x4 plate of the sub build you attached in the previous step, and the front row sits on 2 horizontal 1x4 bricks with 1x4 side studs. Repeat symmetrically to the right.

Group 17:

60. Locate 2 columns of studs on the 6 front rows that are centered horizontally on your main build. Vertically place a black 1x2 inverted half arch brick on the 2<sup>nd</sup> and 3<sup>rd</sup> rows from the front on the right column of studs you have found, so it slopes to the front. repeat symmetrically to the left. Then, place 2 more vertically one to the right of the other behind the ppps, so they slope to the back.

61. Horizontally place a black 1x2 hinge brick base upright on the 2 right columns of front facing side studs to the left of the right sloping 1x6x1 slope tile, so the open side of the brick is on the top. Repeat symmetrically to the left.

62. Place a black 2x2 plate on top of the 4 vertical 1x2 inverted half arch bricks. Horizontally place 2 black 1x2x3 bricks one in front of the other on top of the ppp. Place a black 2x2 plate on top of the ppps. Vertically place a black 1x2 slope tile on the left column of the ppp, so it slopes to the left. Repeat symmetrically to the right.

63. Let's make a part! Horizontally place a black 2x12 plate in front of you. Horizontally place a black 2x6 tile printed with the signature of Cristiano Ronaldo and his name in gold. Horizontally place a black 2x3 pentagonal tile to the left of the ppp, so the triangular tip points to the left. Repeat symmetrically to the right. Place a black 2x2 plate with 1x2 antistuds and bottom bar handle underneath the 2 left columns of your part, so the bar handle is on the front. Repeat symmetrically to the right. Bring back your main build and position it horizontally in front of you, so the 2 1x2 hinge bricks base face the front. Attach the bottom front bar handles of your part to the front facing hinge bricks. Press the top side of your attached part towards the back until it reaches the green tiles.

Group 18:

64.1 Let's make a part! Horizontally place a dark grey 1x2 plate with 2x2 upright facing side studs in front of you, so the side studs face the back. Place the back row of a black 2x2 brick on the ppp, so 1 row overhangs to the front.

64.2 Vertically place the back row of a black 2x4 plate underneath the front overhang, so 3 rows are exposed to the front.

64.3 Horizontally place a black 1x2 plate on top of your part on the back row. Horizontally place a dark grey 1x2 plate with 2x2 upright side studs on top of the ppp, so the side studs face the back. Horizontally place a black 1x2 plate on top of the ppp. Vertically place 2 black 1x5x4 inverted half arch bricks one to the right of the other on top of your part on the 5 back rows, so they slope to the front. Bring back your main build, so the Ronaldo's signature plaque faces the front. Vertically place your part on the 5 back rows on the 3<sup>rd</sup> and 4<sup>th</sup> columns from the left of your main build. This is a support.

65. Vertically place a black 1x2 slope tile with cutout on the leftmost column of the 5<sup>th</sup> and 6<sup>th</sup> rows from the back (here, we are counting only the columns of the 2 mentioned rows), so it slopes to the front. Vertically place another to the right of the ppp, so it slopes to the front.

Group 19:

66. Let's make a part! Vertically place a black 1x2 plate in front of you. Then, horizontally place a 1x5x4 half arch brick on the back row, so 4 rows overhang to the right.

67. Repeat symmetrically to the front.

68. Vertically place a black 1x2 log brick on top of your part on the leftmost column. Place a black 2x2 plate on top of your part on the 2 left columns.

69. Vertically place a black 1x2 plate with 2x2 side studs hanging down on the left column of the ppp, so the side studs face the left.

70. Vertically place a black 1x2 plate to the right of the ppp.

71. Place the left column of a black 1x2 brick with hole with a 1x2 plate on top of the ppp, so the 1x2 plate faces the right and the pin hole faces the left. Vertically place a black 1x2 log brick to the left of the ppp.

72. Place 2 black 1x2 bricks with pin hole one to the right of the other on top of your part on the 2 right columns, so their pin holes face the left and the right. Vertically place a black 1x2 plate to the left of the ppps.

73. Horizontally place a black 2x4 plate on top of your part on the 4 left columns.

74. Vertically place a black 1x2 plate with 2x2 side studs hanging down on top of your part on the leftmost column, so the side studs face the left. Place a black 2x2 plate to the right of the ppp. Now, place a black 2x2 curved slope tile to the right of the ppp, so it slopes to the right.

75. Rotate your part 90 degrees clockwise, so the overhang of the half arch brick faces the front. Bring back your main build and position it horizontally in front of you, so the Ronaldo's signature plaque faces the front. Vertically place your part on the back row on the 3<sup>rd</sup> and 4<sup>th</sup> columns from the left of visible studs, so the side studs face the back. This is a support.

76. Let's make a part! Vertically place a black 2x12 plate in front of you. Place the front row of a black 2x2 curves slope tile on the back row, so it slopes to the back, and 1 row extends to the back. Place a black 2x2 plate in front of the ppp. Repeat both parts symmetrically to the front. Vertically place a black 2x6 tile on top of your part, so it is centered vertically. Bring back your main build and position it horizontally in front of you so the Ronaldo's signature plaque faces the front. Vertically place your part upright on the back facing side studs securing the previous attached part from step 75 to the base.

Great progress! In this bag you've completed the whole base and added two strong supports — one at the front and another on the back left. You also built Cristiano Ronaldo's signature plaque, giving the model its first real touch of legend. When you're ready, open Bag 3 and keep the momentum going — the build is taking shape beautifully.

Building Instructions (Bag 3, Book 1):

Group 20:

77. Let's start building the number seven build! Vertically place a red upside down 4x6 plate in front of you. Horizontally place the 2 left columns of a tan 1x4 hinge plate on the back right corner, so the rounded hinge part faces the back, and 2 columns overhang to the right.

78. Horizontally place a black 1x2 plate in front of the 2 left columns of the ppp.

79. Vertically place the 2 front rows of a black 2x3 plate to the left of the 2 ppps, so 1 row overhangs to the back. Take a black 4x6 tile with studs on 3 edges and orient it vertically so the

studs face down and the edge with no studs is on the right. Then, vertically place its 2 left columns in front of the ppp, so 2 rows overhang to the front.

80. Vertically place the 2 back rows of an upside down red 2x16 plate underneath the front left corner, so 14 rows of antistuds extend to the front. Repeat symmetrically to the right.

81. Vertically place a black 4x6 tile with studs on 3 edges on top of your sub build on the 3<sup>rd</sup> through 8<sup>th</sup> rows from the front, so the edge without studs faces the right. Vertically place another behind the ppp, so the edge with no studs faces the right.

82. Vertically place a black 2x3 plate on top of your part on the front right corner, so 1 row overhangs to the front. Horizontally place a black 1x2 plate to the left of the back row of the ppp.

Group 21:

83. Horizontally place the 2 right columns of a tan 1x4 hinge plate in front of the ppp, so the rounded hinge part faces the front and 2 columns overhang to the left.

84. Let's make a part! Vertically place a red 2x16 plate in front of you. Horizontally place the 2 left columns of a black 2x3 plate underneath the 2 back rows of the ppp, so 1 column extends to the right.

85. Vertically place a black 2x3 plate in front of the 2 left columns of the ppp.

86. Vertically place the 2 back rows of a red 1x8 plate on the rightmost column of your part, so it sits on the back horizontal 2x3 plate, and 6 rows overhang to the front.

87. Bring back your sub build and place it vertically in front of you, in the same position as step 83. Turn your part upside down, so the pppps are on the front. push the left overhanging hinge plate of your sub build towards the front, so it forms a right angle. Vertically place these 2 overhanging rows of the front left hinge plate on the 3<sup>rd</sup> and 4<sup>th</sup> rows from the front on the rightmost column of antistuds, so they sit on the vertical front right red 1x8 plate.

88. Push your attached part forward as far as you can. Turn your sub build right side up, so the part you have just attached is horizontally on the back. You have formed the number 7. Vertically place the 3 back rows of a black 1x5 plate underneath the 6<sup>th</sup> column from the right of your build, so 2 rows extend to the front avoiding the hinge part to fold.

89. Vertically place a black 1x2 plate underneath the 2<sup>nd</sup> column from the left of the 2 back rows of your seven build (here, we are counting only the columns withing the 2 mentioned rows). Place the 2 back rows of 2 black 4x4 plates, one to the right of the other, to the right of the ppp, so 2 rows are exposed to the front.

90. Horizontally place a gold 2x4 right wedge plate on the 4<sup>th</sup> and 5<sup>th</sup> rows from the back on the 4 right columns, so the right angle is on the front right, and the studs are at the back. and it sits on a vertical 2x3 plate. Vertically place the 2 back rows of a gold 2x4 left wedge plate on the 4<sup>th</sup> and 5<sup>th</sup> rows from the back on the 5<sup>th</sup> and 6<sup>th</sup> columns from the right, so the long straight side with studs faces the left and the cut corner faces the right.

Group 22:

91. Horizontally place a red 1x2 plate to the left of the back row of the ppp. Horizontally place a red 1x8 plate on the left of the ppp. Horizontally place another behind the ppp.

92. Horizontally place the right column of a black 2x3 plate underneath the back left corner of the seven build. Vertically place the right column of a red 2x2 right wedge plate on the leftmost column of the ppp, so the right angle faces the back right and 1 column extends to the left. Vertically place a red 1x2 plate to the right of the ppp.

93. Horizontally place the 2 right columns of a black 2x3 plate under the 2 left columns of the 3<sup>rd</sup> and 4<sup>th</sup> rows from the back (here, we are only counting the columns within the 2 mentioned rows). Place the right column of a red 2x2 right wedge plate on the leftmost column of the ppp, so the right angle faces the back right and the cut corner faces the front left.

Group 23:

94. Vertically place a gold 2x4 right wedge plate on the 4 back rows on the 2 left columns, so the cut corner faces the front left and the long straight side with studs faces the back. Place 6 gold 2x2 tiles with studs on edge, 1 to the right of the other, to the right of the 2 front rows of the ppp, so the studs face the back. Repeat the 6 placements symmetrically to the back, so the studs face the front. Place 2 more, one to the right of the other, on the 2 back rows of your 7 build to the right of the ppps, so the studs face the front. You should have placed 14 gold 2x2 tiles with studs on edge in total. Then, vertically place a gold 1x2 plate to the right of the ppps on the back right corner of your seven build.

95. Vertically place a gold 1x2 left wedge tile on the 5<sup>th</sup> and 6<sup>th</sup> rows from the back on the 6<sup>th</sup> column from the right, so the cut corner faces the front right. Vertically place a gold 1x2 right wedge tile on the 3<sup>rd</sup> and 4<sup>th</sup> rows from the back on the rightmost column, so the cut corner faces the front left. Place a gold 1x1 round tile with open stud to the left of the front row of the ppp. Place another behind the ppp.

96. Horizontally place the 2 right columns of a dark tan 1x4 hinge plate to the left of the ppp, so the rounded hinge part faces the front. push the 2 left columns forward so it forms a 43 ° with the right column and attaches to a horizontal gold 2x4 right hinge plate.

97. Place a gold 1x1 round plate with open stud between the right column of the front row and the right column of the back row of the semi folded 1x4 hinge plate.

98. Orient the long stem of the Number seven so it sits vertically in front of you. Horizontally place a gold 1x2 plate on the 2 left columns of the 2<sup>nd</sup> row from the front (here, we are counting only the columns of this mentioned column). Place 10 bold 2x2 tiles with studs on edge one in front of the other behind the ppp, so the studs face the right. Repeat the 10 placements symmetrically to the right.

99. Place a dark green 2x2 right wedge plate on the 2<sup>nd</sup> and 3<sup>rd</sup> rows from the back on the 2<sup>nd</sup> and 3<sup>rd</sup> columns from the left of visible studs, so the long straight side faces the back and the cut corner the front left. Vertically place a dark green 2x4 tile to the right of the ppp. Place a dark green 2x2 tile with 1 stud to the right of the ppp. Next, horizontally place a dark green 2x4 tile to the right of the ppp. Then, horizontally place another to the right of the ppp. Now, place a gold 1x1 round plate with open stud on the stud of the 2x2 tile with 1 stud.

100. Vertically place a dark green 2x4 tile on the 3<sup>rd</sup> through 6<sup>th</sup> rows from the front, so it is centered horizontally on the long stem. Vertically place 4 more, 1 behind the other, behind the ppp. Place a dark green 2x2 right wedge tile behind the ppp, so the short straight side faces the left and the studs face the front.

Group 24:

101.1 Horizontally place the back row of a red 2x4 right wedge plate on top of your seven build on the 4 left columns of the front row, so the cut corner faces the front right and the studs face the back.

Group 25:

101.2 Horizontally place a gold 2x4 right wedge plate on top of the ppp, so the edges align.

Group 26:

102. Horizontally place the back row of a black 2x4 right wedge plate underneath the front row of your seven build, so the cut corner faces the front right. Place a black 4x4 plate behind the ppp.

103. Let's make a part! Place a dark grey 4x6 plate in front of you. Vertically place a black 1x2 brick with 2 side studs on the back right corner so the side studs face the right. Horizontally place 2 grey 1x2 bricks with axle hole 1 to the left to the other to the left of the back row of the ppp, so the axle holes face the front and the back. Vertically place the back row of a black 1x2 brick with 2 side studs to the left of the ppp, so the side studs face the left. Place the left column of a black 3x3 right corner plate in front of the ppp, so the right angle faces the back left, and 1 row overhangs to the front. Horizontally place a grey 1x2 brick with axle hole behind the 2 right columns of the ppp, with the axle hole facing the front and the back. Horizontally place another to the right of the ppp. Place a White 2x2 corner plate in front of the ppp, so it looks like a braille letter D. Vertically place a black 1x2 brick with 2 side studs to the right of the ppp, so the side studs face the right. rotate it 180 degrees, so the studs face the left. Bring back your seven build, so the long stem is vertically in front of you. Fold the 2 right overhanging columns of the black 1x4 hinge plate towards the front left. Once it is folded completely place the front overhanging row on the back row of your part on the 2<sup>nd</sup> and 3<sup>rd</sup> columns from the left.

104. Vertically place the right column of a black 2x4 left wedge plate underneath the back right overhang of your attached part, so 1 row extends to the back. Place a gold 1x1 round plate with open stud on the back row of the ppp.

105. Vertically place the front right corner of a black 2x4 left wedge plate on the ppp. So, the cut corner is on the back left and the studs face the right. Vertically place a black 1x2 plate in front of the right column of the ppp. Horizontally place a tan 2x4 plate to the left of the ppp.

106. Place a white 2x2 corner plate on top of the ppp on the 2 left columns, so it looks like a braille letter H. Place the front row of a black 3x3 corner plate to the right of the ppp, so it looks like a large braille letter J. Place a gold 1x1 round plate with open stud behind the right column of the ppp.

107 Place a dark tan semi folded 1x4 hinge plate on the 4<sup>th</sup> and 6<sup>th</sup> rows from the front row, so it is centered horizontally and the back row is placed on the 2<sup>nd</sup> and 3<sup>rd</sup> columns from the right, the rounded hinge part faces the right, the front row sits on a tan 2x4 plate from step 105 and the left column of the back row sits in front of a dark green vertical 2x4 tile.

108. Place a dark green 2x2 right wedge plate on the 5<sup>th</sup> and 6<sup>th</sup> rows from the front on the 2<sup>nd</sup> and 3<sup>rd</sup> columns from the left, so the cut corner faces the front right and the studs face the back, and it sits in front of the vertical 2x4 tile.

109. Vertically place 2 black 3x4 tiles with a column of 3 studs one to the right of the other on the 3 front rows. Vertically place a black 2x4 left wedge plate behind the 2 right columns of the right ppp, so the studs face the right and the cut corner faces the back left.

110. Rotate your sub build 90 degrees counterclockwise so the side studs face the front and the back. Place a black 1x1 brick upright on the rightmost column of front facing side studs. Horizontally place a black 1x3 slope brick upright to the left of the ppp, so it slopes to the left.

111. Horizontally place a black 1x2x2/3 slope tile upright on the 2 columns of front facing side studs, so it slopes to the left. Repeat symmetrically to the back.

Great job! In this bag you've started building the big number seven as its own separate build. It's a large, detailed shape with lots of pieces, and you've already created a strong part of its structure. This number seven is the famous number Cristiano Ronaldo wears, and you'll finish it

and attach it to the main model in the next bag. When you're ready, open Bag 4 and keep the build moving forward!

Building Instructions (Bag 4, Book 1):

Group 27:

112. Turn your seven build upside down, so the short top bar of the seven diagonally points to the front on the right. the long stem should be horizontally in front of you on the back. Place a black 2x2 inverted tile on the 2 back rows of the 10<sup>th</sup> and 11<sup>th</sup> columns from the left of antistuds (here, we are counting only the rows within the 2 mentioned columns), so it sits to the right of a black 4x4 plate from step 102.

113. Vertically place the 1x2 plate of a transparent clear 12L bar with 1x2 plate and 1x1 round plate on one end to the right of the ppp, so 8L of the bar extend to the front. Place the left column of a black 2x2 curved inverted slope tile on the 2 back rows of the ppp, so it slopes to the right.

114. Horizontally place a black 2x3 plate to the right of the ppp.

115. Vertically place the 1x2 plate of a transparent clear 12L bar with 1x2 plate and 1x1 round plate on one end to the right of the ppp, so 8L of the bar extend to the front. Place the left column of a black 2x2 curved inverted slope tile on the 2 back rows of the ppp, so it slopes to the right.

Group 28:

116. Let's make a sub build! Vertically place a black 1x3 plate in front of you.

117. Horizontally place a red 2x3 plate on top of the 2 back rows of the ppp, so it is centered horizontally.

118. Place a black 3x3 quarter round plate to the right of the vertical 1x3 plate, so the right angle faces the front left, and the rounded edge faces the back right, and only the back left corner attaches underneath the right overhang. Repeat symmetrically to the left.

119. Place a red 2x2 plate with cut corner on the 2 back rows of the ppp on the 2 left columns, so the right angle faces the front right. Repeat symmetrically to the right.

120. Horizontally place a dark green 1x2 tile on the front row of your sub build on the 2<sup>nd</sup> and 3<sup>rd</sup> columns from the left. Repeat symmetrically to the right.

121. Vertically place the back row of a red 1x2 plate to the right of the ppp, so 1 row overhangs to the front. Horizontally place the rightmost column of a black 1x2 plate underneath the front right overhang.

122. Vertically place the back row of a red 1x2 plate on the front left corner of your sub build, so 1 row overhangs to the front.

123. Vertically place the back left corner of a black 4x8 plate underneath the front overhanging row of the ppp.

124. Place the front row of a red 2x2 plate on the back row of the ppp on the 2<sup>nd</sup> and 3<sup>rd</sup> from the left, so the back row sits in front of the left horizontal dark green 1x2 tile. Skip 1 column to the right and place another, so 1 row overhangs to the front. Vertically place a dark green 1x4 tile on the 3<sup>rd</sup> through 6<sup>th</sup> rows from the back so it is centered horizontally and it sits between the 2 ppps.

125. Place the back left corner of a black 3x3 plate underneath the front right overhang, so it attaches under the front row of the front right red 2x2 plate.

126. Vertically place a dark green 1x2 tile on top of the ppp on its back right corner. Horizontally place another to the left of the front row of the ppp. Repeat both placements symmetrically to the left.

Group 29:

127.1 Vertically place the back row of a red 1x3 plate on the 5th row from the front on the rightmost column, so 2 rows overhang to the front.

Group 30:

127.2 Horizontally place a black 1x3 plate in front of the 3x3 plate from step 125, so the right column attaches under the front right overhang, and the vertical red 1x3 plate now overhangs 1 row to the front.

128. Horizontally place a red 2x3 plate on the 4<sup>th</sup> and 5<sup>th</sup> rows from the front on the 3 left columns. Place another horizontally to the right of the ppp.

129. Orient a black 3x3 quarter round plate, so the right angle faces the back left and the rounded edge faces the front right. Place its back right corner underneath the front overhang.

130.1 Horizontally place a dark green 1x2 tile on the 3<sup>rd</sup> row from the front on the 2<sup>nd</sup> and 3<sup>rd</sup> columns from the left. Skip 1 column to the right and horizontally place another. Place a red 1x1 plate to the left of the ppp.

Group 31:

130.2 Place a dark green 1x1 plate on the same row on the leftmost column.

131. Vertically place a red 1x2 plate in front of the ppp. Place a red 2x2 plate with cut corner to the right of the ppp, so the right angle faces the back left. Place another to the right of the ppp, so the right angle faces the back right. Then, place another to the right of the ppp, so the right angle faces the back left.

132. Place a gold 2x2 corner tile with cutout on the back left corner of your sub build, so the cutout faces the back left. Place a gold 2x2 corner plate to the right and in front of the ppp, so it looks like a braille letter J. Repeat both parts symmetrically to the right. Vertically place a gold 1x2 tile on top of your sub build on the 2 back rows so it is centered horizontally.

133. Place a gold 1x1 plate on the 3<sup>rd</sup> row on the leftmost column. Place the left column of a gold 2x2 corner tile with cutout in front of the ppp, so the cutout faces the front left. Place a gold 2x2 corner plate to the right and behind the ppp, so it looks like a braille letter D. Repeat the 3 parts symmetrically to the right.

134. Place a gold 1x2 tile horizontally on the 4<sup>th</sup> row from the front on the 2 left columns. Place another horizontally behind the ppp. Vertically place another to the right of the 2 ppps. Place another horizontally to the right of the back row of the ppp. Place a gold 2x2 corner plate in front of the ppp, so it looks like a braille letter F. Place another to the right of the ppp, so it looks like a braille letter D. Horizontally place a gold 1x2 tile behind the ppp.

135. Place a gold 2x2 corner plate on the front left corner of your sub build, so it looks like a braille letter F. Place a gold 2x2 corner tile with cutout in front and to the right of the ppp, so the cutout faces the front right. place another to the right of the ppp so the cutout faces the front left. Place another to the right of the ppp, so the cutout faces the front right. Horizontally place a gold 1x2 tile to the left of the right column of the ppp.

Group 32:

136. Rotate your part 90 degrees counterclockwise, so the sub build its horizontally in front of you. Turn it upside down so the non-rounded corner faces the front left. Vertically place a black 2x6 plate on top of your sub build on the 6 back rows on the 3<sup>rd</sup> and 4<sup>th</sup> columns from the left of antistuds. Repeat symmetrically to the right.

137. Place a black 2x2 plate with bottom pin connector on the 2 back row of the ppp, so the pin holes of the pin connector face the front and the back. Insert a red 1L pin with stud from front to back into the front facing pin hole of the ppp, Repeat both parts symmetrically to the left.

138. Bring back your seven build, so the long stem is horizontally on the back, and the sort top bar is on the right pointing to the front. Rotate your sub build 180 degrees. Insert the 2 front facing bars of your seven build from back to front into the back facing pin holes of your sub build.

139. Locate the 2 left facing axle holes on the back horizontal long stem. Insert a red 4L axle from left to right into each back facing pin hole of your sub build, so 2L of each axle extends to the left.

140. Rotate your seven build 90 degrees' counterclockwise, so the 2 protruding axles face the front. Turn it right side up, so the long stem is facing diagonally to the front and the top short bar is on the back. Bring back your main build and place it horizontally in front of you, so the Ronaldo's signature plaque faces the front. locate 2 axle holes in front of 2 rows with 4 columns of studs on the back right of your main build. Hold your part upright, so the axles point to the bottom and horizontally insert the 2 bottom protruding axles to the axle holes you have found, press down to secure.

Fantastic progress! In this bag you've completed the big number seven and added the special plaque with the capital letters C and R — Cristiano Ronaldo's initials. Then you attached the whole number-and-plaque build onto the field, giving the model its first bold, iconic feature. When you're ready, open Bag 5 and keep building — the scene for your star is ready to grow.

Building Instructions (Bag 5, Book 1):

Group 33:

141. Let's make a sub build. Horizontally place a black 2x4 plate in front of you. Place a white 1x1 brick with clip on 1 side on top of the ppp on the back right corner, so the clip faces the right.

142. Place another white 1x1 brick with clip on 1 side in front of the ppp, so the clip faces the right.

143. Place the back row of a white 2x2 corner brick to the left of the ppp, so it Looks like a braille letter J and 1 row overhangs to the front. Repeat symmetrically to the back.

144. Place the right column of a black 2x2 prick with pin hole and a half join ball in front of the left column of the ppp, so the half join ball faces to the left close to the back left corner with its pin holes facing the front and the back. Insert the back facing pin of a black rotation joint ball loop with 2 perpendicular pins from front to back into the front facing hole of the half joint ball of the ppp, so the other pinpoints to the left.

145. Horizontally place a black 2x4 plate on top of your sub build, so there's no overhang.

146. Horizontally place the left column of a dark red 1x2 plate with 1x2 upright facing side studs underneath the front right overhang, so the side studs face the front. Repeat symmetrically to the left.

147. Horizontally place the right column of a red 1x2 brick on the left column of the ppp, so 1 column overhangs to the left. Place a blue 1x1 brick on the front right corner of your sub build, so it sits on the front right 1x2 plate with 1x2 upright facing side studs.

148. Place a grey 1x1 plate with 1x1 side stud hanging down on top of the ppp, so the side stud faces the front. Place a tan 1x1 round plate to the left of the ppp. Horizontally place a green 1x2 plate with 2x4 side studs hanging down to the left of the ppp, so the side studs face the front.

149. Horizontally place the right column of a dark red 1x2 plate with 1x2 upright facing side studs underneath the left overhang of the front row, so the side studs face the front and 1 column extends to the left. Place a tan 1x1 round plate on the left column of the ppp.

150. Horizontally place the left column of a dark red 1x2 plate with 1x2 upright facing side studs underneath the back right overhang, so the side studs face the back. Repeat symmetrically to the left.

151. Horizontally place the right column of a red 1x2 brick on the left column of the ppp, so 1 column overhangs to the left. Place a blue 1x1 brick on the back right corner of your sub build, so it sits on the back right 1x2 plate with 1x2 upright facing side studs.

152. Horizontally place the right column of a dark red 1x2 plate with 1x2 upright facing side studs underneath the left overhang of the front row, so the side studs face the back, and 1 column extends to the left. Place a tan 1x1 round plate on the left column of the ppp.

153. Place a grey 1x1 plate with 1x1 side stud hanging down on the back right corner of your sub build, so the side stud faces the back. Place a tan 1x1 round plate to the left of the ppp. Horizontally place a green 1x2 plate with 2x4 side studs hanging down to the left of the ppp, so the side studs face the back.

154. Horizontally Place a red 1x2 slope tile with cutout to the left of the ppp, so it slopes to the left. Repeat symmetrically to the front.

155. Place a dark red 2x2 plate upright on the 2 right columns of back facing side studs So it looks like a braille letter J. place a red 1x2plate vertically upright on the right column of the ppp. Horizontally place the 2 right columns of a red 2x4 curved left slope wedge tile upright on the 2 ppps so it slopes to the left.

156. Place a red 2x2 triangle upright on top of the 2 left columns of the ppp. Vertically place a red 1x2 tile upright to the left of the ppps. Place a 1x2 right wedge tile upright to the left of the ppp, so the cut corner is on the top left.

157. Place a dark red 2x2 plate upright on the 2 right columns of front facing side studs So it looks like a braille letter J. place a red 1x2plate vertically upright on the right column of the ppp. Horizontally place the 2 right columns of a red 2x4 curved right slope wedge tile upright on the 2 ppps so it slopes to the left.

158. Place a red 2x2 triangle upright on top of the 2 left columns of the ppp. Vertically place a red 1x2 tile upright to the left of the ppps. Place a 1x2 left wedge tile upright to the left of the ppp, so the cut corner is on the top left.

159. Place the front row of a dark red 2x2 plate with cut corner on the 2 right columns of the back row of visible studs, so the right angle faces the front right. Repeat symmetrically to the front.

160. Vertically place a red 1x2 plate on top of your sub build on the left column of visible studs, so it is centered vertically.

Group 34:

161. Horizontally place a black 2x4 plate to the right of the ppp, so 1 column overhangs to the right. Horizontally place a green 2x3 plate on top of the ppp on the 3 left columns. Horizontally place a green 1x2 curved left slope wedge tile to the right of the front row of the ppp, so it slopes to the right and 1 column overhangs to the right. Place a green 1x2 curved right slope wedge tile behind the ppp, so it slopes to the right and 1 column overhangs to the right.

162. Place a tan 1x1 round plate on the 2<sup>nd</sup> row from the back on the rightmost column of visible studs, so it sits behind the rightmost column of the horizontal 2x3 plate. Repeat symmetrically to the front.

163.1 Place the back right corner of a red 2x2x2/3 curved left slope wedge tile on the ppp, so it slopes to the left.

Group 35:

163.2. Place a red 2x2x2/3 curved right slope wedge tile with gold number 7 pattern symmetrically to the back.

164. Vertically place a red 1x2 tile in front of the left column of the ppp. Horizontally place the left column of a red 1x2 left wedge tile to the right of the front row of the ppp, so the cut corner faces the back right. Repeat symmetrically to the back using a red 1x2 right wedge tile.

165. Vertically place the 2 right columns of a red 3x4 stepped wedge tile on top of your sub build on the 2 left columns of visible studs, so it steps down to the left and it is centered vertically.

Group 36:

166. Let's make a sub build. Place a red 2x2 plate with 1x2 side studs in front of you, so the side studs face the right. Vertically place the 2 back rows of a red 1x6 plate on the left column of the ppp, so 4 rows overhang to the front.

167. Place the left column of a red 2x2 plate with 1x2 side studs underneath the 2 front rows of your sub build, so the side studs face the right.

168. Rotate your sub build 90 degrees clockwise. Horizontally place a black 1x2 rounded brick with open studs and open center with bars. On top of your sub build on the back row, so it is centered horizontally.

169. Place the back row of a red 2x2 brick with ball socket and axle hole to the right of the ppp, so the socket faces the right.

170. Vertically place 2 dark red 1x2 bricks with axle hole one to the right of the other on top of your sub build on the 2 left columns, so the axle holes face the left and the right.

171. Place a red 2x2 plate with 1x2 side studs on top of the 2 ppps, so the side studs face the front. Repeat symmetrically to the right.

172. Vertically place a medium nougat 1x2 plate with bar handle on a sort side on the back row on the 3<sup>rd</sup> column from the left, so the bar handle faces the front and 1 row overhangs to the front. Repeat symmetrically to the right. Horizontally place a red 1x2 plate on top of the ppps on their front row. Horizontally place a red 1x6 plate on the back row of your sub build, so there's no overhang.

173. Place a green 2x2 corner plate on top of your sub build on the 2<sup>nd</sup> and 3<sup>rd</sup> columns from the left, so it looks like a braille letter F. Repeat symmetrically to the right, so it resembles a braille letter D.

174. Place the back row of a green 2x2 tile with studs on edge on the front row of your sub build, so the studs face the back, it is centered horizontally and 1 row overhangs to the front above the bar handles.

Group 37:

175.1 Horizontally place a red 2x4 plate in front of you. Place 2 red 1x2 plates with rail one to the right of the other on the back row of the ppp, so the rails face the back. Vertically place the front row of 2 red 2x3 tiles 1 to the right of the other on the front row of your part, so 2 rows overhang to the front.

175.2 Horizontally place the 2 back rows of a dark red 4x6 plate with 2 cut corners underneath the front overhang, so the cut corners are on the back right and back left, and 2 rows are exposed to the front.

175.3 Horizontally place the 2 back rows of a red 4x6 curved slope tile with 2 cut corners and studs on edge printed with a gold number 7 pattern on the 2 front rows of the ppp, so the studs face the front and the cut corners face the back right and back left.

175.4 Horizontally place a green 1x2 right wedge tile on the 2 left columns of the front row of the ppp, so the cut corner faces the back left. Place a green 1x2 left wedge tile symmetrically to the right.

175.5 Bring back your sub build and position it horizontally in front of you, so the bar handles face the front. Vertically place the 2 front rows of your part on top of the 2 back rows of your sub build so 6 rows overhang to the back.

176. Turn your sub build upside down so the bar handles face the front Horizontally place a red 1x2 plate on the 2<sup>nd</sup> row from the front on the 2 left columns of antistuds. Place the back row of a red 2x2 inverted curved slope tile on the ppp, so it slopes to the front. Repeat both parts symmetrically to the right.

Group 38:

177. Let's make a part! Vertically place a red 1x2 plate in front of you. Place a red 2x2 plate with cut corner to the left of the ppp, so the right angle faces the back right. place the front row of a red 2x2 curved slope tile on the back row of the 2 ppps, so 1 column of the 2x2 plate with cut corner remains exposed, and it slopes to the back. Vertically place a red 1x2 curved left slope wedge tile to the left of the ppp, so it slopes to the back. Place the back row of a red 1x2 curved right slope wedge tile on the front row of your part, so it slopes to the front and 1 row extends to the front. Vertically place a red 1x2 curved slope tile to the right of the ppp, so it slopes to the front. Bring back your sub build and turn it right side up, so the bar handles face the front. Rotate your part 180 degrees, then vertically place it on the front right facing side studs, so there is no overhang.

178. Let's make a part! Vertically place a red 1x2 plate in front of you. Place a red 2x2 plate with cut corner to the right of the ppp, so the right angle faces the back left. place the front row of a red 2x2 curved slope tile on the back row of the 2 ppps, so 1 column of the 2x2 plate with cut corner remains exposed, and it slopes to the back. Vertically place a red 1x2 curved right slope wedge tile to the right of the ppp, so it slopes to the back. Place the back row of a red 1x2 curved left slope wedge tile on the right column of the front row of your part (here we are counting only the columns within this mentioned row), so it slopes to the front and 1 row extends to the front. Vertically place a red 1x2 curved slope tile to the left of the ppp, so it slopes to the front. Bring back your sub build and position it vertically, so the bar handles face the front. Rotate your part 180 degrees, then vertically place it on the front left facing side studs, so there is no overhang.

179 Turn your sub build upside down, so the bar handles face the front. Bring back your previous sub build and position it vertically in front of you, so the pin faces the back, and the clips face the front. Place it on the 6 back rows of your upside down build, then, push it forward, so the front facing clips clip to the bars of the horizontal 1x2 rounded brick with open studs and open center with bars.

Great work! In this bag you've built Cristiano's torso, complete with the red Portugal team shirt and the big number 7 proudly printed on the back. His arms will come later, but the heart of his figure is already standing strong. When you're ready, open Bag 6 and keep building — your star is starting to come to life.

#### Building Instructions (Bag 6, Book 1):

##### Group 39:

180. Let's start building an arm shoulder! Place a red 2x2 plate with cut corner in front of you, so the right angle faces the front right. Place the left column of a red 1x2 brick with pin hole and 1x2 plate on the right column of the ppp, so the pin hole faces the right.

181. Vertically place a red 1x2 plate on the right column of the ppp.

182.1 Let's make the arm! Horizontally place a red 1x2 plate in front of you. Place the front right corner of a red 2x2 plate with cut corner on the left column of the ppp, so the right angle faces the back right. Horizontally place a red 2x4 left wedge plate to the right of the ppp, so the right angle is on the front left. Horizontally place a red 1x2 plate on the two leftmost visible studs on the front row. Horizontally place the right column of a red 1x2 curved left slope wedge tile on the left column of the ppp, so it slopes to the left and the cutoff corner is on the front left. Horizontally place a 1x3 curved slope tile to the right of the ppp, so it slopes to the right.

182.2 Horizontally place the right column of a red 1x2 plate on the leftmost column of the ppp. Horizontally place a red 1x2 curved left slope wedge tile on the left column of the ppp, so it slopes to the left. Horizontally place a red 1x2 curved slope tile to the right of the ppp, so it slopes to the right.

182.3 Bring back your arm shoulder build so the pin hole faces the back. Place the 2 front rows of your sub build underneath the 2 left columns of your part.

183 Place a red 2x2 curved slope tile on top of your part on the back left corner so it slopes to the front.

184. Turn your arm build upside down so the part you have just attached is on the front left corner and faces down. Place a red 1x1 plate on the back row on the 2<sup>nd</sup> column from the right of antistuds. Horizontally place a red 1x2 curved inverted slope tile to the left of the ppp.

185. Place a red 2x2 inverted tile on the 2 front rows on the 2 left columns of antistuds of your sub build.

186. Turn your arm build right side up, so the long straight side is on the back. and the pin hole faces the front. Horizontally place the right column of a nougat 1x2 rounded plate underneath the leftmost column of the back row (here, we are counting only the columns within this mentioned row), so 1 column extends to the left. Vertically place the back row of a nougat 1x2 plate with bar handle on 1 large side on the left column of the ppp, so the bar handle faces the left and 1 column overhangs to the front.

187. Place the left column of a nougat 2x2 plate with cut corner on the ppp, so the right angle faces the back left.

188. Place a nougat 1x1 round plate with horizontal bar underneath the front left overhang, so the bar points to the front.

189. Clip 3 nougat bar holders with clip on the bar handle. They are the fingers.

Group 40:

190.1 Let's make the shoulder! Place a red 2x2 inverted tile in front of you. Horizontally place a red 1x2 brick with pin hole on the back row of the ppp, so the pin hole faces the front and the back. Place a red 1x2 brick with pin hole and dual liftarm extensions in front of the ppp, so the pin holes face the front and the back and the extensions overhang to the front.

190.2 Insert a blue 3l pin from back to front into the back facing pin hole of your part, so 1L of the pin extends to the back. Place a red 2x2 corner plate on top of your part in the 2 back rows and it resembles a braille letter F.

190.3 Horizontally place a red 1x2 tile on the back row of your part, so there's no overhang. Place a red 2x2x2/3 curved left slope wedge tile in front of the ppp, so it slopes to the front. Insert a red 2L axle from right to left into the right facing axle hole of the right extension, so 1L of the axle extends to the right. align the right and left axle holes of the axle connector of a red 2L axle with axle connector on 1 end with the inner facing axle holes of both extensions, so the 2L axle extends 2L downward. Push the right facing 1L red axle to the left, so it inserts into the axle connector of the ppp an into the axle hole of the left extension. The 2L axle with axle connector on 1 end should be secured. Bring back your arm build so it is horizontally in front of you and the pin hole faces the front right. Insert the back protruding 1L pin of your part from front to back into the front facing pin hole.

191. Bring back your torso build and place it vertically in front of you so the 1L pin faces the front. rotate your arm build 180 degrees counterclockwise, then flip it so it sits on its left side, and the 2L axle extends to the right on the back. Locate the left facing axle hole of your torso sub build close to the back left corner. Insert the right protruding axle of your arm build from left to right on the left facing axle hole of your torso build you have found. Press firmly to secure.

Group 41:

192. Let's build the 2<sup>nd</sup> arm shoulder! Place a red 1x2 brick with pin hole and dual lift arm extensions in front of you, so the pin hole faces the right and the left and the axle holes of the dual liftarm extensions face the front and the back.

193. Align the axle holes of a black ball joint with through axle hole with the inner facing axle holes of the dual liftarm extensions. Insert a red 2L axle from front to back into the front facing axle hole of the front liftarm extensions. Push it towards the back, so it is fully inserted.

194. Place the right column of a red 2x2 inverted tile underneath the left column of the ppp, so 1 column extends to the left.

195. Vertically place a red 1x2 brick with pin hole on the left column of the ppp, so the pin hole faces the right and the left.

196. Place a blue 1x1 plate with 1x2 side studs hanging down on the front row of the ppp, so the side studs face the front. Repeat symmetrically to the back. Place a red 1x1 plate to the right of the back row of the ppp.

197. Place the back left corner of a red 2x2x2/3 curved right slope wedge tile on the ppp, so it slopes to the right. Vertically place a dark blue 1x2 tile printed with the letter C in white.

198. Vertically place a dark blue 1x2 tile upright on the front facing side studs. Repeat symmetrically to the back.

199. Insert a blue 3L pin from left to right into the left facing pin hole, so 1L of the pin extends to the left.

200. Let's make a sub build. Place a red 2x2 plate with cut corner in front of you, so the right angle faces the back right. Place the left column of a red 1x2 brick with pin hole and 1x2 plate on the right column of the ppp, so the pin hole faces the right.

201. Vertically place a red 1x2 plate on the right column of the ppp.

202.1 Let's make a part! Horizontally place a red 1x2 plate in front of you. Place the front left corner of a red 2x2 plate with cut corner underneath the left column of the ppp, so the right angle faces the back left. Horizontally place a red 2x4 left wedge plate to the left of the ppp, so the studs face the front and the cut corner faces the back left.

202.2 Horizontally place the left column of a red 1x2 plate on the rightmost column of the ppp. Horizontally place a red 1x2 curved right slope wedge tile on the right column of the ppp, so it slopes to the right. Horizontally place a red 1x3 curved slope tile to the left of the ppp, so it slopes to the left.

202.3 Bring back your arm shoulder build so the pin hole faces the back. Place the 2 front rows of your sub build underneath the 2 right columns of your part.

203 Place a red 2x2 curved slope tile on top of your part on the back right corner so it slopes to the front.

204. Turn your second arm build upside down so the pin hole faces the front right. Place a red 1x1 plate on the back row on the 2<sup>nd</sup> column from the left of antistuds. Horizontally place a red 1x2 curved inverted slope tile to the right of the ppp.

205. Place a red 2x2 inverted tile on the 2 front rows on the 2 right columns of antistuds of your sub build.

206. Turn your arm build right side up, so the long straight side is on the back. and the pin hole faces the front. Horizontally place the left column of a nougat 1x2 rounded plate underneath the rightmost column of the back row (here, we are counting only the columns within this mentioned row), so 1 column extends to the right. Vertically place the back row of a nougat 1x2 plate with bar handle on 1 large side on the right column of the ppp, so the bar handle faces the right and 1 row overhangs to the front.

207. Place the right column of a nougat 2x2 plate with cut corner on the ppp, so the right angle faces the back right.

208. Place a nougat 1x1 round plate with horizontal bar underneath the front left overhang, so the bar points to the front.

209. Clip 3 nougat bar holders with clip on the bar handle. They are the fingers.

Group 42:

210. Bring back your arm shoulder build and position it horizontally in front of you, so the ball joint faces the left. And the 1L protruding pin faces the right. Rotate your arm build 90 degrees clockwise, so the fingers face the front and the pin hole faces the left back. Insert the 1L pin of your arm shoulder build from left to right into the left facing pin hole of your arm build.

211. Rotate your arm build 90 degrees clockwise so the joint ball faces the back. Bring back your torso build and position it horizontally in front of you, so the socket faces the front right. Attach the joint ball to the front right facing socket.

“Well done! In this bag you’ve built Cristiano’s arms and hands. Both arms can move, and each hand has fingers you can pose and adjust, giving the figure a lively, expressive feel. With the arms complete, your star is almost ready to take the field. When you’re ready, open Bag 7 and keep building — you’re bringing Cristiano to life piece by piece!

Building Instructions (Bag 7, Book 1):

Group 43:

212. Let’s make a sub build. Let’s start building a leg. Horizontally place a green 2x3 plate in front of you. Horizontally Place a green 1x2 plate with 2x2 upright side studs on the back left corner, so the side studs face the back.

213. Place a green 1x1 round plate in front of the left column of the ppp.

214. Place the 1x2 plate of a black 1x2 brick with pin hole and 1x2 plate to the right of the ppp, so the pin hole faces the front. Place the left column of a green 1x2 plate with curved inverted slope tile behind the ppp, so it slopes upward to the back and its front right corner overhangs to the front.

215. Horizontally place a green 2x3 plate on top of your leg build on the 3 left columns.

216. Horizontally place the left column of a green 1x2 plate with rail underneath the right overhang, so the rail faces the front and 1 column extends to the right.

217. Place the left column of a green 2x2 curved round inverted slope brick on the right column of the ppp, so it slopes upward to the back, and tits front right corner overhangs to the front.

218. Vertically place a green 1x2 plate upright on the right column of back facing side studs. Place a green 2x2 curved slope tile on the back facing side studs, so it slopes to the left.

219. Horizontally place a green 1x4 brick on the back row on the 4 right columns.

220. Horizontally place a dark tan 1x4 plate in front of the 3 right columns of the ppp, so 1 column overhangs to the right. Place a green 1x1 round plate under the right overhang.

221. Horizontally place a green 1x4 brick on the 2<sup>nd</sup> row from the back on the 4 left columns. Place a green 1x1 round plate on top of the ppp, on the leftmost column.

Group 44:

222. Horizontally place a black 1x2 brick with 2 side studs on 1 large side to the right of the 1x4 brick , so the side studs face the front. Place a nougat 1x1 brick with 1 side stud on 2 sides to the right of the ppp, so the side studs face the front and the back.

223. Horizontally place a green 2x3 plate on top of your leg build on the 2 front row son the 3 left columns so its front left corner overhangs. Vertically place a dark green 1x2x1 1/3 brick with rotation joint socket on the leftmost column of the ppp. So, the sighed with relief faces the left. Vertically place 2 green 1x2 plates 1 to the right of the other to the right of the ppp.

224. Horizontally place a green 1x2 brick with pin hole on top of the front row of the 2 ppps, so the pin hole faces the front and the back. Place a black 1x2 brick with pin hole and 1x2 plate behind the ppp, so the pin hole faces the front.

225. Vertically place a green 1x2 left wedge plate to the right of the ppp, so the cut corner faces the front right and 1 row overhangs to the front. Horizontally place a green 1x2 plate with rail to the right of the back row of the ppp, so the rail faces the front.

226.1 Rotate your leg build 180 degrees. Vertically place a green 1x2 curved left slope wedge tile on the top of your leg build on the front right corner., so it slopes to the front. Vertically place a green 1x2 curved slope tile to the left of the ppp. Place a green 2x2 curved slope tile to the left of the ppps, so its lopes to the front.

Group 45:

226.2 Place a green 2x2 curved slope tile printed with the number seven in gold to the left of the ppp, so it slopes to the front.

227. Horizontally place a green 2x3 tile on top of your leg build on the back right corner.

Group 46:

228. Let's make a part! Horizontally place a red 1x8 plate horizontally in front of you. Horizontally place a red 1x2 plate with socket on top of the ppp on the 2 right columns, so the socket faces the right.

229. Horizontally place a red 1x2 plate to the left of the ppp.

230. Place a white 1x1x2/3 short brick to the left of the ppp. Horizontally place a red 1x4 plate to the right of the ppp.

231. Horizontally place a red 1x3 tile on the 3 right columns of the ppp. Horizontally place a red 1x2 plate to the left of the ppp.

232. Horizontally place a red 1x2 brick with 2 side studs on each large side to the left of the ppp, so the side studs face the front and the back. Place a nougat 1x1 brick with a side stud on 2 sides to the left of the ppp, so the side stud faces the front and the back.

233. Let's make a part! Place a green 2x2 plate in front of you. Vertically place the 2 front rows of a green 2x3 tile on the ppp, so 1 row overhangs to the back. Place the left column of a medium nougat 2x2 round corner plate with 1x1 cutout underneath the back right corner, so it looks like a braille letter I and 1 column extends to the right and 1 row extends to the back and the rounded cutout faces the back right. Place another to the left of the ppp, so it also resembles a braille letter I, butt the cutout is on the rounded cutout faces the front right. Bring back your previous part and hold it horizontally Attach the back right corner of your part to the leftmost front facing side stud.

234. Rotate your part 180 degrees. Then flip it, so the antistuds face the back and the part you've attached in the previous step is on top. Bring back your leg build and position it vertically in front of you, so the joint ball hole faces the back. Flip it so it sits on its right side, so a column of 3 studs faces up. Attach the right overhang, the part you've attached in the previous step on the 3 rows of studs of your leg build.

235. This is the knee. Turn your leg build upside down, so the socket faces the right and the joint ball hole face the back left. Horizontally place a dark tan 1x3 plate on the front frow on the 3 left columns.

236.1 Vertically place a nougat 1x2 curved right slope white tile on the leftmost column of the ppp, so it slopes to the front and 1 row overhangs to the front Vertically place a nougat 1x2 curved slope tile to the right of the ppp, so it slopes to the front and 1 row overhangs to the front.

Group 47:

236.2 Vertically place a red 1x2 curved slope tile to the right of the ppp, so it slopes to the front and 1 row overhangs to the front.

237. Horizontally place a red 1x4 plate to the right of the back row of the ppp. Vertically place the front row of a red 1x2 curved left slope wedge tile on the leftmost column of the ppp, so it slopes to the back and 1 row overhangs to the back. Place a red 2x2 curved slope tile to the right of the ppp, so it slopes to the back and 1 row overhangs to the back. Place a red 2x2x2/3 curved corner slope tile to the right of the ppp, so the rounded corner faces the back right.

238. Horizontally place a dark red 1x3 plate upright on the 2 left columns of front facing side studs, so the leftmost column is not attached. Horizontally place a nougat 1x2 plate upright on the 2 left columns of the ppp. Horizontally place the right column of a nougat 1x2 slope tile with cutout on the leftmost column of the ppp, so it slopes to the left. Horizontally place a red 1x4 curved slope tile upright to the right of the ppp, so it slopes to the right. There should be a free remaining stud on the right of the ppp.

Group 48:

239. Flip your part so it sits on its back side, so it is shaped like a triangle, and the tip of the triangle faces up. Place the front row of a nougat 1x2 curved left slope wedge tile on the leftmost column of front facing side studs, so it slopes upward. Place a red 1x2 curved slope tile to the right of the ppp, so it slopes upward.

240. Let's make the twin. Horizontally place a red 1x2 curved inverted slope tile in front of you, so it slopes upward to the left. Horizontally place the left column of a nougat 1x2 plate on the right column of the ppp, so 1 column overhangs to the right. Horizontally place the left column of a red 1x2 curved inverted slope tile underneath the right overhang. Bring back your leg build so the antistuds face the front and the tip of the triangular shape, the knee points to the back. Place your part upright on the 4<sup>th</sup> through 7<sup>th</sup> columns of antistuds starting from the right.

Group 49:

241. Horizontally place the 2 columns of a red 1x4 plate on the 2 studs facing up, so it sits to the right of a vertical red 1x2 curved slope tile from step 239. Vertically place the back row of a red 1x2 curved right slope wedge tile on the leftmost column of the ppp, so it slopes to the front. Place a red 2x2 curved slope tile to the right of the ppp, so it slopes to the front. Place a red 2x2x2/3 curved corner slope tile to the right of the ppp, so the rounded corner faces the front right.

Group 50:

242. Let's start building the 2<sup>nd</sup> leg! Horizontally place a red 1x12 plate horizontally in front of you. Horizontally place a red 1x2 plate with socket on top of the ppp on the 2 left columns, so the socket faces the left.

243. Horizontally place a red 1x2 plate to the right of the ppp.

244. Place a white 1x1x2/3 short brick to the right of the ppp. Horizontally place a red 1x4 plate to the left of the ppp.

245. Horizontally place a red 1x3 tile on the 3 left columns of the ppp. Horizontally place a red 1x2 plate to the right of the ppp.

246. Horizontally place a red 1x2 brick with 2 side studs on each large side to the right of the ppp, so the side studs face the front and the back. Place 2 nougat 1x1 brick with a side stud on 2 sides 1 to the right of the other to the right of the ppp, so the side stud faces the front and the back.

247. Let's make a part! Horizontally place a green 2x8 plate in front of you. Horizontally place a black 1x8 brick with 7 pin holes on top of the ppp on the back row, so there's no overhang.

Place 2 green 1x2 bricks with pin hole one to the right of the other on the front right corner of your part, so the pin holes face the front and the back. Horizontally place a black 1x2 brick with 2 side studs on 1 long side to the left of the ppp, so the side studs face the front. Place a grey 1x1 brick with side stud to the left of the ppp, so the side stud faces the front. Place a white 1x1x2/3 short brick to the left of the ppp. Bring back your sub build and position it horizontally in front of you, so the socket faces the left. Place the 3 left columns of the front row of your part on the 3 right columns of your sub build, so 5 columns overhang to the right.

248. Horizontally place a medium nougat 1x4 plate on top of your sub build on the front row on the 4<sup>th</sup> through 7<sup>th</sup> columns from the left of visible studs.

249. Turn your sub build upside down, so the socket faces the left. Place a green 1x1 round plate on the back row on the 5<sup>th</sup> column of antistuds starting from the right.

250. Place a green 2x2 curved inverted slope brick on top of your upside down sub build on the 5<sup>th</sup> and 6<sup>th</sup> columns of antistuds starting from the right, so it slopes downward to the front. Place another to the left of the ppp, so it slopes downward to the front.

Group 51:

251. Horizontally place a green 2x3 plate on top of your sub build, on the 2<sup>nd</sup> through 4<sup>th</sup> columns from the right of antistuds. Then, place the left column of a green 2x2 curved inverted slope tile on the rightmost column of the ppp, so it slopes to the right.

252. Horizontally place a green 1x2 curved inverted slope tile on the back row on the 4<sup>th</sup> and 5<sup>th</sup> columns from the right, so it slopes to the right. Horizontally place a green 1x2 plate to the left of the ppp.

Group 52:

253. Place a nougat 1x1 plate on top of your sub build, on the back row, so it is centered horizontally. Horizontally place the right column of a nougat 1x2 curved inverted slope tile on the ppp, so it slopes to the left.

Group 53:

254. Horizontally place a nougat 1x2 plate on the back row on the 5<sup>th</sup> and 6<sup>th</sup> columns from the left of antistuds. Horizontally place the left column of a red 1x2 curved inverted slope tile on the right column of the ppp, so it slopes to the right. Place another to the left of the ppp, so it slopes to the left.

Group 54:

255. Turn your sub build right side up, so the socket faces the left. Place a green 2x2 corner plate on top of your sub build on the 2 right columns, so it looks like a braille letter D. Place another to the left of the ppp, so it resembles a braille letter F. Horizontally place a red 1x2 plate on the front row on the 2<sup>nd</sup> and 3<sup>rd</sup> columns from the right between and in front of the ppps.

Group 55:

256. Vertically place the front row of a green 1x2 plate to the left of the ppp. Place a green 2x2 plate with 1x2 side studs to the right of the ppp, so the side studs face the back. Vertically place a green 1x2 plate to the right of the ppp.

Group 56:

257. Horizontally place a red 1x2 plate to the left of the front row of the ppp, so it sits on the green 2x2 plate with 1x2 back facing side studs.

258. Place the front right corner of a green 2x2 curved slope tile on the left column of the ppp, so it slopes to the left. Repeat symmetrically to the right.

Group 57:

259. Place the back right corner of a green 2x2 plate upright on the 3<sup>rd</sup> column from the right of front facing side studs. Horizontally place the 2 left columns of a green 2x4 curved slope tile upright on the ppp, so it slopes to the right.

260. Horizontally place the back row of a green 2x4 right wedge plate on top of your sub build on the front row on the 4 right columns of visible studs, so the cut corner faces the front right, the studs face the back and the front left corner overhangs.

261. Place the front row of 2 green 2x2 curved slope tiles 1 to the left of the other on the back row of the ppp, so they slope to the back.

Group 58:

262. Horizontally place a nougat 1x2 plate on the front row on the 4<sup>th</sup> and 5<sup>th</sup> columns from the left of visible studs.

263. Place a red 1x1 plate to the left of the ppp.

264. Horizontally place a red 1x4 curved slope tile on top of your sub build on the 4 left columns of visible studs, so it slopes to the left. Horizontally place a nougat 1x2 curved slope tile to the right of the ppp, so it slopes to the right.

Group 59:

265. Place a nougat 1x1 plate upright on the rightmost column of front facing side studs. Place the left column and the back row of a nougat 2x2 round corner plate with 1x1 cutout upright to the left of the ppp, so the right rounded edge faces the bottom left and it resembles a braille letter E.

266. Vertically place the front row of a nougat 1x2 curved right slope wedge tile upright on the top row of the ppp, so it slopes upward. Vertically place a nougat 1x2 curved left slope wedge tile upright to the right of the ppp, so it slopes upward and it sits on the front facing nougat 1x1 plate from the previous step.

267. Horizontally place the 2 right columns of a red 1x4 plate upright on the 2 columns of front facing side studs. Vertically place the front row of a red 1x2 curved slope tile upright on the rightmost column of the ppp, so it slopes upward. Place the back row of a red 2x2 curved slope tile upright to the left of the bottom row of the ppp, so it slopes downward. Place a red 2x2x2/3 curved corner slope tile to the left of the ppp, so the curved corner faces the bottom left.

268. Place a nougat 1x1 plate upright on the rightmost column of back facing side studs. Place the left column and the back row of a nougat 2x2 round corner plate with 1x1 cutout upright to the left of the ppp, so the right rounded edge faces the bottom left and it resembles a braille letter E.

269. Vertically place the front row of a nougat 1x2 curved left slope wedge tile upright on the top row of the ppp, so it slopes upward. Vertically place a nougat 1x2 curved right slope wedge tile upright to the right of the ppp, so it slopes upward and it sits on the back facing nougat 1x1 plate from the previous step.

270. Horizontally place the 2 right columns of a red 1x4 plate upright on the 2 columns of back facing side studs. Vertically place the front row of a red 1x2 curved slope tile upright on the rightmost column of the ppp, so it slopes upward. Place the back row of a red 2x2 curved slope

tile upright to the left of the front row of the ppp, so it slopes downward. Place a red 2x2x2/3 curved corner slope tile to the left of the ppp, so the curved corner faces the bottom left.

271. Insert a blue 3L pin from front to back into each front facing pin hole, so 1L of each pin extends to the front.

272. Flip it so the 2 1l pins protrude to the top. Bring back the first leg build, and position it horizontally, so the socket faces the right and the joint ball hole faces the back. Attach the 2 bottom back left facing pin holes from top to bottom onto the 2 top protruding pins.

273. Let's make a part. Horizontally place a black 9L thick bent liftarm in front of you with the pin holes facing the front and the back and the short arm facing up on the right. Insert a grey 3L pin axle from front to back into the rightmost and topmost front facing pin hole using the 1L axle end, so the 2L pin extends to the front. Insert a blue 3L pin from front to back into the pin hole to the left of the inserted ppp, so 2L extends to the front. Insert a red 2L axle from back to front into the leftmost back facing pin hole, so 1L extends to the back. Insert a black 2L pin from back to front into the back facing pin hole to the right of the ppp, so 1L of the pin extends to the back. Skip a pin hole to the right and insert another from back to front, so 1L extends to the back. Skip another and insert another from back to front, so 1L of the pin extends to the back. You should have inserted 3 2L pins in total.

274. Bring back your legs sub build, so the 1 socket faces the right and 1 socket faces the left, and the ball joint socket faces the back. Flip it your part so the 2 3L protruding pins face down. Insert the 1L back facing axle into the leftmost bottom facing pin hole of your legs build. Insert the 3 top facing pins into the 2<sup>nd</sup> 4<sup>th</sup> and 6<sup>th</sup> bottom pin holes of your legs build starting from the left. Press firmly to secure. Flip your legs build, so the joint ball hole faces up hold it in this position. Bring back your torso build and orient it, so it faces the left and the rotating pin is on the bottom. Insert the bottom pin into the top facing ball joint hole of your legs build.

Fantastic work! In this bag you've built Cristiano's two powerful legs. One leg is stretched high, pointing toward the sky in his famous bicycle-kick pose, while the other is bent as the strong support leg on the ground. Together they create the dynamic movement he's known for. When you're ready, open Bag 8 and keep building — your star is almost ready to take flight.

#### Building Instructions (Bag 8, Book 1):

##### Group 60:

275. Let's make a sub build! Horizontally place a medium nougat 2x5 stair plate in front of you, so the stairs lead down to the left. Horizontally place a nougat 1x2 slope tile on the back right corner of the ppp, so it slopes to the back.

276. Repeat symmetrically to the front.

277. Stack 2 Nougat 1x2 plates, then vertically place the stack to the left of the 2 ppps.

278. Place a white 1x1 2/3 short brick with 2 side studs to the left of the front row of the stack, so the side studs face the front. Repeat symmetrically to the back. Vertically place a grey 1x2x1 2/3 with studs on 3 sides to the left of the ppps, so the 2x2 side studs face the left.

279. Stack a nougat 1x2 plate on a medium 1x2 plate with 2 clips on a large side. Vertically place your stack underneath the 2<sup>nd</sup> column from the right of your sub build, so the clips face the right.

280. Turn your sub build upside down, so the clips face the right. Horizontally lace 2 medium nougat 1x2 curved inverted slope tiles one in front of the other on the 2<sup>nd</sup> and 3<sup>rd</sup> columns from

the right of antistuds, so they slope to the right and they sit on the vertical 1x2 plate with 2 right facing clips and on the 2x5 stair plate.

281.1 Place a grey 2x2 plate to the left of the ppps.

Group 61:

281.2 Place a dark brown 2x2 plate on the ppp.

282. Place a dark brown 2x2 plate with 1x2 side studs upright on the left facing side studs, so its 1x2 side studs face down. place the left column of a dark brown 1x2 plate with 3 spikes on the top column of left facing side studs, so the spikes point upward.

283. Place a dark brown 2x2 triangular tile upright on the left facing side studs so the right angle faces the bottom front.

284. Turn your sub build right side up, so the clips face the right. horizontally place a dark brown 2x4 plate on top of your sub build, so there's no overhang. Place 2 dark brown 1x1 slope tiles 1 in front of the other on the leftmost column of the ppp, so they slope to the right.

285. Vertically place a dark brown 1x2 plate upright on the left column of front facing side studs. Place a nougat 1x1 plate upright to the right of the top row of the ppp.

286. Vertically place the back row of a dark brown 1x2 plate on the front facing stud below the ppp.

287. Place a dark brown 2x2x2/3 curved left wedge slope tile upright to the left of the ppp, so it slopes to the left and it attaches only by the back right corner to the sub build.

288. Horizontally place a dark brown 1x2 curved slope tile to the right of the top row of the ppp, so it slopes to the right. Horizontally place a dark brown 1x2 curved right slope wedge tile below the ppp, so it slopes to the right.

289. Place a nougat 1x1 quarter round tile upright on the right front facing side stud, so the right angle faces the bottom left and the rounded edge faces the top right. Horizontally place a dark brown 1x2 curved right slope wedge tile upright to the left of the ppp, so it slopes to the left.

Group 62:

290. Vertically place a dark brown 1x2 plate upright on the left column of back facing side studs. Place a nougat 1x1 plate upright to the right of the top row of the ppp.

291. Vertically place the back row of a dark brown 1x2 plate on the back facing stud below the ppp.

292. Place a dark brown 2x2x2/3 curved left wedge slope tile upright to the left of the ppp, so it slopes to the left and it attaches only by the back right corner to the sub build.

293. Horizontally place a dark brown 1x2 curved slope tile upright to the right of the top row of the ppp, so it slopes to the right. Horizontally place a dark brown 1x2 curved right slope wedge tile upright below the ppp, so it slopes to the right.

294. Place a nougat 1x1 quarter round tile upright on the back right facing side stud, so the right angle faces the bottom left and the rounded edge faces the top right. Horizontally place a dark brown 1x2 curved right slope wedge tile upright to the left of the ppp, so it slopes to the left.

295. Horizontally place a Nougat 4x4x2 large, molded face with Cristiano Ronaldo pattern on top of your head build.

296. Bring back your Cristiano Ronaldo body build so it faces the left. Hold your head build the vertically upright, so the face faces the left and the clips are on the bottom right. Clip the bottom clips to the top facing bars of the body.

Group 63:

297. Let's make a shoe build. Horizontally place a medium blue 1x2 plate with 2x2 upright facing side studs in front of you, so the side studs face the back. Horizontally place a dark grey 1x2 plate with tow ball on the ppp, so the tow ball faces the right.

298. Horizontally place a blue 1x2 plate on top of the ppp.

299. Horizontally place the 2 left columns of a white 1x3 rounded plate on the ppp, so 1 column overhangs to the right above the tow ball. Horizontally place a blue 1x2 plate with 2x2 side studs hanging down on the 2 left columns of the ppp, so the side studs face the front.

300. Place a medium blue 1x1 plate with 1x2 upright facing side studs on top of your shoe build on the left column, so the side studs face the back.

Group 64:

301. Place a white 1x1 brick with side stud on the ppp, so the side stud faces the right. Place a blue 1x1 plate with 1x2 side studs hanging down on the ppp, so the side studs face the front.

302. Place a white 1x1 half round tile on the top row of front facing side studs. Vertically place a gold 1x2 half round tile with stud upright on the 2 bottom rows of front facing side studs on the left column, so the rounded edge faces the right. Place a white 2x2 tile with 2 1x1 curved cutouts upright to the right and to the top of the ppp.

303. Horizontally place a white 1x2 curved slope tile on top of your sub build on the 2 right columns, so it slopes to the right.

304. Place a white 1x1 half round tile on the top row of back facing side studs. Vertically place a gold 1x2 half round tile with stud upright on the 2 bottom rows of back facing side studs on the left column, so the rounded edge faces the right. Place a white 2x2 tile with 2 1x1 curved cutouts upright to the right and to the top of the ppp.

305. Flip your shoe build, so the tow ball faces up on the right. Place a white 2x1 triple slope tile with inside stud holder upright on the left facing side stud, so the flat side faces down. Horizontally place the right column of a white 1x2x2/3 slope tile with grille on top of your build on the single stud, so it slopes to the left.

306. Place a gold 1x1 round plate with open stud on the bottom right facing antistud. Place a blue 1x2 curved inverted slope tile vertically upright on the 2 right facing antistuds, so it slopes upward.

307. Place the left column and the back row of a medium blue 2x2 curved corner tile on the front facing side stud so the rounded edge face the top right. Repeat symmetrically to the back.

308. Bring back your Cristiano Ronaldo build, so it is facing the front. Rotate your shoe build 90 degrees counterclockwise so the tow ball faces up on the back. Attach the tow ball to his right leg kicked straight up.

Group 65:

309. Let's make a shoe build. Horizontally place a medium blue 1x2 plate with 2x2 upright facing side studs in front of you, so the side studs face the back. Horizontally place a dark grey 1x2 plate with tow ball on the ppp, so the tow ball faces the left.

310. Horizontally place a blue 1x2 plate on top of the ppp.

311. Horizontally place the 2 right columns of a white 1x3 rounded plate on the ppp, so 1 column overhangs to the left above the tow ball. Horizontally place a blue 1x2 plate with 2x2 side studs hanging down on the 2 right columns of the ppp, so the side studs face the front.

312. Place a medium blue 1x1 plate with 1x2 upright facing side studs on top of your shoe build on the right column, so the side studs face the back.

313. Place a white 1x1 brick with side stud on the ppp, so the side stud faces the left. Place a blue 1x1 plate with 1x2 side studs hanging down on the ppp, so the side studs face the front.

314. Place a white 1x1 half round tile on the top row of front facing side studs. Vertically place a gold 1x2 half round tile with stud upright on the 2 bottom rows of front facing side studs on the right column, so the rounded edge faces the left. place a white 2x2 tile with 2 1x1 curved cutouts upright to the left and to the top of the ppp.

315. Horizontally place a white 1x2 curved slope tile on top of your sub build on the 2 left columns, so it slopes to the left.

316. Place a white 1x1 half round tile on the top row of back facing side studs. Vertically place a gold 1x2 half round tile with stud upright on the 2 bottom rows of back facing side studs on the right column, so the rounded edge faces the left. place a white 2x2 tile with 2 1x1 curved cutouts upright to the left and to the top of the ppp.

317. Flip your shoe build, so the tow ball faces up on the left. Place a white 2x1 triple slope tile with inside stud holder upright on the right facing side stud, so the flat side faces down. Horizontally place the left column of a white 1x2x2/3 slope tile with grille on top of your build on the single stud, so it slopes to the right.

318. Place a gold 1x1 round plate with open stud upright on the bottom left facing antistud. Place a blue 1x2 curved inverted slope tile vertically upright on the 2 left facing antistuds, so it slopes upward.

319. Place the right column and the back row of a medium blue 2x2 curved corner tile on the front facing side stud so the rounded edge face the top left. Repeat symmetrically to the back.

320. Bring back your Cristiano Ronaldo build, so it is facing the front. Rotate your shoe build 90 degrees clockwise so the tow ball faces up on the back. Attach the tow ball to his left supporting leg.

Group 66:

321. Bring back your main build and position it horizontally in front of you, so the Ronaldo's signature plaque faces the front. orient Ronaldo, so it is facing the left. Insert the 2 2L back protruding pins to the 2 front left facing holes of the back left support, so this back rests on the front support.

322. Insert a blue 3L bar from front to back into front facing open stud on the short top bar of the seven, so 2L of the bar extends to the front.

323. Let's make a part! vertically place a yellow 2L pin round connector with slot, so the pin holes face the front and the back. Insert a black 2L pin from front to back into the front facing pin hole, so 1L extends to the front. Repeat symmetrically to the back. Hold your part vertically upright and insert the bottom bar into the open inner stud of a white, black, blue, and pink half soccer ball. Attach the bottom facing open stud of a second half soccer ball onto the top facing 1L pin. Attach your soccer ball using one of the outward holes from front to back onto the 2L front facing bar.

Incredible work! In this bag you've built Cristiano's head, complete with his molded face and signature hairstyle, giving your star a real, lifelike expression. You also built his two shoes and placed the whole figure onto the field. His high bicycle-kick leg connects to the back-left support, and his back rests gently against the front support, creating his famous flying pose. Finally, you built the soccer ball and attached it to the big number seven with a bar, adding movement and excitement to the scene. With this, the first dynamic position is complete. When you're ready, you can begin the second pose and enjoy building Cristiano in a whole new way.

Second build: signature victory "Siuuu pose.

Book 2

Bag 1

Group 1: contains the pieces for steps 1-10.

Group 2: contains the pieces for step 11.

Group 3: contains the pieces for steps 12-20.

Group 4: contains the pieces for steps 21-22.

Group 5: contains the pieces for steps 23-24.

Group 6: contains the pieces for steps 25-26. 1..

Group 7: contains the pieces for steps 26.2-29.

Group 8: contains the pieces for steps 30-34.

Bag 2

Group 9: contains the pieces for steps 35-36.1.

Group 10: contains the pieces for steps 36.2-43.1.

Group 11: contains the pieces for steps 43.2 -47.

Group 12: contains the pieces for steps 48-49.1.

Group 13: contains the pieces for steps 49.2-56.1.

Group 14: contains the pieces for step 56.2.

Group 15: contains the pieces for steps 56.3-60.

Group 16: contains the pieces for steps 61-62.

Group 17: contains the pieces for steps 63-65.

Bag 3

Group 18: contains the pieces for steps 66-71.

Group 19: contains the pieces for steps 72-79.

Group 20: contains the pieces for steps 80-82.

Group 21: contains the pieces for steps 83-89.

Group 22: contains the pieces for step 90.1.

Group 23: contains the pieces for step 90.2.

Group 24: contains the pieces for steps 91-100.

#### Bag 4

Group 25: contains the pieces for steps 101-102.

Group 26: contains the pieces for steps 103-113.

Group 27: contains the pieces for step 114.1.

Group 28: contains the pieces for steps 114.2-117.1.

Group 29: contains the pieces for steps 117.2-122.

Group 30: contains the pieces for steps 123-127.

#### Bag 5

Group 31: contains the pieces for steps 128-134.

Group 32: contains the pieces for steps 135-144.

Group 33: contains the pieces for steps 145-149.1.

Group 34: contains the pieces for steps 149.2-152.

Group 35: contains the pieces for steps 153-160.

Group 36: contains the pieces for steps 161-162.

Group 37: contains the pieces for steps 163-165.

#### Bag 6

Group 38: contains the pieces for steps 166-171.

Group 39: contains the pieces for steps 172-173.

Group 40: contains the pieces for steps 174-178.

Group 41: contains the pieces for steps 179-184.

Group 42: contains the pieces for steps 185-192.

Group 43: contains the pieces for steps 193-196.

Group 44: contains de pieces for steps 197-202.

#### Bag 7

Group 45: contains de pieces for steps 203-210.

Group 46: contains de pieces for steps 211-215.

Group 47: contains de pieces for step 216.1.

Group 48: contains de pieces for steps 216.2-218.

Group 49: contains de pieces for steps 219-223.1.

Group 50: contains de pieces for steps 223.2-226.

Group 51: contains de pieces for steps 227-233.

Group 52: contains de pieces for steps 234-241.

Group 53: contains de pieces for steps 242-246.

Group 54: contains de pieces for step 247.1.

Group 55: contains de pieces for steps 247.2-249.

Group 56: contains de pieces for steps 250-254.

Group 57: contains de pieces for steps 255-257.

Group 58: contains the pieces for steps 258-263.

Group 59: contains the pieces for steps 264-270.

Bag 8

Group 60: contains the pieces for steps 271-277.1.

Group 61: contains the pieces for steps 277.2- 285.

Group 62: contains the pieces for steps 286-292.

Group 63: contains the pieces for steps 293-302.

Group 64: contains the pieces for steps 303-312.

Group 65: contains the pieces for steps 313-318.

Description:

Here is a description of the alternative MODEL OF Cristiano Ronaldo's SIUUU Celebration Pose that might help you blind builder imagine what the build looks like once finished. The alternative model stands on a green base that represents the football field. At the front of the base, there is a black nameplate with Cristiano Ronaldo's signature in gold, giving the display a premium finish.

At the back of the field, a large gold number seven rises upright and centered. Attached to the front of this number seven is a gold "CR" plaque set against a dark green background, matching the style of the main model.

On the pitch, Cristiano Ronaldo appears in his famous celebration pose, the one LEGO refers to as "SIUUU." His chest leans forward, while his head stretches back, capturing the powerful movement of the celebration. He is wearing the official Portugal national team kit: a red shirt with the number 7 printed on the front and back, and green shorts. His arms are poseable, and his head can turn, allowing small adjustments to the pose.

Ronaldo stands at the center of the pitch, facing the FIFA Official Match Ball placed between his legs. The ball is white, blue, and pink, and sits perfectly centered between his shoes without touching them, as if waiting for the next moment of action.

General placement guidelines

1. Rows and Columns Across the Whole Build:

Unless we say otherwise, rows are counted from front to back or back to front, and columns are counted from left to right or from right to left across the entire build.

Example: Vertically place a tan 1x2 plate on the 4th and 5<sup>th</sup> rows from the front on the 3rd column from the left. or place a white 2x2 tile with stud on the 2 back rows on the 3<sup>rd</sup> and 4<sup>th</sup> columns from the right.

This uses the full build's row and column Layout.

## 2. Why We Sometimes Count Columns from a Specific Row:

Each row can have a different number of columns. This happens when the build becomes narrower or wider toward the sides, or when certain rows have cutouts, curves, or irregular shapes.

So, if a row is shorter or wider than the rows above or below it, counting columns across the whole build becomes misleading. To avoid confusion, we count columns within that specific row.

Example: Instead of: Place the 1x2 plate on the front row on the 2nd and 3rd columns from the right. We say: Place the 1x2 plate on the 2nd and 3rd columns from the right of the front row.

This makes it clear that the row itself is the reference, not the whole build.

## 3. Why We Sometimes Count Rows from a Specific Column:

Each column can have a different number of rows. This happens when one column extends further back than the next, another extends forward, some columns are tall, others short, or the shape is staggered or irregular. When columns vary in height or depth, counting rows across the entire build becomes confusing. To avoid this, we count rows within that specific column.

Example: Place a tan 1x1 round plate on the 3rd row from the back of the 2nd column from the right.

This avoids the problem of columns with different lengths.

## 4. Using Landmarks for Tactile Orientation:

When rows and columns alone aren't enough, we add landmarks—nearby pieces that help the builder feel where the new piece belongs.

Example: Vertically place a green 2x4 plate on the 2nd through 5th rows from the back on the 2nd and 3rd columns from the left, so the back row sits on the front row of the back left 2x2 corner plate, and the front row sits on the back row of the front left 2x2 corner plate.

These tactile cues confirm the correct placement.

## General technic guidelines

1. In this set, you will use Technic elements such as liftarms, pins, axles, and connectors. Liftarms may appear in different shapes (for example, straight, L-shaped, bent, or T-shaped), and they may include both pin holes (round) and axle holes (cross-shaped). Liftarms also come in two thicknesses, which affects how far pins and axles extend when inserted.

Liftarm Thickness: Thick vs. Thin:

- A thick liftarm is the standard type and is 1L thick.
- A thin liftarm is 0.5L thick (half the thickness of a regular liftarm).

When a step uses a thin liftarm, the instruction will always say so. If the instruction does not mention thickness, you should assume the liftarm is the standard 1L thick type.

This is important because they are half as thick, and a pin or axle inserted through a thin liftarm will extend 0.5L farther on 1 side compared to the same pin inserted through a thick liftarm.

#### Example

- In a 3L thick liftarm, inserting a 2L pin from front to back leaves 1L extending toward the front.
- In a 3L thin liftarm, inserting the same 2L pin from front to back leaves 1.5L extending toward the front.

## 2. Counting the Holes

- When a liftarm has both pin holes and axle holes, we count all holes in order, from one end of the liftarm to the other.
- Unless the instruction specifically says, in the axle hole or in the pin hole, you should assume the counting includes both types of holes together.
- The instruction will always tell you which direction to count from: from the right or from the left.

#### Examples

- Insert a tan 2L pin into the 2nd back-facing hole from the right.

Count all holes (pin and axle) starting at the right end. Place the pin in the second hole.

- Insert a black 2L axle into the 3rd hole from the left.

Count all holes from the left end until the third one, regardless of type.

- Insert a blue pin into the axle hole in the 4th position from the right.

Here, the instruction specifies axle hole, so place the pin in the cross-shaped hole at that position.

## 3. Directional Guidance for Inserting or Attaching Pieces

To make Technic building smoother for blind builders, we always specify the exact direction a pin, axle, or connector moves when it is inserted or attached.

We use the following terms:

- front to back — the piece moves away from you
- back to front — the piece moves toward you
- top to bottom — the piece moves downward
- bottom to top — the piece moves upward

#### Examples

- Insert a black 2L pin from front to back into the second front-facing hole from the right of your 5L liftarm.

- Insert a 3L pin from back to front into the 3<sup>rd</sup> back facing pin hole from the left, so 2L of the pin extends to the back. Attach the leftmost front facing hole of your 7L liftarm from back to front onto the 2L back extending pin.

## 4. Specifying How Far a Pin or Axle Extends

After inserting or attaching a piece, we always tell you how much of the pin or axle extends in each direction, using Technic length units (L).

This measurement automatically accounts for whether the liftarm is thick or thin.

#### Examples

- Insert a black 2L pin from front to back into the second front-facing hole from the right of the 5L liftarm, so 1L of the pin extends toward the front.

- Attach the leftmost back-facing hole of a 7L liftarm from front to back onto the 1L pin extending at the front.

These technic guidelines help to make Technic-set building easier for blind builders.

Let's continue building the 2<sup>nd</sup> model!

Building Instructions (Bag 1, Book 2):

#### Group 1:

1. Place a black 4x4 corner plate in front of you, so the right angle faces the back right and it looks like a large braille letter D. Horizontally place the 4 right columns of a black 1x8 brick on the back row of the ppp, so 4 columns overhang to the left.

2. Vertically place the back row of a black 4x4 corner plate underneath the 4 left columns of your build, so it looks like a large braille letter F.

3. Vertically place a black 1x4 brick with 4 side studs on 1 long side on the 2<sup>nd</sup> through 4<sup>th</sup> rows from the back of the rightmost column, so the side studs face the right, and 1 row overhangs to the front.

4. Vertically place the back right corner of a dark grey 2x4 plate underneath the front overhang.

5. Vertically place a black 1x2 log brick on the 2<sup>nd</sup> and 3<sup>rd</sup> rows from the front on the rightmost column of your build, so it sits in front of the vertical 1x4 brick with 4 right facing side studs. Vertically place a black 1x4 brick with 4 side studs on 1 long side in front of the ppp, so the side studs face the right, and 3 rows overhang to the front.

6. Let's make a part. Vertically place a dark grey 2x4 plate in front of you. Vertically place a white 1x10 brick with 9 pin holes on top of the ppp on the left column, so the pin holes face the right and the left and it is centered vertically. Bring back your main build and position it vertically in front of you so the overhang is on the front right. Vertically place the 3 back overhanging rows of your part on the 2<sup>nd</sup> through 4<sup>th</sup> rows from the back on the leftmost column of your main build.

7. Vertically place the back right corner of a black 4x4 corner plate underneath the front right overhang, so the right angle faces the front right and it looks like a large braille letter J. Repeat symmetrically to the left.

8. Vertically place a dark grey 1x10 brick on top of your build on the 2<sup>nd</sup> column from the right, so it is centered vertically. Repeat symmetrically to the left.

9. Horizontally place a yellow 1x4 plate to the right of the front top of the ppp., so it sits between the 2 ppps.

10. Horizontally place 2 black 1x4 bricks with 4 side studs on 1 long side 1 to the right of the other on the front row, so the side studs face the front and there's no overhang.

#### Group 2:

11.1 Let's make 2 identical parts! Horizontally place a black 6x8 brick with pin holes and open center in front of you. Insert a black 2L pin from right to left into the right frontmost facing pin hole, so 1L of the pin extends to the right. Insert the pin end of a blue 2L pin axle from right to left into the right backmost facing pin hole, so the 1L axle end extends to the right. Repeat both parts symmetrically to the left. You should now have 2 identical parts! Tacke one of your parts and rotate it 180 degrees, so the protruding axles face the left close to the front left corner and the right close to the front right corner. Insert a black 2L pin from front to back into the front leftmost facing pin hole, so 1L of the pin extends forward. Repeat symmetrically to the right. Horizontally attach the back leftmost and the back rightmost facing pin holes of the other part the one you haven't rotated from front to back onto the 2 black 1L front facing pins.

11.2 Bring back your main build and position it vertically in front of you so the 1x10 brick with 9 pin holes is vertically on the left with its pin holes facing the left and the right. Align the right side of your sub build with the left side of your main build so the corners are even. Insert the right protruding pins and axles from left to right into the left facing pin holes of your main build. Press firmly to secure.

Group 3:

12. Let's make a sub build! Place a black 4x4 corner plate in front of you, so the right angle faces the back left and it looks like a large braille letter F. Horizontally place the 4 left columns of a black 1x8 brick on the back row of the ppp, so 4 columns overhang to the right.

13. Place the back row of a black 4x4 corner plate underneath the 4 right columns of the ppp, so it looks like a large braille D.

14. Vertically place a black 1x4 brick with 4 side studs on 1 long side in front of the leftmost column of the horizontal 1x8 brick on the 2<sup>nd</sup> row from the back on the leftmost column, so the side studs face the left, and 1 row overhangs to the front.

15. Vertically place the back left corner of a dark grey 2x4 plate underneath the front overhang.

16. Vertically place a black 1x2 log brick on the 2<sup>nd</sup> and 3<sup>rd</sup> rows from the front on the leftmost column of your build, so it sits in front of the vertical 1x4 brick with 4 left facing side studs. Vertically place a black 1x4 brick with 4 side studs on 1 long side in front of the ppp, so the side studs face the left, and 3 rows overhang to the front.

17. Let's make a part! Vertically place a dark grey 2x4 plate in front of you. Vertically place a white 1x10 brick with 9 pin holes on top of the ppp on the right column, so the pin holes face the right and the left and it is centered vertically. Bring back your main build and position it vertically in front of you so the overhang is on the front left. Vertically place the 3 back overhanging rows of your part on the 2<sup>nd</sup> through 4<sup>th</sup> rows from the back on the rightmost column of your main build.

18. Vertically place the back left corner of a black 4x4 corner plate underneath the front left overhang, so the right angle faces the front left, and it looks like a large braille letter H. Repeat symmetrically to the right.

19. Vertically place a dark grey 1x10 brick on top of your build on the 2<sup>nd</sup> column from the left, so it is centered vertically. Repeat symmetrically to the right.

20. Horizontally place a yellow 1x4 plate to the left of the front row of the ppp, so it sits between the 2 ppps.

Group 4:

21. Horizontally place 2 black 1x4 bricks with 4 side studs on 1 long side 1 to the right of the other on the front row, so the side studs face the front and there's no overhang.

22. Bring back your main build and position it vertically in front of you so the 2 protruding 1L axles and 2 1L pins face the left. Align the right side of your sub build with the left side of your main build so the corners are even. Insert the left protruding pins and axles from right to left into the right facing pin holes of your main build. Press firmly to secure.

Group 5:

23. Let's make 2 identical parts! Horizontally place a green 1x4 plate in front of you. Horizontally place the 2 left columns of a green 1x6x1 slope tile with 1x2x1/3 cutout on the 2 right columns of the ppp, so it slopes to the right and 4 columns extend to the right. Repeat symmetrically to the left. You should now have 2 identical parts! Bring back your main build and place it vertically in front of you. Horizontally place one of your parts upright on the front facing side studs, so there's no overhang. Repeat symmetrically to the back.

24. Let's make 2 identical parts! Horizontally place a green 1x2 plate in front of you. Horizontally place the 2 left columns of a green 1x6x1 slope tile with 1x2x1/3 cutout on the ppp, so it slopes to the right. You should now have 2 identical parts! Bring back your main build and position it horizontally in front of you, so the side studs face the front. Take 1 of your parts and horizontally place it upright on the 6 right columns of front facing side studs, so it slopes to the right. Repeat symmetrically to the left.

Group 6:

25. Turn your build upside down, so the 2 parts you have just attached are facing the back. Vertically place a black 1x2 plate on the 2 front rows on the 9th column from the right of antistuds, so it sits to the left of the vertical right black 2x4 plate with 3 holes. Repeat symmetrically to the left. Then, repeat both placements symmetrically to the back.

26.1 Place a dark blue 2x2 inverted tile on top of your upside down build on the 9<sup>th</sup> and 10<sup>th</sup> columns from the right, so it is centered vertically. Repeat symmetrically to the left.

Group 7:

26.2 Place 2 yellow 2x2 inverted tiles one to the right of the other to the right of the ppp, between the 2 ppps.

27. Let's make a part! Vertically place a dark grey 2x4 plate in front of you. Place a dark grey 2x2 inverted slope brick on the back row of the ppp, so it slopes upward to the back. Place a grey 2x2 round brick with axle hole in front of the ppp. Turn it upside down so the 2 ppps are on the bottom front. Place your part on top of your main build on the 4 back rows on the 10<sup>th</sup> and 11<sup>th</sup> columns from the left of antistuds.

28. Let's make a part! Place a black 4x4 plate in front of you. Horizontally place a black 2x4 brick with 3 top facing axle holes on top of the ppp on the 2 front rows. place 2 dark grey 2x2 inverted slope bricks one to the right of the other on the back row of your part, so they slope upward to the back. Bring back your upside down main build and position it horizontally in front of you so the side with no side studs faces the front. turn your part upside down so the slopes are on the back. Place the 2<sup>nd</sup> row from the back of your part on top of your main build on the front row of antistuds, so it is centered horizontally and 2 rows extend to the front.

29. Turn your build right side up, so the side with the 2 inverted slopes from the previous step faces the back. Vertically place 2 black 2x4 plates 1 to the right of the other on the 4 back rows, so together they are centered horizontally.

Group 8:

30. Horizontally place a green 2x4 tile to the left of the 2 front rows of the left ppp. Horizontally place a green 1x4 plate to the left of the back row of the ppp. Then, repeat both parts symmetrically to the right.

31. Vertically place the back row of a green 2x6 tile to the right of the right horizontal 1x4 plate from the previous step. Place another vertically in front of the ppp. Repeat both placements symmetrically to the left.

32. Horizontally place a green 2x6 tile in front of the back right horizontal one. Place another horizontally in front of the ppp. Repeat both placements symmetrically to the left.

33. Vertically place a green 2x6 tile on the 6 front rows on the 5<sup>th</sup> and 6<sup>th</sup> columns from the right counting the visible studs. Vertically place a green 1x6 plate to the left of the ppp. Vertically place a green 2x6 tile to the left of the ppp. Place another vertically to the left of the ppps. You should have placed 3 green 2x6 tiles and 1 1x6 tile.

34. Vertically place a green 2x6 plate with 5 axle holes to the left of the ppp. Vertically place a green 1x6 tile to the left of the ppp. Vertically place a green 2x6 tile to the left of the ppp.

Great beginning! In this first bag you've started shaping the field, building the strong base where everything else will grow. You've set down the very first layer of the new build, and it already feels solid under your hands. When you're ready, open Bag 2 and keep the adventure going — the next pieces are waiting for you.

Building Instructions (Bag 2, Book 2):

Group 9:

35. Let's make a part! Horizontally place a green 2x4 brick in front of you. Vertically place a green 1x2 brick with axle hole on top of the ppp on the leftmost column.

36.1 Place a white 1x1 brick to the right of the back row of the ppp. Place another on the back right corner of your part.

Group 10:

36.2 Place a black 1x1 brick to the left of the ppp.

37. Horizontally place a green 1x3 brick in front of the 3 ppps.

38. Horizontally place a green 2x4 brick on top of your part, so there's no overhang.

39. Horizontally place a dark green 1x2 plate on top of your part in the back left corner. Horizontally place a grey 1x2 plate with socket on 1 large side on the ppp, so the socket faces the front. Horizontally place a dark green 1x2 plate on top of the ppp.

40. Place a green 2x2 brick on top of your part on the 2 right columns.

41. Horizontally place a green 2x4 brick on top of your part, so there's no overhang.

42. Place 2 green 1x1 bricks with pin hole one in front of the other on top of your part on the leftmost column, so the pin holes face the front and the back.

43.1 Horizontally place a white 1x3 plate on top of your part on the back row on the 3 right columns. Place a gold 1x1 plate on top of the ppp on its leftmost column. Skip 1 column to the right and place another.

Group 11:

43.2 Place a dark blue 1x1 plate to the left of the ppp. Horizontally place a white 1x3 plate on top of the 3 ppps.

44. Horizontally place a green 1x3 brick in front of the ppp.

45. Horizontally place a green 2x4 plate on top of your part, so there's no overhang. Place 2 green 2x2 tiles with upright 1x2 plate one to the right of the other on top of your part with the side studs facing the front. Horizontally place a tan 1x4 plate upright on the front facing side studs.

46. Rotate your sub build 90 degrees clockwise, so the side studs face the left. Then, flip it, so it sits on the right side with the studs of the ppp facing up on the right and the antistuds facing the left. Vertically attach the side studs of 2 green 1x2 bricks with 1x2 side studs on 1 long side one in front of the other to the left facing antistuds of your sub build. Now, vertically place a tan 1x4 plate underneath the 2 ppps.

47. Rotate your sub build 90 degrees clockwise, so the 3 ppps are on the back. Bring back your main build and position it horizontally in front of you, so the side with no green 1x6x1 slope tiles faces the back. Vertically place your sub build on the right gap so the front row attaches to a horizontal yellow 1x4 plate on the 2<sup>nd</sup> row from the front of visible studs.

Group 12:

48. Let's make a part! Horizontally place a green 2x4 brick in front of you. Vertically place a green 1x2 brick with axle hole on top of the ppp on the rightmost column.

49.1 Horizontally place a black 1x3 plate to the left of the back row of the ppp. Place a white 1x1 plate on the leftmost column of the ppp. Skip one column to the right and place another.

Group 13:

49.2 Place a red 1x1 plate to the left of the ppp. Horizontally place a red 1x3 plate on top of the 3 ppps.

50. Horizontally place a green 1x3 brick in front of the ppp.

51. Horizontally place a green 2x4 brick on top of your part, so there's no overhang.

52. Horizontally place a dark green 1x2 plate on top of your part on the back right corner. Horizontally place a grey 1x2 plate with socket on 1 large side on the ppp, so the socket faces the front. Horizontally place a dark green 1x2 plate on top of the ppp.

53. Place a green 2x2 brick on top of your part on the 2 left columns.

54. Horizontally place a green 2x4 brick on top of your part.

55. Place 2 green 1x1 bricks with pin hole 1 in front of the other on the rightmost column of the ppp, so the pin holes face the front and the back.

56.1 Horizontally place a white 1x3 plate to the left of the back row of the ppp.

Group 14:

56.2 Horizontally place a green 1x3 plate on the ppp.

Group 15:

56.3 Horizontally place a white 1x3 plate on top of the ppp.

57 Horizontally place a green 1x3 brick in front of the ppp.

58. Horizontally place a green 2x4 plate on top of your part. Place 2 green 2x2 tiles with upright 1x2 plate one to the right of the other on top of your part with the side studs facing the front. Horizontally place a tan 1x4 plate upright on the front facing side studs.

59. Flip it, so it sits on the front side with the studs of the ppp facing up on the front and the antistuds facing the back. Vertically attach the side studs of 2 green 1x2 bricks with 1x2 side studs on 1 long side one to the right of the other to the back facing antistuds of your sub build. Now, horizontally place a tan 1x4 plate underneath the 2 ppps.

60. Bring back your main build and position it horizontally in front of you, so the side without side green 1x6x1 slope tiles faces the back. Vertically place your sub build on the left gap, so the front row attaches to a horizontal yellow 1x4 plate on the 2<sup>nd</sup> row from the front of visible studs.

Group 16:

61. Horizontally place a green 2x4 tile on top of your main build on the 2 front rows of visible studs on the 4 left columns of visible studs. Repeat symmetrically to the right.

62. Turn your build upside down, so the 2 inverted slope bricks face the front. Place a black 2x2 round plate with axle hole on top of your upside down build on each corner, so there are 4 in total. Place another on the 2 back rows on the 8<sup>th</sup> and 9<sup>th</sup> columns from the right. Repeat symmetrically to the left. Then, repeat both placements symmetrically on the 3<sup>rd</sup> and 4<sup>th</sup> rows from the front. Place another on the 2 front rows of antistuds, so it is centered horizontally.

Group 17:

63. Turn your build right side up so the 2 inverted slope bricks are on the back. Place 2 grey 2x2 round tiles with hole in the 2 back rows of your build one to the right of the other.

64. Horizontally place a black 1x2 hinge brick base upright on the 2 right columns of front facing side studs to the left of the right sloping 1x6x1 slope tile, so the open side of the brick is on the top. Repeat symmetrically to the left.

65. Let's make a part! Horizontally place a black 2x12 plate in front of you. Horizontally place a black 2x6 tile printed with the signature of Cristiano Ronaldo and his name in gold. Horizontally place a black 2x3 pentagonal tile to the left of the ppp, so the triangular tip points to the left. Repeat symmetrically to the right. Place a black 2x2 plate with 1x2 antistuds and bottom bar handle underneath the 2 left columns of your part, so the bar handle is on the front. Repeat symmetrically to the right. Bring back your main build and position it horizontally in front of you, so the 1x2 hinge bricks base face the front. Attach the bottom front bar handles of your part to the front facing hinge bricks. Press the top side of your attached part towards the back until it reaches the green tiles.

What a fantastic play! With Bag 2 you've completed the entire soccer field — the bright green base where Cristiano Ronaldo will soon take his place. You've laid every tile with precision, creating a smooth, solid pitch that feels ready for a real match under your fingers. This field is the foundation of the whole scene, strong and steady, waiting for the legend himself to rise above it. When you're ready, open Bag 3 and keep the match going — the next big moment is already lining up.

Building Instructions (Bag 3, Book 2):

Group 18:

66. Let's start building the number seven build! Vertically place a red upside down 4x6 plate in front of you. Horizontally place the 2 left columns of a tan 1x4 hinge plate on the back right corner, so the rounded hinge part faces the back, and 2 columns overhang to the right.

67. Horizontally place a black 1x2 plate in front of the 2 left columns of the ppp.

68. Vertically place the 2 front rows of a black 2x3 plate to the left of the 2 ppps, so 1 row overhangs to the back. Take a black 4x6 tile with studs on 3 edges and orient it vertically so the studs face down and the edge with no studs is on the right. Then, vertically place its 2 left columns in front of the ppp, so 2 rows overhang to the front.

69. Vertically place the 2 back rows of an upside down red 2x16 plate underneath the front left corner, so 14 rows of antistuds extend to the front. Repeat symmetrically to the right.

70. Place a black 4x6 tile with studs on 3 edges on top of your sub build on the 3<sup>rd</sup> through 8<sup>th</sup> rows from the front, so the edge without studs faces the right. Vertically place another behind the ppp, so the edge with no studs faces the right.

71. Vertically place a black 2x3 plate on top of your part on the front right corner, so 1 row overhangs to the front. Horizontally place a black 1x2 plate to the left of the back row of the ppp.

Group 19:

72.. Horizontally place the 2 right columns of a tan 1x4 hinge plate in front of the ppp, so the rounded hinge part faces the front and 2 columns overhang to the left.

73. Let's make a part! Vertically place a red 2x16 plate in front of you. Horizontally place the 2 left columns of a black 2x3 plate underneath the 2 back rows of the ppp, so 1 column extends to the right.

74. Vertically place a black 2x3 plate in front of the 2 left columns of the ppp.

75. Vertically place the 2 back rows of a red 1x8 plate on the rightmost column of your part, so it sits on the back horizontal 2x3 plate, and 6 rows overhang to the front.

76. Bring back your sub build and place it vertically in front of you, in the same position as step 83. Turn your part upside down, so the pppps are on the front. push the left overhanging hinge plate of your sub build towards the front, so it forms a right angle. Vertically place these 2 overhanging rows of the front left hinge plate on the 3<sup>rd</sup> and 4<sup>th</sup> rows from the front on the rightmost column of antistuds, so they sit on the vertical front right red 1x8 plate.

77. Push your attached part forward as far as you can. Turn your sub build right side up, so the part you have just attached is horizontally on the back. You have formed the number 7. Vertically place the 3 back rows of a black 1x5 plate underneath the 6<sup>th</sup> column from the right of your build, so 2 rows extend to the front avoiding the hinge part to fold.

78. Vertically place a black 1x2 plate underneath the 2<sup>nd</sup> column from the left of the 2 back rows of your seven build (here, we are counting only the columns withing the 2 mentioned rows). Place the 2 back rows of 2 black 4x4 plates one to the right of the other to the right of the ppp, so 2 rows are exposed to the front.

79. Horizontally place a gold 2x4 right wedge plate on the 4<sup>th</sup> and 5<sup>th</sup> rows from the back on the 4 right columns, so it sits on a vertical 2x3 plate, and the cut corner faces the front left, and the long straight side faces the back. Vertically place the 2 back rows of a gold 2x4 left wedge plate on the 4<sup>th</sup> and 5<sup>th</sup> rows from the back on the 5<sup>th</sup> and 6<sup>th</sup> columns from the right, so the long straight side faces the left and the cut corner faces the front right.

Group 20:

80. Horizontally place a red 1x2 plate to the left of the back row of the ppp. Horizontally place a red 1x8 plate on the left of the ppp. Horizontally place another behind the ppp.

81. Horizontally place the right column of a black 2x3 plate underneath the back left corner of the seven build. Vertically place the right column of a red 2x2 right wedge plate on the leftmost column of the ppp, so the cut corner faces the front left, and the right angle faces the back right. Vertically place a red 1x2 plate to the right of the ppp.

82. Horizontally place the 2 right columns of a black 2x3 plate under the 2 left columns of the 3<sup>rd</sup> and 4<sup>th</sup> rows from the back (here, we are only counting the columns within the 2 mentioned rows). Place the right column of a red 2x2 right wedge plate on the leftmost column of the ppp, so the cut corner faces the back right and the right angle faces the front left.

Group 21:

83. Vertically place a gold 2x4 right wedge plate on the 4 back rows on the 2 left columns, so the long straight side faces the back, and the cut corner faces the front left. Place 6 gold 2x2 tiles with studs on edge 1 to the right of the other to the right of the 2 front rows of the ppp, so the studs face the back. Repeat the 6 placements symmetrically to the back, so the studs face the front. Place 2 more on the 2 back rows of your 7 build, to the right of the ppps, so the studs face the front. Then, vertically place a gold 1x2 plate to the right of the ppps on the back right corner of your seven build. You should have placed 8 2x2 tiles with studs on edge on the 2 back rows and 6 on the 3<sup>rd</sup> and 4<sup>th</sup> rows from the back, 14 in total.

84. Vertically place a gold 1x2 left wedge tile on the 5<sup>th</sup> and 6<sup>th</sup> rows from the back on the 6<sup>th</sup> column from the right, so the cut corner faces the front right. Vertically place a gold 1x2 right wedge tile on the 3<sup>rd</sup> and 4<sup>th</sup> rows from the back on the rightmost column, so the cut corner faces the front left. Place a gold 1x1 round tile with open stud to the left of the front row of the ppp. Place another behind the ppp.

85. Horizontally place the 2 right columns of a dark tan 1x4 hinge plate to the left of the ppp, so the rounded hinge part faces the front. push the 2 left columns forward, so it forms a 43 ° Angle, it attaches to a horizontal gold 2x4 right wedge plate.

86. Place a gold 1x1 round plate with open stud between the right column of the front row and the right column of the back row of the semi folded 1x4 hinge plate.

87. Orient the long stem of the Number seven so it sits vertically in front of you. Horizontally place a gold 1x2 plate on the 2 left columns of the 2<sup>nd</sup> row from the front (here, we are counting only the columns of this mentioned column). Place 10 bold 2x2 tiles with studs on edge one in front of the other behind the ppp, so the studs face the right. Repeat the 10 placements symmetrically to the right.

88. Place a dark green 2x2 right wedge plate on the 2<sup>nd</sup> and 3<sup>rd</sup> rows from the back on the 2<sup>nd</sup> and 3<sup>rd</sup> columns from the left of visible studs, so the short straight side faces the front right and the cut corner the front left. Horizontally place a dark green 2x4 tile to the right of the ppp. Place a dark green 2x2 tile with 1 stud to the right of the ppp. Horizontally place a dark green 2x4 tile to the right of the ppp. Then, horizontally place another to the right of the ppp. Now, place a gold 1x1 round plate with open stud on the stud of the 2x2 tile with 1 stud.

89. Vertically place a dark green 2x4 tile on the 3<sup>rd</sup> through 6<sup>th</sup> rows from the front, so it is centered horizontally on the long stem. Vertically place 4 more, 1 behind the other, behind the ppp. Place a dark green 2x2 right wedge tile behind the ppp, so the right angle faces the front right and the cut corner faces the back left.

Group 22:

90.1 Horizontally place the back row of a red 2x4 right wedge plate on top of your seven build on the 4 left columns of the front row, so the cut corner faces the front right and the studs face the back.

Group 23:

90.2 Horizontally place a gold 2x4 right wedge plate on top of the ppp so the edges align.

Group 24:

91. Horizontally place the back row of a black 2x4 right wedge plate underneath your seven build, so the cut corner faces the front right. Place a black 4x4 plate behind the ppp.

92. Let's make a part! Place a dark grey 4x6 plate in front of you. Vertically place a black 1x2 brick with 2 side studs on the back right corner so the side studs face the right. Horizontally place 2 grey 1x2 bricks with axle hole 1 to the left of the other, to the left of the back row of the ppp, so the axle holes face the front and the back. Vertically place the back row of a black 1x2 brick with 2 side studs to the left of the ppp, so the side studs face the left. Place the left column of a black 3x3 right corner plate in front of the ppp, so the right angle faces the back left, and 1 row overhangs to the front. Horizontally place a grey 1x2 brick with axle hole behind the 2 right columns of the ppp, with the axle hole facing the front and the back. Horizontally place another to the right of the ppp. Place a White 2x2 corner plate in front of the ppp, so it looks like a braille letter D. Vertically place a black 1x2 brick with 2 side studs to the right of the ppp, so the side studs face the right. rotate it 180 degrees, so the studs face the left. Bring back your seven build, so the long stem is vertically in front of you. Fold the 2 right overhanging columns of the black 1x4 hinge plate towards the front left. Once it is complete folded place the front overhanging row on the back row of your part on the 2<sup>nd</sup> and 3<sup>rd</sup> columns from the left.

93. Vertically place the right column of a black 2x4 left wedge plate underneath the back right overhang of your attached part, so 1 row extends to the back. Place a gold 1x1 round plate with open stud on the back row of the ppp.

94. Vertically place the front right corner of a black 2x4 left wedge plate on the ppp. So, the cut corner is on the back left and the studs face the right. Vertically place a black 1x2 plate in front of the right column of the ppp. Horizontally place a tan 2x4 plate to the left of the ppp.

95. Place a white 2x2 corner plate on top of the ppp on the 2 left columns, so it looks like a braille letter H. Place the front row of a black 3x3 corner plate to the right of the ppp, so it looks like a large braille letter J. Place a gold 1x1 round plate with open stud behind the right column of the ppp.

96. Place a dark tan semi folded 1x4 hinge plate on the 4<sup>th</sup> and 6<sup>th</sup> rows from the front, so the rounded hinge part faces the right, the back row is placed on the 2<sup>nd</sup> and 3<sup>rd</sup> columns from the right and the front row sits on a tan 2x4 plate from step 105 and the left column of the back row sits in front of a dark green vertical 2x4 tile.

97. Place a dark green 2x2 right wedge plate on the 5<sup>th</sup> and 6<sup>th</sup> rows from the front on the 2<sup>nd</sup> and 3<sup>rd</sup> columns from the left, so the cut corner faces the front right and the studs face the back, and it sits in front of the vertical 2x4 tile.

98. Vertically place 2 black 3x4 tiles with a column of 3 studs one to the right of the other on the 3 front rows. Vertically place a black 2x4 left wedge plate behind the 2 right columns of the right ppp, so the studs face the right and the cut corner faces the back left.

99. Rotate your sub build 90 degrees counterclockwise so the side studs face the front and the back. Place a black 1x1 brick upright on the rightmost column of front facing side studs. Horizontally place a black 1x3 slope brick upright to the left of the ppp, so it slopes to the left.

100. Horizontally place a black 1x2x2/3 slope tile upright on the 2 columns of front facing side studs, so it slopes to the left. Repeat symmetrically to the back.

Great work! In this bag you've started building the big number seven as its own separate piece. It's a tall, strong shape that grows layer by layer under your hands. This number seven is the one Cristiano Ronaldo proudly wears, and you'll finish the full shape in the next bag. When you're ready, open Bag 4 and keep the build moving forward.

#### Building Instructions (Bag 4, Book 2):

##### Group 25:

101. Turn your seven build upside down, so the long stem is horizontally on the front and the top short bar of the number seven faces vertically the back left. Place a black 2x2 inverted tile on the 3<sup>rd</sup> and 4<sup>th</sup> rows from the front of antistuds on the 10<sup>th</sup> and 11<sup>th</sup> columns from the right. Horizontally place a black 2x3 plate to the left of the ppp.

102. Vertically place the 1x2 plate of a transparent clear 12L bar with 1x2 plate and 1x1 round plate on one end on the same rows on the 8<sup>th</sup> column from the left of antistuds, so 8L of the bar extends to the back. Place the right column of a black 2x2 curved inverted slope tile on the 2 front rows of the ppp, so it slopes to the left. Skip 3 columns to the left and place the 1x2 plate of a transparent clear 12L bar with 1x2 plate and 1x1 round plate on one end on the 13<sup>th</sup> column from the left of antistuds, so 8L of the bar extends to the back. Place the right column of a black 2x2 curved inverted slope tile on the 2 front rows of the ppp, so it slopes to the left.

##### Group 26:

103. Let's make a sub build! Vertically place a black 1x3 plate in front of you.

104. Horizontally place a red 2x3 plate on top of the 2 back rows of the ppp, so it is centered horizontally.

105. Place a black 3x3 quarter round plate to the right of the vertical 1x3 plate, so the right angle faces the front left, and the rounded edge faces the back right, and its front left corner attaches underneath the right overhang. Repeat symmetrically to the left.

106. Place a red 2x2 plate with cut corner on the 2 back rows of the ppp on the 2 left columns, so the right angle faces the front right. Repeat symmetrically to the right.

107. Horizontally place a dark green 1x2 tile on the front row of your sub build on the 2<sup>nd</sup> and 3<sup>rd</sup> columns from the left. Repeat symmetrically to the right.

108. Vertically place the back row of a red 1x2 plate to the right of the ppp, so 1 row overhangs to the front. Horizontally place the rightmost column of a black 1x3 plate underneath the front right overhang.

109. Vertically place the back row of a red 1x2 plate on the front left corner of your sub build, so 1 row overhangs to the front. Vertically place a dark green 1x4 plate on top of your part on the 3<sup>rd</sup> through 6<sup>th</sup> rows from the back, so it is centered horizontally.

110. Vertically place the back left corner of a black 4x8 plate underneath the front overhanging row of the ppp.

111. Place the front row of a red 2x2 plate on the back row of the ppp on the 2<sup>nd</sup> and 3<sup>rd</sup> columns from the left, so the back row sits in front of the left horizontal dark green 1x2 tile. Skip 1 column to the right and place another, so 1 row overhangs to the front.

112. Place the back left corner of a black 3x3 plate underneath the front right overhang, so it attaches under the front row of the front right red 2x2 plate.

113. Vertically place a dark green 1x2 tile on top of the ppp on its back right corner. Horizontally place another to the left of the front row of the ppp. Repeat both placements symmetrically to the left.

Group 27:

114.1 Vertically place the back row of a red 1x3 plate on the 5th row from the front on the rightmost column, so 2 rows overhang to the front.

Group 28:

114.2 Horizontally place a black 1x3 plate in front of the 3x3 plate from step 125, so the right column attaches under the front right overhang, and the vertical red 1x3 plate now overhangs 1 row to the front.

115. Horizontally place a red 2x3 plate on the 4<sup>th</sup> and 5<sup>th</sup> rows from the front on the 3 left columns. Place another horizontally to the right of the ppp.

116. Orient a black 3x3 quarter round plate, so the right angle faces the back left and the rounded edge faces the front right. Place its back right corner underneath the front overhang.

117.1 Horizontally place a dark green 1x2 tile on the 3<sup>rd</sup> row from the front on the 2<sup>nd</sup> and 3<sup>rd</sup> columns from the left. Skip 1 column to the right and horizontally place another. Place a red 1x1 plate to the left of the ppp.

Group 29:

117.2 Place a dark green 1x1 plate on the same row on the leftmost column.

118. Vertically place a red 1x2 plate in front of the ppp. Place a red 2x2 plate with cut corner to the right of the ppp, so the right angle faces the back left. Place another to the right of the ppp, so the right angle faces the back right. Then, place another to the right of the ppp, so the right angle faces the back left.

119. Place a gold 2x2 corner tile with cutout on the back left corner of your sub build, so the cutout faces the back left. Place a gold 2x2 corner plate to the right and in front of the ppp, so it looks like a braille letter J. Repeat both parts symmetrically to the right. Vertically place a gold 1x2 tile on top of your sub build on the 2 back rows so it is centered horizontally.

120. Place a gold 1x1 plate on the 3<sup>rd</sup> row on the leftmost column. Place the left column of a gold 2x2 corner tile with cutout in front of the ppp, so the cutout faces the front left. Place a gold 2x2 corner plate to the right and behind the ppp, so it looks like a braille letter D. Repeat the 3 parts symmetrically to the right.

121. Place a gold 1x2 tile horizontally on the 4<sup>th</sup> row from the front on the 2 left columns. Place another horizontally behind the ppp. Vertically place another to the right of the 2 ppps. Place another horizontally to the right of the back row of the ppp. Place a gold 2x2 corner plate in front of the ppp, so it looks like a braille letter F. Place another to the right of the ppp, so it looks like a braille letter D. Horizontally place a gold 1x2 tile behind the ppp.

122. Place a gold 2x2 corner plate on the front left corner of your sub build, so it looks like a braille letter F. Place a gold 2x2 corner tile with cutout in front and to the right of the ppp, so the cutout faces the front right. Place another to the right of the ppp so the cutout faces the front left. Place another to the right of the ppp, so the cutout faces the front right. Horizontally place a gold 1x2 tile to the left of the right column of the ppp.

Group 30:

123. Rotate your part 90 degrees counterclockwise, so the sub build its horizontally in front of you. Turn it upside down so the non-rounded corner faces the front left. Vertically place a black 2x6 plate on top of your sub build on the 6 back rows on the 3<sup>rd</sup> and 4<sup>th</sup> columns from the left of antistuds. Repeat symmetrically to the right.

124. Place a black 2x2 plate with bottom pin connector on the 2 back rows of the ppp, so the pin holes of the pin connector face the front and the back. Insert a red 1L pin with stud from front to back into the front facing pin hole of the ppp, Repeat both parts symmetrically to the left.

125. Bring back your seven build, so the long stem is horizontally on the back, and the sort top bar is on the right pointing to the front. Rotate your sub build 180 degrees. Insert the 2 front facing bars of your seven build from back to front into the back facing pin holes of your sub build.

126. Locate the 2 left facing axle holes on the left horizontal long stem. Insert a red 4L axle from left to right into each back facing pin hole of your sub build, so 2L of each axle extends to the left. Turn it right side up, so the long stem is facing diagonally to the front and the top short bar is horizontally on the back.

127. Bring back your main build and place it horizontally in front of you, so the Ronaldo's signature plaque faces the front. Locate 2 2x2 round tiles with hole in the 2 back rows of your main build. Hold your part vertically upright and insert the 2 bottom protruding axles to the holes you have found. Press down to secure.

Amazing progress! In this bag you've finished building the big number seven and added the special plaque with the capital letters C and R. Then you attached the plaque to the number and placed the whole piece onto the main build, where it now stands upright on the field. When you're ready, open Bag 5 and keep the excitement going — the model is growing taller and stronger under your hands.

#### Building Instructions (Bag 5, Book 2):

##### Group 31:

128. Let's make a sub build. Horizontally place a black 2x4 plate in front of you. Place a white 1x1 brick with clip on 1 side on top of the ppp on the back right corner, so the clip faces the right.

129. Place another white 1x1 brick with clip on 1 side in front of the ppp, so the clip faces the right.

130. Place the back row of a white 2x2 corner brick to the left of the ppp, so it Looks like a braille letter J and 1 row overhangs to the front. Repeat symmetrically to the back.

131. Place the right column of a black 2x2 prick with pin hole and a half join ball in front of the left column of the ppp, so the half join ball faces to the left close to the back left corner with its pin holes facing the front and the back. Insert the back facing pin of a black rotation joint ball loop with 2 perpendicular pins from front to back into the front facing hole of the half joint ball of the ppp, so the other pinpoint to the left.

132. Horizontally place a black 2x4 plate on top of your sub build, so there's no overhang.

133. Horizontally place the left column of a dark red 1x2 plate with 1x2 upright facing side studs underneath the front right overhang, so the side studs face the front. Repeat symmetrically to the left.

134. Horizontally place the right column of a red 1x2 brick on the left column of the ppp, so 1 column overhangs to the left. Place a blue 1x1 brick on the front right corner of your sub build, so it sits on the front right 1x2 plate with 1x2 upright facing side studs.

Group 32:

135 Place a red 1x1 plate with 1x1 side stud underneath the front left corner of your sub build, so the side stud faces the front.

136. Horizontally place the left column of a dark red 1x2 plate with 1x2 upright facing side studs underneath the back right overhang, so the side studs face the back. Repeat symmetrically to the left.

137. Horizontally place the right column of a red 1x2 brick on the left column of the ppp, so 1 column overhangs to the left. Place a blue 1x1 brick on the back right corner of your sub build, so it sits on the back right 1x2 plate with 1x2 upright facing side studs.

138. Place a red 1x1 plate with 1x1 upright facing side stud underneath the back left overhang, so the side stud faces the back.

139. Place a tan 1x1 round plate on top of your sub build on the back row on the 3<sup>rd</sup> column from the right. Horizontally place a green 1x2 plate with 1x2 side studs hanging down to the right of the ppp, so the side studs face the back. Repeat both parts symmetrically to the front.

140. Horizontally place a green 1x2 plate with 1x4 side studs hanging down on top of your sub build on the front left corner, so the side studs face the front. Repeat symmetrically to the back.

141. Place a dark red 2x2 plate upright on the 2 right columns of back facing side studs So it looks like a braille letter J. place a red 1x2 plate vertically upright on the right column of the ppp. Horizontally place the 2 right columns of a red 2x4 curved left slope wedge tile upright on the 2 ppps so it slopes to the left.

142. Place a red 2x2 triangle upright on top of the 2 left columns of the ppp. Vertically place a red 1x2 tile upright to the left of the ppps.

143. Place a dark red 2x2 plate upright on the 2 right columns of front facing side studs So it looks like a braille letter J. place a red 1x2 plate vertically upright on the right column of the ppp. Horizontally place the 2 right columns of a red 2x4 curved right slope wedge tile upright on the 2 ppps so it slopes to the left.

144. Place a red 2x2 triangle upright on top of the 2 left columns of the ppp. Vertically place a red 1x2 tile upright to the left of the ppps.

Group 33:

145. Place the front row of a dark red 2x2 plate with cut corner on the 2 right columns of the back row of visible studs, so the right angle faces the front right. Repeat symmetrically to the front.

146. Horizontally place the 2 left columns of a green 2x3 plate on top of your sub build on the 2 right columns, so it is centered vertically and 1 column overhangs to the right. Horizontally place the left column of a green 1x2 curved left slope wedge tile on the front row on the rightmost column of the ppp, so it slopes to the right and 1 column overhangs to the right. Horizontally place a green 1x2 curved right slope wedge tile behind the ppp, so it slopes to the right and 1 column overhangs to the right.

147. Place a dark red 2x2 corner plate on top of your sub build on the 2 back rows on the 2<sup>nd</sup> and 3<sup>rd</sup> columns from the left, so it resembles a braille letter J. Repeat symmetrically to the front.

148. Horizontally place a black 2x4 plate on top of your sub build on the 2<sup>nd</sup> through 5<sup>th</sup> columns from the left, so it is centered vertically, and it sits on the 2 ppps and on the horizontal green 2x4 plate. Place a tan 1x1 round plate in front of the rightmost column of the ppp. Repeat symmetrically to the back.

149.1 Place the back right corner of a red 2x2x2/3 curved left slope wedge tile on the ppp, so it slopes to the left.

Group 34:

149.2. Place a red 2x2x2/3 curved right slope wedge tile with gold number 7 pattern symmetrically to the back.

150. Vertically place a red 1x2 tile in front of the left column of the ppp. Horizontally place the left column of a red 1x2 left wedge tile to the right of the front row of the ppp, so the cut corner faces the back right. Repeat symmetrically to the back using a red 1x2 right wedge tile.

151. Vertically place a red 1x2 curved left slope wedge tile on top of your sub build on the 2 front rows on the 3<sup>rd</sup> column from the left, so it slopes to the front. Place a red 1x2 curved right slope wedge tile symmetrically to the back.

152. Vertically place the 2 right columns of a red 3x4 stepped wedge tile on top of your sub build on the 2 left columns of visible studs, so it steps down to the left and it is centered vertically.

Group 35:

153. Let's make a sub build. Place a red 2x2 plate with 1x2 side studs in front of you, so the side studs face the right. Vertically place the 2 back rows of a red 1x6 plate on the left column of the ppp, so 4 rows overhang to the front.

154. Place the left column of a red 2x2 plate with 1x2 side studs underneath the 2 front rows of your sub build, so the side studs face the right.

155. Rotate your sub build 90 degrees clockwise. Horizontally place a black 1x2 rounded brick with open studs and open center with bars. On top of your sub build on the back row, so it is centered horizontally.

156. Place the back row of a red 2x2 brick with ball socket and axle hole to the right of the ppp, so the socket faces the right. Repeat symmetrically to the left.

157. Place a red 2x2 plate with 1x2 side studs on top of the ppp, so the side studs face the front. Repeat symmetrically to the right.

158. Vertically place a medium nougat 1x2 plate with bar handle on a sort side on the back row on the 3<sup>rd</sup> column from the left, so the bar handle faces the front and 1 row overhangs to the front. Repeat symmetrically to the right. Horizontally place a red 1x2 plate on top of the ppps on their front row. Horizontally place a red 1x6 plate on the back row of your sub build, so there's no overhang.

159. Place a green 2x2 corner plate on top of your sub build on the 2<sup>nd</sup> and 3<sup>rd</sup> columns from the left, so it looks like a braille letter F. Repeat symmetrically to the right, so it resembles a braille letter D.

160. Place the back row of a green 2x2 tile with studs on edge on the front row of your sub build, so it is centered horizontally and 1 row overhangs to the front above the bar handles.

Group 36:

161.1 Vertically place a red 1x4 plate in front of you. Place the left column of 2 red 2x3 tiles one in front of the other on the ppp, so 2 columns overhang to the right.

161.2 Vertically place the 2 left columns of a dark red 4x6 plate with 2 cut corners underneath the right overhang, so the cut corners are on the back left and front left, and 2 columns are exposed to the right.

161.3 Horizontally place the 2 back rows of a red 4x6 curved slope tile with 2 cut corners and studs on edge printed with a gold number 7 pattern on the 2 right columns of the ppp, so the studs face the right and the cut corners face the back left and front left.

161.4 Vertically place a green 1x2 right wedge tile on the 2 front rows of the right column of the ppp, so the cut corner faces the front left. Place a green 1x2 left wedge tile symmetrically to the back.

161.5 Bring back your sub build and position it horizontally in front of you, so the bar handles face the front. Rotate your part 90 degrees clockwise. Vertically place the 2 front rows of your part on top of the 2 back rows of your sub build so 6 rows overhang to the back.

162. Turn your sub build upside down so the bar handles face the front. Horizontally place a red 1x2 plate on the 2<sup>nd</sup> row from the front on the 2 left columns of antistuds. Place the back row of a red 2x2 inverted curved slope tile on the ppp, so it slopes to the front. Repeat both parts symmetrically to the right.

Group 37:

163. Let's make a part! Vertically place a red 1x2 plate in front of you. Place a red 2x2 plate with cut corner to the left of the ppp, so the right angle faces the back left. place the front row of a red 2x2 curved slope tile on the back row of the 2 ppps, so 1 column of the 2x2 plate with cut corner remains exposed, and it slopes to the back. Vertically place a red 1x2 curved left slope wedge tile to the left of the ppp, so it slopes to the back. Place the back row of a red 1x2 curved right slope wedge tile on the front row of your part, so it slopes to the front and 1 row extends to the front. Vertically place a red 1x2 curved slope tile to the right of the ppp, so it slopes to the front. Bring back your sub build and turn it right side up, so the bar handles face the front. Rotate your part 180 degrees, then vertically place it on the front right facing side studs, so there is no overhang.

164. Let's make a part! Vertically place a red 1x2 plate in front of you. Place a red 2x2 plate with cut corner to the right of the ppp, so the right angle faces the back right. place the front row of a red 2x2 curved slope tile on the back row of the 2 ppps, so 1 column of the 2x2 plate with cut corner remains exposed, and it slopes to the back. Vertically place a red 1x2 curved right slope wedge tile to the right of the ppp, so it slopes to the back. Place the back row of a red 1x2 curved left slope wedge tile on the right column of the front row of your part (here we are counting only the columns within this mentioned row), so it slopes to the front and 1 row extends to the front. Vertically place a red 1x2 curved slope tile to the left of the ppp, so it slopes to the front. Bring back your sub build and position it vertically, so the bar handles face the front. Rotate your part 180 degrees, then vertically place it on the front left facing side studs, so there is no overhang.

165. Turn your sub build upside down, so the bar handles face the front. Bring back your previous sub build and position it vertically in front of you, so the pin faces the back, and the clips face the front. Place it on the 6 back rows of your upside down build, then, push it forward, so the front facing clips clip to the bars of the horizontal 1x2 rounded brick with open studs and open center with bars.

What a brilliant move on the pitch! In Bag 5 you've built Cristiano Ronaldo's torso — the bright red Portugal team shirt with the number seven shining proudly on the front. This is the heart of the uniform, the part every fan recognizes, and you've shaped it with perfect control. The torso is now complete and ready to join the rest of the figure in the next plays. When you're ready, open Bag 6 and keep the match alive — the build is getting more exciting with every step!

#### Building Instructions (Bag 6, Book 2):

##### Group 38:

166. Let's build the first arm shoulder! Place a red 1x2 brick with pin hole and dual lift arm extensions in front of you, so the pin hole faces the right and the left and the axle holes of the dual liftarm extensions face the front and the back and the liftarms face the left.

167. Align the axle holes of a black ball joint with through axle hole with the inner facing axle holes of the dual liftarm extensions. Insert a red 2L axle from front to back into the front facing axle hole of the front liftarm extensions. Push it towards the back, so it is fully inserted.

168. Place the right column of a red 2x2 inverted tile underneath the left column of the ppp, so 1 column extends to the left.

169. Vertically place a red 1x2 brick with pin hole on the left column of the ppp, so the pin hole faces the right and the left.

170. Place a blue 1x1 plate with 1x2 side studs hanging down on the front row of the ppp, so the side studs face the front. Repeat symmetrically to the back. Place a red 1x1 plate to the right of the back row of the ppp.

171. Place the back left corner of a red 2x2x2/3 curved right slope wedge tile on the ppp, so it slopes to the right. Vertically place a dark blue 1x2 tile printed with the letter C in white.

##### Group 39:

172. Vertically place a dark blue 1x2 tile upright on the front facing side studs. Repeat symmetrically to the back.

173. Insert a blue 3L pin from left to right into the left facing pin hole, so 1L of the pin extends to the left.

##### Group 40:

174. Let's make the first arm build. Place a red 2x2 plate with cut corner in front of you, so the right angle faces the back right. Place the left column of a red 1x2 brick with pin hole and 1x2 plate on the right column of the ppp, so the pin hole faces the right.

175. Vertically place a red 1x2 plate on the right column of the ppp.

176. Horizontally place the rightmost column of a red 2x4 left wedge plate on top of your part on the leftmost column, so the long straight side faces the back, and the cut corner faces the front left.

177. Place the left column of a red 2x2 plate with cut corner on the rightmost column of the ppp, so the right angle faces the back right.

178. Place a red 2x2 curved slope tile on top of your part on the 2 right columns, so it slopes to the left. Horizontally place a red 1x3 curved slope tile to the left of the back row of the ppp, so it slopes to the left.

##### Group 41:

179. Place the right column of a nougat 2x2 plate with cut corner underneath the leftmost column of your part, so the right angle faces the back left. Vertically place a nougat 1x2 plate with bar handle on 1 large side on the leftmost column of the ppp, so the bar handle faces the left.

180. Horizontally place the left column of a nougat 1x2 rounded plate on the back row of the ppp. Place a nougat 1x1 round plate with horizontal bar in front of the left column of the ppp so the bar points to the front.

181. Clip 3 nougat bar holders with clip on the bar handle. They are the fingers.

182. Turn your arm build upside down, so the fingers face the left. Place a red 2x2 inverted tile on top of your arm build on the 2 right columns. Horizontally place a red 1x2 inverted curved slope tile to the left of the front row of the ppp, so it slopes to the left. Place a red 1x1 plate to the left of the ppp.

183. Flip it, so it sits on the back side and the antistuds face the front and the bar of the 1x1 round plate with horizontal bar faces up. Bring back your arm shoulder build from step 173 and insert its left facing pin from right to left into the right facing pin hole of your arm build.

184. Bring back your torso build and place it vertically in front of you, so the stepped wedge plate faces up, stepping down to the front and the pin faces the front. Attach the tow ball of your arm build to the right socket.

Group 42:

185. Let's build the second arm shoulder! Place a red 1x2 brick with pin hole and dual lift arm extensions in front of you, so the pin hole faces the right and the left and the axle holes of the dual liftarm extensions face the front and the back and the liftarms face the right.

186. Align the axle holes of a black ball joint with through axle hole with the inner facing axle holes of the dual liftarm extensions. Insert a red 2L axle from front to back into the front facing axle hole of the front liftarm extensions. Push it towards the back, so it is fully inserted.

187. Place the right column of a red 2x2 inverted tile underneath the left column of the ppp, so 1 column extends to the left.

188. Vertically place a red 1x2 brick with pin hole on the left column of the ppp, so the pin hole faces the right and the left.

189. Rotate Your arm shoulder build 90 Degrees counterclockwise, so the tow ball faces the back, and the pin hole faces the front. Place a red 2x2 corner plate on top of your arm shoulder build on the 2 front rows, so it looks like a braille letter J.

190. Horizontally place a red 1x2 tile on top of your arm shoulder build on the front row. Place a red 2x2x2/3 curved left slope wedge tile behind the ppp, so it slopes to the back.

191. Insert a blue 3L pin from to back into the front facing pin hole, so 1L of the pin extends to the front.

192. Let's build the 2<sup>nd</sup> arm! Place a red 1x2 brick with pin hole and 1x2 plate in front of you, so the pin hole faces the left, and the plate faces the right. Place the left column of a red 2x2 plate with cut corner underneath the 1x2 plate of the ppp, so the right angle faces the back left.

Group 43:

193. Vertically place a red 1x2 plate on top of the of your arm build on the leftmost column.

194. Horizontally place a red 2x4 right wedge plate on the rightmost column of your arm build, so the long straight edge faces the back, and the cut corner faces the front right.

195 Place a red 2x2 plate with cut corner on top of your arm build on the 2nd and 3<sup>rd</sup> columns from the left, so the right angle faces the back left.

196. Place a red 2x2 curved slope tile on top of your arm build on the 2 left columns, so it slope to the right. Place a red 1x3 curved slope tile to the right of the back row of the ppp, so it slopes to the right.

Group 44:

197. Place the left column of a nougat 2x2 plate with cut corner underneath the rightmost column of the arm build, so the right angle faces the back left and 1 row extends to the front and 1 column to the right. Vertically place a nougat 1x2 plate with bar handle on 1 large side on the rightmost column of the ppp, so the bar handle faces the right.

198. Horizontally place the right column of a nougat 1x2 rounded plate on the back row of the ppp. Place a nougat 1x1 round plate with horizontal bar in front of the right column of the ppp so the bar points to the front.

199. Clip 3 nougat bar holders with clip on the bar handle. They are the fingers.

200. Turn your sub build upside down, so the fingers face the right. Place a red 2x2 inverted tile on top of your arm build on the 2 left columns. Horizontally place a red 1x2 curved slope tile to the right of the front row of the ppp, so it slopes to the right. Place a red 1x1 plate on the right side of the ppp. Flip it, so it sits on its back side and the antistuds face the front.

201. Bring back your arm shoulder build from step 191 and insert its right facing pin from left to right into the left facing pin hole of your arm build.

202. Bring back your torso build, so the pin faces the front and the arm you have attached is on the right. Attach the tow ball of your arm build to the left facing socket.

Another fantastic play! In Bag 6 you've built Cristiano Ronaldo's arms and hands — the parts that bring all his power, balance, and signature celebrations to life. Both arms can move, and each hand has poseable fingers you can adjust, just like a real player getting ready for the perfect pass or goal celebration. With the arms complete, your figure is almost ready to take the field. When you're ready, open Bag 7 and keep the match going strong.

Building Instructions (Bag 7, Book 2):

Group45:

203. Let's start building the first leg! Horizontally place a red 1x12 plate horizontally in front of you. Horizontally place a red 1x2 plate with socket on top of the ppp on the 2 left columns, so the socket faces the left.

204. Horizontally place a red 1x2 plate to the right of the ppp.

205. Place a white 1x1x2/3 short brick to the right of the ppp. Horizontally place a red 1x4 plate to the left of the ppp.

206. Horizontally place a red 1x3 tile on the 3 left columns of the ppp. Horizontally place a red 1x2 plate to the right of the ppp.

207. Horizontally place a red 1x2 brick with 2 side studs on each large side to the right of the ppp, so the side studs face the front and the back. Place 2 nougat 1x1 brick with a side stud on

2 sides 1 to the right of the other to the right of the ppp, so the side stud faces the front and the back.

208. Place the left column of a green 2x2 curved inverted slope brick underneath the rightmost column of your sub build, so it slopes upward to the front. Place a green 1x1 round plate on the back right corner of the ppp.

209. Horizontally place a green 2x2 curved inverted slope brick to the left of the previous one, so it slopes upward to the front.

210. Place a nougat 1x1 plate to the left of the ppp underneath your leg build. Horizontally place the right column of a medium nougat 1x2 curved inverted slope tile on the ppp.

Group 46:

211. Let's make the twin. Horizontally place a red 1x2 curved inverted slope tile in front of you, so it slopes upward to the left. Horizontally place the left column of a nougat 1x2 plate on the right column of the ppp, so 1 column overhangs to the right. Horizontally place the left column of a red 1x2 curved inverted slope tile underneath the right overhang. Bring back your leg build so the antistuds face the front and the socket face the left. Horizontally place it upright on the 4<sup>th</sup> through 7<sup>th</sup> columns from the left of front facing antistuds of your leg build.

212. Flip your leg build, so the antistuds face down. Horizontally place a green 2x3 plate on top of your leg build on the 2<sup>nd</sup> through 4<sup>th</sup> columns from the right.

213. Place a white 1x1 brick on the back left corner of the ppp.

214. Place the left column of a green 2x2 corner plate on top of your leg build on the rightmost column, so it looks like a braille letter F, and 1 column overhangs to the right. Place a red 1x1 plate with 1x1 upright facing side stud underneath the right overhanging column, so the side stud faces the front.

215. Place a grey 1x1 brick with 1 side stud on top of your leg build on the back row on the 2<sup>nd</sup> column from the right, so the side stud faces the back. Horizontally place a black 1x2 brick with 2 side studs on a large side to the left of the ppp, so the side studs face the back. Horizontally place a medium nougat 1x4 plate to the left of the ppp.

Group 47:

216.1 Horizontally place the left column of a green 1x2 plate on the back row on the rightmost column of your leg build, so 1 column overhangs to the right.

Group 48:

216.2 Horizontally place a red 1x2 plate on top of the ppp. Horizontally place a green 1x2 plate with 1x2 side studs hanging down on the ppp, so the side studs face the front.

217. Horizontally place a green 1x4 brick on top of your leg build on the 4 right columns of the front row (here, we are counting only the columns within this mentioned row).

218. Place the back row of a green 2x2 plate on the 2 right columns of front facing side studs, so the bottom right corner overhangs. Vertically place a green 1x2 tile upright on the left column of the ppp. Place a green 2x2 curved slope tile upright to the right of the ppp, so it slopes to the right.

Group 49:

219. Horizontally place the front row of a green 2x4 right wedge plate on top of your sub build on the back row on the 2<sup>nd</sup> through 5<sup>th</sup> columns from the right, So the long straight edge faces the front and the cut corner faces the back right and 1 row overhangs to the back.

220. Place a green 2x2 plate with 1x2 side studs upright on the 5<sup>th</sup> and 6<sup>th</sup> columns from the left of back facing side studs, so the 1x2 side studs face down and it attaches by the top row. Vertically place a green 1x2 plate upright to the right of the ppp. Vertically place a green 1x2 tile on the 5<sup>th</sup> columns of back facing antistuds from the left. Horizontally place a green 2x4 slope tile upright to the right of the ppp, so it slopes to the right.

221. Flip your part, so the ppps are on top. Vertically place the top row of a green 1x2 curved slope tile upright on the left back facing side stud, so it slopes upward. Place a green 2x2 curved slope tile upright to the right of the ppp, so it slopes upward.

222. Horizontally place a green 1x2 curved inverted slope tile upright to the right of the bottom row of the ppp, so it slopes to the right.

223.1 Flip your part so the studs face up and the socket faces the left. Vertically place a green 1x2 curved right slope wedge tile on top of your leg build on the 2<sup>nd</sup> column from the right, so it slopes to the front. Place a green 2x2 curved slope tile to the left of the ppp, so it slopes to the front.

Group 50:

223.2 Place a green 2x2 curved slope tile with a gold number 7 pattern to the left of the ppp, so it slopes to the front. Horizontally place a green 1x2 left wedge tile behind the ppp, so the cut corner faces the back right.

224. Horizontally place a nougat 1x2 plate on top of your leg build on the 4<sup>th</sup> and 5<sup>th</sup> columns from the left of visible studs.

225. Place a red 1x1 plate to the left of the ppp.

226. Horizontally place a red 1x4 curved slope tile on top of your sub build on the 4 left columns of visible studs, so it slopes to the left. Horizontally place a nougat 1x2 curved slope tile to the right of the ppp, so it slopes to the right.

Group 51:

227. Place a nougat 1x1 plate upright on the rightmost column of front facing side studs. Place the left column and the back row of a medium nougat 2x2 curved corner plate with 1x1 cutout upright to the left of the ppp, so it resembles a braille letter E.

228. Vertically place the front row of a nougat 1x2 curved straight slope wedge tile upright on the top row on the left column of the ppp, so it slopes upward. Vertically place a nougat 1x2 curved left slope wedge tile to the right of the ppp, so it slopes upward.

229. Horizontally place the 2 right columns of a red 1x4 plate upright on the 2 columns of front facing side studs. Vertically place the front row of a red 1x2 curved slope tile upright on the rightmost column of the ppp, so it slopes upward. Place the back row of a red 2x2 curved slope tile upright to the left of the bottom row of the ppp, so it slopes downward. Place a red 2x2x2/3 curved corner slope tile to the left of the ppp, so the curved corner faces the bottom left.

230. Place a nougat 1x1 plate upright on the rightmost column of back facing side studs. Place the left column and the back row of a nougat 2x2 round corner plate with 1x1 cutout upright to the left of the ppp, so the right rounded edge faces the bottom left and it resembles a braille letter E.

231. Vertically place the front row of a nougat 1x2 curved left slope wedge tile upright on the top row of the ppp, so it slopes upward. Vertically place a nougat 1x2 curved right slope wedge tile upright to the right of the ppp, so its lopes upward and it sits on the back facing nougat 1x1 plate from the previous step.

232. Horizontally place the 2 right columns of a red 1x4 plate upright on the 2 columns of back facing side studs. Vertically place the front row of a red 1x2 curved slope tile upright on the rightmost column of the ppp, so it slopes upward. Place the back row of a red 2x2 curved slope tile upright to the left of the front row of the ppp, so it slopes downward. Place a red 2x2x2/3 curved corner slope tile to the left of the ppp, so the curved corner faces the bottom left.

233.1 Let's make a part! Place a green 2x2 curved inverted slope tile in front of you, so it slopes upward to the right. Place another symmetrically to the left. Horizontally place a green 1x2 plate on top of the ppps on the back row, so it is centered horizontally and connects them.

233.2 Place the back row of a green 2x2 curved inverted slope brick in front of the ppp, so it slopes upward to the front.

233.3 Horizontally place a black 1x4 rounded plate on top of your part on the 2<sup>nd</sup> row from the front. Horizontally place a green 1x2 plate on top of your part on the back row, so it is centered horizontally.

233.4 Vertically place a green 2x3 plate on top of your part, so it is centered vertically. Place a green 1x1 round plate on the 2<sup>nd</sup> row from the front on the rightmost column. Repeat symmetrically to the left.

233.5 Horizontally place a dark green 1x2x1 1/3 brick with joint socket on top of your part on the back row, so it is centered horizontally, and the side with relief faces the back.

233.6 Horizontally place a black 1x4 rounded plate on top of your part, so it is centered vertically. Horizontally place a green 1x2 plate on top of your part on the front row, so there's no overhang.

233.7 Place 2 green 1x1 bricks 1 to the right of the other on the front row. Horizontally place a green 1x2 plate on top of the ppps. Horizontally place a grey 1x2 half round brick behind the ppp, so the rounded side faces the back.

233.8 Bring Back your leg build and place it horizontally in front of you, so the socket faces the left and the antistuds face down. rotate your part 90 degrees clockwise so the joint socket faces the right. Then, place the 2nd column from the right of the front row of your part underneath the right overhang of your part.

Group 52:

234. Let's start building the 2<sup>nd</sup> leg! Horizontally place a red 1x12 plate horizontally in front of you. Horizontally place a red 1x2 plate with socket on top of the ppp on the 2 right columns, so the socket faces the right.

235. Horizontally place a red 1x2 plate to the left of the ppp.

236. Place a white 1x1x2/3 short brick to the left of the ppp. Horizontally place a red 1x4 plate to the right of the ppp.

237. Horizontally place a red 1x3 tile on the 3 right columns of the ppp. Horizontally place a red 1x2 plate to the right of the ppp.

238. Horizontally place a red 1x2 brick with 2 side studs on each large side to the left of the ppp, so the side studs face the front and the back. Place 2 nougat 1x1 bricks with a side stud on 2 sides 1 to the left of the other to the left of the ppp, so the side studs face the front and the back.

239. Place the right column of a green 2x2 curved inverted slope brick underneath the leftmost column of your sub build, so it slopes upward to the front. Place a green 1x1 round plate on the back left corner of t ppp.

240. Horizontally place a green 2x2 curved inverted slope brick to the right of the previous one, so it slopes upward to the front.

241. Place a nougat 1x1 plate to the right of the ppp underneath your 2<sup>nd</sup> leg build. Horizontally place the left column of a medium nougat 1x2 curved inverted slope tile on the ppp.

#### Group 53:

242. Let's make the twin. Horizontally place a red 1x2 curved inverted slope tile in front of you, so it slopes upward to the left. Horizontally place the left column of a nougat 1x2 plate on the right column of the ppp, so 1 column overhangs to the right. Horizontally place the left column of a red 1x2 curved inverted slope tile underneath the right overhang. Bring back your 2<sup>nd</sup> leg build so the antistuds face the front and the socket face the right. Horizontally place it upright on the 4<sup>th</sup> through 7<sup>th</sup> columns from the right of front facing antistuds of your second leg build.

243. Flip your 2<sup>nd</sup> leg build, so the antistuds face down. Horizontally place a green 2x3 plate on top of your leg build on the 2<sup>nd</sup> through 4<sup>th</sup> columns from the left.

244. Place a white 1x1 brick on the back right corner of the ppp.

245. Place the right column of a green 2x2 corner plate on top of your leg build on the leftmost column, so it looks like a braille letter D, and 1 column overhangs to the left. Place a red 1x1 plate with 1x1 upright facing side stud underneath the left overhanging column, so the side stud faces the front.

246. Place a grey 1x1 brick with 1 side stud on top of your 2<sup>nd</sup> leg build on the back row on the 2<sup>nd</sup> column from the left, so the side stud faces the back. Horizontally place a black 1x2 brick with 2 side studs on a large side to the right of the ppp, so the side studs face the back. Horizontally place a medium nougat 1x4 plate to the right of the ppp.

#### Group 54:

247.1 Horizontally place the right column of a green 1x2 plate on the back row on the leftmost column of your 2<sup>nd</sup> leg build, so 1 column overhangs to the left.

#### Group 55:

247.2 Horizontally place a red 1x2 plate on top of the ppp. Horizontally place a green 1x2 plate with 1x2 side studs hanging down on the ppp, so the side studs face the front.

248. Horizontally place a green 1x4 brick on top of your 2<sup>nd</sup> leg build on the 4 left columns of the front row (here, we are counting only the columns within this mentioned row).

249. Place the back row of a green 2x2 plate on the front facing side studs, so 1 row overhangs to the bottom. Vertically place a green 1x2 tile upright on the right column of the ppp. Place a green 2x2 curved slope tile upright to the left of the ppp, so it slopes to the left.

#### Group 56:

250. Horizontally place the front row of a green 2x4 left wedge plate on top of your sub build on the back row on the 2<sup>nd</sup> through 5<sup>th</sup> columns from the left, So the long straight edge faces the front and the cut corner faces the back left and 1 row overhangs to the back.

251. Place a green 2x2 plate with 1x2 side studs upright on the 5<sup>th</sup> and 6<sup>th</sup> columns from the right of back facing side studs, so the 1x2 side studs face down and it attaches by the top row. Vertically place a green 1x2 plate upright to the left of the ppp. Vertically place a green 1x2 tile on the 5<sup>th</sup> column of back facing antistuds from the right. Horizontally place a green 2x4 slope tile upright to the left of the ppp, so it slopes to the left.

252. Flip your part, so the ppps are on top. Vertically place the top row of a green 1x2 curved slope tile upright on the right back facing side stud, so it slopes upward. Place a green 2x2 curved slope tile upright to the left of the ppp, so it slopes upward.

253. Horizontally place a green 1x2 curved inverted slope tile upright to the left of the bottom row of the ppp, so it slopes to the left.

254. Flip your part so the studs face up and the socket faces the right. Vertically place a green 1x2 curved right slope wedge tile on top of your 2<sup>nd</sup> leg build on the 2<sup>nd</sup> column from the left, so it slopes to the front. Place a green 2x2 curved slope tile to the right of the ppp, so it slopes to the front. Place another to the right of the ppp, so it slopes to the front. Horizontally place a green 1x2 right wedge tile behind the ppp, so the cut corner faces the back left.

#### Group 57:

255. Horizontally place a nougat 1x2 plate on top of your 2<sup>nd</sup> leg build on the 4<sup>th</sup> and 5<sup>th</sup> columns from the right of visible studs.

256. Place a red 1x1 plate to the left of the ppp.

257. Horizontally place a red 1x4 curved slope tile on top of your sub build on the 4 right columns of visible studs, so it slopes to the right. Horizontally place a nougat 1x2 curved slope tile to the left of the ppp, so it slopes to the left.

#### Group 58:

258. Place a nougat 1x1 plate upright on the leftmost column of front facing side studs. Place the right column and the back row of a medium nougat 2x2 curved corner plate with 1x1 cutout upright to the right of the ppp, so it resembles a braille letter I.

259. Vertically place the front row of a nougat 1x2 curved left slope wedge tile upright on the top row on the right column of the ppp, so it slopes upward. Vertically place a nougat 1x2 curved right slope wedge tile upright to the left of the ppp, so it slopes upward.

260. Horizontally place the 2 left columns of a red 1x4 plate upright on the 2 columns of back facing side studs. Vertically place the front row of a red 1x2 curved slope tile upright on the leftmost column of the ppp, so it slopes upward. Place the back row of a red 2x2 curved slope tile upright to the right of the front row of the ppp, so it slopes downward. Place a red 2x2x2/3 curved corner slope tile to the left of the ppp, so the curved corner faces the bottom left.

261. Place a nougat 1x1 plate upright on the leftmost column of back facing side studs. Place the left column and the back row of a nougat 2x2 round corner plate with 1x1 cutout upright to the right of the ppp, so the rounded edge faces the bottom left and it resembles a braille letter I.

262. Vertically place the front row of a nougat 1x2 curved left slope wedge tile upright on the top row of the ppp, so it slopes upward. Vertically place a nougat 1x2 curved right slope wedge tile upright to the left of the ppp, so its lopes upward and it sits on the back facing nougat 1x1 plate from the previous step.

263. Horizontally place the 2 left columns of a red 1x4 plate upright on the 2 columns of front facing side studs. Vertically place the front row of a red 1x2 curved slope tile upright on the leftmost column of the ppp, so it slopes upward. Place the back row of a red 2x2 curved slope tile upright to the right of the front row of the ppp, so it slopes downward. Place a red 2x2x2/3 curved corner slope tile to the right of the ppp, so the curved corner faces the bottom left.

Group 59:

264. Rotate your second leg build 180 degrees so the socket faces the left. Bring back your first leg build from step 33 and position it horizontally in front of you, so the socket faces the left and the 1x2 brick with rotation joint socket faces the right. place the 2<sup>nd</sup> column from the right of the back row of your first leg underneath the right overhanging column of your 2<sup>nd</sup> leg build.

265. Vertically place a black 1x4 rounded plate on top of your legs build on the 2<sup>nd</sup> column from the right securing the previous step.

266. Rotate your legs build 90 degrees clockwise, so the joint ball socket faces the front and the legs point to the back. Horizontally place the right column of a dark red 1x2 plate with 1x2 upright facing side studs, on top of your legs build on the front row on the leftmost column, so the side studs face the front. Horizontally place a red 1x2 ingot tile upright on the front facing side studs. Repeat both parts symmetrically to the right.

267. Vertically place a green 2x3 plate on top of your legs build on the 3 front rows, so it is centered horizontally.

268. Horizontally place a red 1x4 curved double slope tile on top of your legs build on the front row. Horizontally place a green 1x2 curved left slope wedge tile behind the 2 right columns of the ppp, so it slopes to the right. Horizontally place a green 1x2 curved right slope wedge tile to the left of the ppp, so it slopes to the left.

269. Bring back your torso build and position it vertically in front of you, so the pin faces the back. Insert the back rotating pin from front to back into the front facing joint socket. You need to angle the rotating pin, so that the torso gets inserted as Cristiano Ronaldo is leaning back with his chest pushed forward in his celebration pose.

270. Locate a left facing stud on the torso close to the insertion into the legs. Place a red 2x2 triangular tile upright on this left facing side stud you found, so it's right angle faces the top front. Repeat symmetrically to the right.

Great work! In this bag you've built both strong legs and connected them securely to the torso. The figure is starting to take shape under your hands, standing taller and feeling more like a real athlete ready to move. The boots will come later, so for now enjoy how solid and balanced the build feels. When you're ready, open Bag 8 and keep the momentum going — you're getting closer to bringing Cristiano to life.

Building Instructions (Bag 8, Book 2):

Group 60:

271. Let's start building the head! Horizontally place a medium nougat 2x5 stair plate in front of you, so the stairs lead down to the left. Horizontally place a nougat 1x2 slope tile on the back right corner of the ppp, so it slopes to the back.

272. Repeat symmetrically to the front.

273. Stack 2 nougat 1x2 plates, then vertically place the stack to the left of the 2 ppps.

274. Place a white 1x1 2/3 short brick with 2 side studs to the left of the front row of the stack, so the side studs face the front. Repeat symmetrically to the back. Vertically place a grey 1x2x1 2/3 with studs on 3 sides to the left of the ppps, so the 2x2 side studs face the left.

275. Stack a nougat 1x2 plate on a medium 1x2 plate with 2 clips on a large side. Vertically place your stack underneath the 2nd column from the right of your sub build, so the clips face the right.

276. Turn your sub build upside down, so the clips face the right. Horizontally place 2 medium nougat 1x2 curved inverted slope tiles one in front of the other on the 2nd and 3rd columns from the right of antistuds, so they slope to the right and they sit on the vertical 1x2 plate with 2 right facing clips and on the 2x5 stair plate.

277.1 Place a grey 2x2 plate to the left of the ppps.

Group 61:

277.2 Place a dark brown 2x2 plate on the ppp.

278. Place a dark brown 2x2 plate with 1x2 side studs upright on the left facing side studs, so its 1x2 side studs face down. Place the left column of a dark brown 1x2 plate with 3 spikes on the top column of left facing side studs, so the spikes point upward.

279. Place a dark brown 2x2 triangular tile upright on the left facing side studs so the right angle faces the bottom front.

280. Turn your sub build right side up, so the clips face the right. Horizontally place a dark brown 2x4 plate on top of your sub build, so there's no overhang. 2 dark brown 1x1 slope tiles 1 in front of the other on the leftmost column of the ppp, so they slope to the right.

281. Vertically place a dark brown 1x2 plate upright on the left column of front facing side studs. Place a nougat 1x1 plate upright to the right of the top row of the ppp.

282. Vertically place the back row of a dark brown 1x2 plate on the front facing stud below the ppp.

283. Horizontally place a dark brown 1x2 curved slope tile on top of the ppp, so it slopes to the right. Horizontally place a dark brown 1x2 curved right slope wedge tile below the ppp, so it slopes to the right.

284. Place a dark brown 2x2x2/3 curved left wedge slope tile upright to the left of the ppp, so it slopes to the left and it attaches only by the back right corner to the sub build.

285. Place a nougat 1x1 quarter round tile upright on the right front facing side stud, so the right angle faces the bottom left and the rounded edge faces the top right. Horizontally place a dark brown 1x2 curved right slope wedge tile upright to the left of the ppp, so it slopes to the left.

Group 62:

286. Vertically place a dark brown 1x2 plate upright on the left column of back facing side studs. Place a nougat 1x1 plate upright to the right of the top row of the ppp.

287. Vertically place the back row of a dark brown 1x2 plate on the back facing stud below the ppp.

288. Horizontally place a dark brown 1x2 curved slope tile upright on top of the ppp, so it slopes to the right. Horizontally place a dark brown 1x2 curved right slope wedge tile upright below the ppp, so it slopes to the right.

289. Place a dark brown 2x2x2/3 curved left wedge slope tile upright to the left of the ppp, so it slopes to the left and it attaches only by the back right corner to the sub build.

290. Place a nougat 1x1 quarter round tile upright on the back right facing side stud, so the right angle faces the bottom left and the rounded edge faces the top right. Horizontally place a dark brown 1x2 curved right slope wedge tile upright to the left of the ppp, so it slopes to the left.

291. Horizontally place a nougat 4x4x2 large, molded face with Cristiano Ronaldo pattern on top of your head build.

292. Bring back your Cristiano Ronaldo body build so it faces the left. Hold your head vertically upright, so the face faces the left and the clips are on the bottom right. Clip the bottom clips to the top facing bars of the body.

Group 63:

293. Let's build the first shoe! Horizontally place a medium blue 1x2 plate with 2x2 side studs in front of you, so the side studs face the back. Horizontally place a black 1x2 plate with a tow ball on each short side on top of the ppp.

294. Horizontally place a blue 1x2 plate on top of the ppp.

295. Horizontally place the 2 right columns of a white 1x3 rounded plate on the ppp, so 1 column overhangs to the left. Horizontally place a blue 1x2 plate with 2x2 side studs hanging down on top of your part on the 2 right columns, so the side studs face the front.

296. Place a medium blue 1x1 plate with 1x2 upright facing side studs on the right column of the ppp, so the side studs face the back. Horizontally place a white 1x2 curved slope tile to the left of the ppp, so it slopes to the left.

297. Place a medium blue 1x1 brick with pin hole to the right of the ppp, so the pin holes face the right and the left. Place a blue 1x1 plate with 1x2 side studs hanging down on the ppp, so the side studs face the front.

298. Place a white 1x1 half round tile on the top row of back facing side studs. Vertically place a gold 1x2 half round tile with stud upright on the 2 bottom rows of back facing side studs on the left column, so the rounded edge faces the right. place a white 2x2 tile with 2 1x1 curved cutouts upright to the right and to the top of the ppp.

299. Repeat the 3 parts symmetrically to the front.

300. Flip your shoe build, so the tow ball on the same side of the 1x2 curved slope tile faces up on the right. Place a white 2x1 triple slope tile with inside stud holder upright on the left facing side stud, so the flat side faces down. Horizontally place.

301. Place a gold 1x1 round plate with open stud on the bottom right facing antistud. Place a blue 1x2 curved inverted slope tile vertically upright on the 2 right facing antistuds, so it slopes upward.

302. Attach the top facing tow ball to Cristiano Ronaldo's right leg using the socket.

Group 64:

303. Let's build the second shoe! Horizontally place a medium blue 1x2 plate with 2x2 side studs in front of you, so the side studs face the back. Horizontally place a black 1x2 plate with a tow ball on each short side on top of the ppp.

304. Horizontally place a blue 1x2 plate on top of the ppp.

305. Horizontally place the 2 left columns of a white 1x3 rounded plate on the ppp, so 1 column overhangs to the right. Horizontally place a blue 1x2 plate with 2x2 side studs hanging down on top of your part on the 2 left columns, so the side studs face the front.

306. Place a medium blue 1x1 plate with 1x2 upright facing side studs on the left column of the ppp, so the side studs face the back. Horizontally place a white 1x2 curved slope tile to the right of the ppp, so it slopes to the right.

307. Place a medium blue 1x1 brick with pin hole to the left of the ppp, so the pin holes face the right and the left. Place a blue 1x1 plate with 1x2 side studs hanging down on the ppp, so the side studs face the front.

308. Place a white 1x1 half round tile on the top row of back facing side studs. Vertically place a gold 1x2 half round tile with stud upright on the 2 bottom rows of back facing side studs on the left column, so the rounded edge faces the right. place a white 2x2 tile with 2 1x1 curved cutouts upright to the right and to the top of the ppp.

309. Repeat the 3 parts symmetrically to the front.

310. Flip your second shoe build, so the tow ball located on the same side of the 1x2 curved slope tile faces up on the right. Place a white 2x1 triple slope tile with inside stud holder upright on the left facing side stud, so the flat side faces down.

311. Place a gold 1x1 round plate with open stud on the bottom right facing antistud. Place a blue 1x2 curved inverted slope tile vertically upright on the 2 right facing antistuds, so it slopes upward.

312. Attach the top ball to Cristiano Ronaldo's left leg using the socket.

Group 65:

313. Bring Back your main build and position it horizontally in front of you, so the big number seven is on the back. Locate 2 holes each one with 1 up facing socket. Attach the bottom tow balls of the shoes to these sockets, so the Cristiano Ronaldo is facing the front.

314. The pin holes of the shoes should align with the pin holes of the base. Insert a grey 2L bar with 1L pin with stud from top to bottom into each top facing hole of the 2 shoes, so there are 2 in total. Push them all the way down to firmly secure.

315. Vertically place the back row of a white 1x2 slope tile with grille on the stud of each 2 ppps, so they slope to the front.

316. Rotate your build 90 degrees clockwise, so the Ronaldo is facing the left. Place the right column and the back row of a medium blue 2x2 curved corner tile on the front facing side stud of the front shoe, so the rounded edge faces the top left. Repeat symmetrically to the back. Then, repeat both placements to the back shoe.

317. Insert a blue 3L bar from top to bottom into the top facing pin hole located between the 2<sup>nd</sup> and 3<sup>rd</sup> rows from the front on the base, so 2L extends upward.

318. Let's make a part! vertically place a yellow 2L pin round connector with slot, so the pin holes face the front and the back. Insert a black 2L pin from front to back into the front facing pin hole, so 1L extends to the front. Repeat symmetrically to the back. Hold your part vertically upright and insert the bottom bar into the open inner stud of a white, black, blue, and pink half soccer ball. Attach the bottom facing open stud of a second half soccer ball onto the top facing 1L pin. Attach your soccer ball using one of the outward holes from top to bottom onto the 2L top facing bar.

What a legendary finish! In Bag 8 you've brought the whole scene to life — you built Cristiano's head with his iconic hairstyle, you placed his powerful shoes ready for action, and you completed the official FIFA ball, the heart of every unforgettable match. With these final pieces, your build stands complete: a moment of pure football magic captured forever in bricks. You've reached the end of the set and the alternative model with skill, patience, and the spirit of a true champion. Enjoy your creation — you've earned the victory!

Congratulations on finishing your build! Would you like to inspire other blind people to build LEGO sets? Let's feature your build on our [Builders page](#). It's easy and we will do all the work! Just contact us at [info@bricksfortheblind.org](mailto:info@bricksfortheblind.org) and together we will make it happen!

We hope you enjoyed building your LEGO set! Bricks for the Blind is able to create these text-based building instructions thanks to generous donations from our builders. If you enjoy the instructions we create, please consider making a \$5 donation at <https://www.gofundme.com/f/bricks-for-the-blind-gofundme>. Bricks for the Blind is a registered tax exempt 501(c)(3) corporation.

Please [sign up](#) for our newsletter and follow us on [Facebook](#) and [Instagram](#) to be the first to know when new instructions are available.

At the end of the instructions set is an advertisement for the Lego Editions 43012 Cristiano Ronaldo Soccer Highlights.